The EZDown installation guide for ISUZU

oty

PN

Parts Description


ED0400 Kit Components

ED0403 ED0404 **ED0303**

ED0401 162554 ED0405 ED0308 ED0005 ED0206 **ED0006** ED0406



STABILUS





There are two parts of this vehicle that you will be working on:

A/ Tail gate pillar B/ Tail gate bracket hinge

Please note the safety guidelines with reference to loading weight on tailgate after installation of EZDown. Visit our website at www.ezdown.co.za to see EZDown in action.




Remove the rubber.

Remove the hinge bolt.

Put the big diameter washer onto the bottom mounting stud and screw it into the hinge mounting bolt hole. Don't forget to tighten.























STEP 11

STEP 10

0

STEP

 ∞

STEP

STEP 7

O

STEP (

Please store your OEM Parts.

which will now release mounting bracket bolt, Remove the Steel bar


Please keep re-bound

mounting bolt.

rubber bracket handy as this is reused!


Remove the Steel bar

Remove the top Steel bar mounting bolt. the whole steel bar.























STEP.13 Place the damper with Piston rod facing down on the STEP 12

mounting studs.




Attach the E clips in place on the top and bottom studs.



Remove the other side steel bar as per prior steps 6 through to 9.

STEP 15

STEP 14











STEP 16

STEP 17

Place the last cable mounting stud through the cable eye and place a 2mm small diameter washer into the steel bar mounting onto the stud and insert it hole, and tighten in place.





Fit the warning sticker to the tailgate to ensure the tailgate does not get overloaded.

STEP 19

