TAG DESCRIPTION TABLE

MIL-STD-38784 V8a

6 December 2007

abbrsect

Abbreviation Section

Description: Identifies the paragraph used to define abbreviations/acronyms and the associated list.

Source paragraph: 4.3.4 & 4.5.9

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, (abbrtitle?, acronymlist))`

Used in Elements: `forward, preface, and intro`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.

caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

abbrtitle

Abbreviation Title

Description: Identifies the title for the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `abbrsect`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

acronym

Acronym

Description: Identifies the first time an acronym or abbreviation is used in a chapter. The def part of the acronym is used to define the acronym/abbreviation, while the term part of the acronym contains the actual acronym/abbreviation. Within the text, the term portion will be surrounded with parenthesis.

Source paragraph: 4.3.4 & 4.5.9

Content Model: `(def, term) -(acronym | figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: exclus and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

acronymlist

Acronym/Abbreviation List

Description: Identifies the list of acronyms and abbreviations.

Source paragraph: 4.3.4 & 4.5.9

Content Model: `(acronymrow | (term, def))+ -(acronym | figure | table | foldout | objmedia)`

Used in Elements: `abbrsect`

Entities used in this element: exclus and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	**NUTOKEN**	**2.5IN**	Allows you to define the right term width
ltermwidth	**NUTOKEN**	**1IN**	Allows you to define the left term width
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the list is autogenerated.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

acronymrow

Acronym/Abbreviation List Row

Description: Identifies a set of term and definition for an acronym/abbreviation list.

Source paragraph: 4.3.4 & 4.5.9

Content Model: `(term, def)`

Used in Elements: `acronymlist`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

activity

Reporting Activity

Description: Identifies the activity submitting a technical publication deficiency report list.

Source paragraph: 4.5.9

Content Model: `(#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+`

Used in Elements: `tpdrrow` and `tpdrtbl`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

address

Change Sheet Name/Address

Description: Identifies the name and address of the activity responsible for preparation of the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: `(#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+`

Used in Elements: `chginssht`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

appendix

Appendix

Description: Identifies an appendix to the manual

Source paragraph: 4.2.9.6

Content Model: `(title, para0+) +(ftnote | figure | table | foldout | objmedia)`

Used in Elements: `rear`

Entities used in this element: append, inclus, and chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

applic

Applicability/Effectivity Definition Entry

Description: Defines applicability/effectivity markings.

Source paragraph: 4.3f & 4.5.9

Content Model: `(term, def)`

Used in Elements: `applicdef`

Entities used in this element: chgatt and yesorno

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#REQUIRED**	Allows the author to generate a unique ID for use when referencing this entry.
flagnote	**NUMBER**	**1**	Identifies whether flagnotes (TV Screens) shall be used to display Effectivity.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

applicabil

Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicabilty/effectivity markings defined in the applicability definition (applicdef) to appear at that point in running text.

Source paragraph: 4.3f

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(applicabil | figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

applicdef

Applicability/Effectivity Definition

Description: Identifies the paragraph used to define applicability/effectivity markings, and the associated list.

Source paragraph: 4.3f

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, (appltitle?, applichd?, applic+))`

Used in Elements: `foreword, preface, and intro`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	**NUTOKEN**	**2.5IN**	Allows you to define the right term width. Their is currently no FOSI support for this attribute.
ltermwidth	**NUTOKEN**	**1IN**	Allows you to define the left term width. Their is currently no FOSI support for this attribute.
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.

applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

applichd

Applicabilty/Effectivity List Column Headings

Description: Defines the column headings used for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: `(term, def)`

Used in Elements: `applicdef`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

appltitle

Applicability/Effectivity Definition

Description: Identifies the title for the applicabilty/effectivity list.

Source paragraph: 4.3f

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `applicdef`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

authnot

Authority Notice

Description: Identifies the authority notice at the bottom of the title page.

Source paragraph: 4.5.1.15

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

auxfront

Auxillary Front

Description: Identifies the front matter that appears in second and subsequent volumes, and second and subsequent parts in a volume.

Source paragraph: 4.2.9.1

Content Model: `(warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro)?, safesum?) +(ftnote)`

Used in Elements: `docpart` and `volume`

Entities used in this element: auxfrnt and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

bindByCoords

Bind By Coordinates

Description: Identifies coordinates on a graphic that may be used for referencing. Please note that there is currently no FOSI support for this element.

Source paragraph: None

Content Model: `(xref*)`

Used in Elements: `graphic`

Entities used in this element: cgmatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
coords	**CDATA**	**#REQUIRED**	A list of the coordinates identifing the region on the graphic.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
title	**CDATA**	**#IMPLIED**	Label / Screentip of hotspot
descript	**CDATA**	**#IMPLIED**	Description of graphical hotspot
visibility	**(VISIBLE | HIDDEN)**	**VISIBLE**	The 'visibility' attribute indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	**(INTERACTIVE | NONE)**	**NONE**	The 'interactivity' attribute indicates if an object may receive mouse events. When the 'interactivity' of an object is set to off, events for this object are disabled.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

bindById

Bind By ID

Description: Identifies ID of a region in a CGM that may be used for referencing. Please note that there is currently no FOSI support for this element.

Source paragraph: None

Content Model: `(xref*)`

Used in Elements: `graphic`

Entities used in this element: cgmatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
objectid	**CDATA**	**#REQUIRED**	The name of the ID identifing the region on the CGM.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
title	**CDATA**	**#IMPLIED**	Label / Screentip of hotspot
descript	**CDATA**	**#IMPLIED**	Description of graphical hotspot
visibility	**(VISIBLE | HIDDEN)**	**VISIBLE**	The 'visibility' attribute indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	**(INTERACTIVE | NONE)**	**NONE**	The 'interactivity' attribute indicates if an object may receive mouse events. When the 'interactivity' of an object is set to off, events for this object are disabled.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

bindByName

Bind By Name

Description: Identifies name of a region on a CGM that may be used for referencing. Please note that there is currently no FOSI support for this element.

Source paragraph: None

Content Model: `(xref*)`

Used in Elements: `graphic`

Entities used in this element: cgmatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
ap-stargetname	**CDATA**	**#REQUIRED**	The name of the region on the CGM.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
title	**CDATA**	**#IMPLIED**	Label / Screentip of hotspot
descript	**CDATA**	**#IMPLIED**	Description of graphical hotspot
visibility	**(VISIBLE | HIDDEN)**	**VISIBLE**	The 'visibility' attribute indicates if an object is visible or not. A non-visible object behaves like a non-interactive object (i.e., it cannot be clicked or highlighted).
interactivity	**(INTERACTIVE | NONE)**	**NONE**	The 'interactivity' attribute indicates if an object may receive mouse events. When the 'interactivity' of an object is set to off, events for this object are disabled.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

body

Body

Description: Identifies the portion of the manual where chapters are used, exclusive of front matter and appendices, indexes, etc.

Source paragraph: 4.2.9.3 & 4.5.1.3.2 & 3.2.38

Content Model: `(chapter, chapter+, ipbchap?, ddchapter?) +(ftnote)`

Used in Elements: `doc, docpart, and volume`

Entities used in this element: bodyele

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numcols	**(1 | 2)**	**#REQUIRED**	Allows the author to define the page format as one or two columns for this section of the manual.

brk

Break

Description: This element is used to indicate that a column, line, or page break should be forced at that point. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: None.

Content Model: `EMPTY`

Used in Elements: `Globally included in doc`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	**(COL | LINE | NPG)**	**LINE**	Allows the author to define what type of break will occur when the brk element is used - column, line, or page.

caution

Caution

Description: Identifies a CAUTION in the manual.

Source paragraph: 4.3.10

Content Model: `(para*) -(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution)`

Used in Elements: `entry, step1, step2, step3, step4, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, subpara8, abbrsect, applicdef, dddesc, ddindex, ipbfinding, ipbesdsdesc, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbshtnoexplm, ipbsimassm, ipbsmrexpl, ipbuseonexpl, para0, ratddesc, tctolist, tmimprep, symsect, and lrp. Globally included in safesum.`

Entities used in this element: list, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

change

Changed Information

Description: Identifies material that has been changed. In order to add material, the type attribute should be set to add, and the change element should surround the added material. In order to delete material where a complete history of all changes to the document are being preserved, the type attribute should be set to delete and the change element should surround the deleted material. If all changes are not being preserved, change the material and surround it with a change element, setting the type attribute to add.

Source paragraph: 4.7.3.9

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: text, exclus, yesorno, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
level	**NMTOKEN**	**#REQUIRED**	Defines the change level for the modification.
change	**(ADD | DELETE)**	**ADD**	Defines the type of change - addition or deletion of text.
mark	**NUMBER**	**1**	Allows the author to define if a change mark will appear for this change. 1. will produce a change bar on the page - 0. will suppress it.

revchg	**NUMBER**	**0**	Allows the author to tag whether this modification is for a revision or a change. 0. indicates a change. 1. for a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

chapter

Chapter

Description: Identifies a chapter.

Source paragraph: 4.2.9.3

Content Model: `(title, ((section, (note?, section)+) | para0+)) +(figure | table | foldout | objmedia)`

Used in Elements: `body`

Entities used in this element: chap, inclus, and chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

chgdate

Change Date

Description: Identifies the date of the latest change.

Source paragraph: 4.5.1.17

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chghistory

Change History

Description: Identifies the beginning of the change history dates. The first date in the chghist is the original date and subsequent dates are change 1, change 2, etc.

Source paragraph: 4.5.3

Content Model: `(chginfo*)`

Used in Elements: `idinfo`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chginfo

Change Information

Description: Container element to identify the change information contained in the change history of the document.

Source paragraph: 4.5.3

Content Model: `(chgtxt?, date)`

Used in Elements: `chghistory`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chginssht

Change Instruction Sheet

Description: Identifies the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: `(chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?)`

Used in Elements: `front` and `auxfront`

Entities used in this element: chgsht

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chglist

Change List

Description: Identifies the Remove Pages and Insert Pages columns on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: `(tabmat | (removepg, insertpg)+)`

Used in Elements: `chginssht`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chgnum

Change Number/Letter

Description: Identifies the latest change number/letter.

Source paragraph: 4.7.3.1, 4.2.1.4.2.3, 4.5.1.17, & 4.5.3.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chgpara

Change Paragraph

Description: Identifies the paragraph change status.

Source paragraph: 4.7.3.11.2

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chgrec

Change Record

Description: Identifies the change record page. This page will be an empty table whose contents will be completed by the person filing the change pages in the manual. The change record page will be automatically generated by the FOSI.

Source paragraph: 4.5.5

Content Model: `EMPTY`

Used in Elements: `front` and `auxfront`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

chgtxt

Change Text

Description: This element is optional and is used to provide an alpha representation of the current change level. This element will only be tagged by those branches of the armed services that require alpha change numbers. For all other users, this element is optional and should not be tagged.

Source paragraph: 4.5.3

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `chginfo`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

clink

Contextual Link

Description: One of several HyTime elements. Can be used in any situation similar to the xref or extref element - will reference any nameloc declared.

Source paragraph: None

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
HyBase	**NAME #FIXED**	**HYLINK**	Used in combination with HyTime to establish contextual link.
HyBnames	**CDATA #FIXED**	**"REFSUB LINKEND"**	Used in combination with HyTime to establish contextual link.

anchrole	**CDATA #FIXED**	**"REFMARK REF-SUB #LIST"**	Used in combination with HyTime to establish an anchor role for contextual links.
anchcstr	**NAMES**	**SELF REQUIRED**	Used in combination with HyTime to establish type of anchor string defined for a contextual link.
linkend	**CDATA**	**#IMPLIED**	References a linkend declared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

cntentry

Table of Contents Entry

Description: Identifies an entry for a manually tagged Table of Contents

Source paragraph: 4.5.6

Content Model: `(label, title, pageno)`

Used in Elements: `contents` and `volcontents`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
inlevel	**NUMBER**	**#IMPLIED**	Identifies the indenture level of the entry.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

cogact

Cognizant Field Activity

Description: Identifies Cognizant Field Activity on the title page and is included in the distribution statement. This is a Navy requirement.

Source paragraph: 4.5.1.11

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

colspec

Column Specification

Description: Defines a column in a table. Each column must have a column specification. The column specification defines the width of the column and an optional name used when column is starting or ending a horizontal span or referenced in a table entry. Column specifications in a table group apply to the table heading (boxheads) and the table body. The table heading can redefine the column specifications if needed, however, the table body must use the column specifications defined in the table group.

Source paragraph: 4.3.9

Content Model: `EMPTY`

Used in Elements: `entrytbl, tfoot, tgroup, and thead`

Entities used in this element: yesorno and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
colname	**NMTOKEN**	**#IMPLIED**	Allows the author to define a column name.
colnum	**NUMBER**	**#IMPLIED**	Allows the author to define a column number.
align	**(LEFT | RIGHT | CENTER | JUSTIFY | CHAR)**	**#IMPLIED**	Allows the author to align text within the cell.
charoff	**NUTOKEN**	**#IMPLIED**	Determines the distance the cell content should offset from the horizontal alignment character.
char	**CDATA**	**#IMPLIED**	Defines the alignment character that can be used to align values within a column.
leftmar	**NUTOKEN**	**#IMPLIED**	Defines the left margin for the cell.
rightmar	**NUTOKEN**	**#IMPLIED**	Defines the right margin for the cell.
topmar	**NUTOKEN**	**#IMPLIED**	Defines the top margin for the cell.
botmar	**NUTOKEN**	**#IMPLIED**	Defines the bottom margin for the cell.
mindepth	**NUTOKEN**	**#IMPLIED**	Allows you to define a minimum depth if desired.
colwidth	**CDATA**	**#IMPLIED**	Allows you to define the column widths.
colsep	**NUMBER**	**#IMPLIED**	Allows you to include a vertical line to seperate columns. A value of 1. for this attribute will generate column separators.
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of 1. for this attribute will generate row separators.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

contents

Table of Contents

Description: Identifies the table of contents. For Army documents, the table of contents consists of chapter and section titles. For all other services, the table of contents consists of chapter, section, and paragraph titles. If an index is used, the table of contents consists of chapter, section, and primary paragraph titles. This information is automatically compiled by the FOSI.

Source paragraph: 4.5.6

Content Model: `(cntentry* | #PCDATA)*`

Used in Elements: `front and auxfront`

Entities used in this element: cntnt and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1. when the Table of Contents is autogenerated.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

contractno

Contract Number

Description: Identifies the contract number on the title page.

Source paragraph: 4.5.1.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

copyright

Copyright Notice

Description: Identifies the copyright notice on the title page.

Source paragraph: 4.1.2 & 4.5.1.14

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

dataiden

Data Identification

Description: May be used to identify specific types of data (e.g. hazardous materials, special tools, etc.). Use of this element does not affect the formatted output, but is intended to be used in database functions and data searches.

Source paragraph: 4.5.1.7, 4.5.1.16, 4.5.1.17, & 4.5.3.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(dataiden | figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks,`

removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	**CDATA**	**#REQUIRED**	Defines the type of data being used in the database functions and database searches.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

date

Date

Description: Identifies a date.

Source paragraph: 4.5.1.17 & 4.5.9.4b

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)

Used in Elements: chginssht, chginfo, ratdentry, and tctorow

Entities used in this element: text, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

dateinc

Date Incorporated

Description: Identifies the date the information affected by the directive or engineering change proposal was incorporated into the manual.

Source paragraph: 4.5.9.4d

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ratdentry`

Entities used in this element: text, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ddchapter

Difference Data Chapter

Description: Identifies the difference data chapter.

Source paragraph: 4.7.3.3

Content Model: `(dddesc, (ddindex, ddsheet+)?) +(figure | table | foldout | objmedia)`

Used in Elements: `body`

Entities used in this element: ddchap, inclus, and chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
numcols	**(1 | 2)**	**1**	Allows the author to define the page format as one or two columns for this section of the manual.

dddesc

Difference Data Description

Description: Identifies the lead-in information for the difference data chapter.

Source paragraph: 4.7.3.3

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)`

Used in Elements: `ddchapter`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ddindex

Difference Data Index

Description: Identifies the paragraph used to lead-in to the difference data index, and its associated list.

Source paragraph: 4.7.3.3.1

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*, ddlist)`

Used in Elements: `ddchapter`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.

applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ddlist

Difference Data List

Description: Identifies the listing of part numbers to corresponding difference data sheets.

Source paragraph: 4.7.3.3

Content Model: `(partno, pageno)*`

Used in Elements: `ddindex`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ddsheet

Difference Data Sheet

Description: Identifies a difference data sheet.

Source paragraph: 4.7.3.3

Content Model: `((nomen, (partno+ | modelno+ | typedes+)), para0+)`

Used in Elements: `ddchapter`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

def

Definition

Description: Identifies a definition in a list

Source paragraph: 4.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `symsect, acronym, acronymlist, acronymrow, applic, applichd, defhd, deflist, glosslist, glossrow, ipbuseoncodelist, symrow`

Entities used in this element: text, exclus, secur and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

defhd

Definition List Column Headings

Description: Identifies the column headings for a definition list.

Source paragraph: 4.3.4

Content Model: `(term, def)`

Used in Elements: `deflist`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

deflist

Definition List

Description: Identifies a two-column definition list. This element can be used when a listing is needed to define particular terms.

Source paragraph: 4.3.4

Content Model: `(title?, defhd?, (term, def)+)`

Used in Elements: `para, entry, and ftnote`

Entities used in this element: chgatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	**NUTOKEN**	**1.9IN**	Allows you to set the right term width
ltermwidth	**NUTOKEN**	**0.7IN**	Allows you to set the left term width
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

destr

Destruction Notice

Description: Identifies the destruction notice on the title page.

Source paragraph: 4.5.1.13

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

discl

Disclosure Notice

Description: Identifies the disclosure notice on the title page.

Source paragraph: 4.5.1.10

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
disclose1	**CDATA**	**#IMPLIED**	Identifies which type of disclosure notice will appear on the title page. Use of this attribute will generate an alternate disclosure notice as opposed the notice generated by the FOSI.

distrib

Distribution Statement

Description: Identifies the distribution statement.

Source paragraph: 4.5.1.11

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	**(A | B | C | D | E | F | X)**	**#REQUIRED**	Identifies and displays type of distribution statement per STINFO requirements.

doc

Document

Description: Identifies the entire document

Source paragraph: 4.1.7

Content Model: `((volume, volume+) | (front, body, rear?)) +(pgbrk | brk | subjinfo | line | modreq | location | note)`

Used in Elements: `Top Level Element`

Entities used in this element: doc, service, docatt, secur, and pubatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
service	**(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)**	**#REQUIRED**	Identifies which branch of the service. If no branch is suitable, "FRN" shall be chosen
FRN	**CDATA**	**#IMPLIED**	Allows author to manually enter the branch. This will be displayed on the "A" page of the LEP
docid	**CDATA**	**#IMPLIED**	Allows for the author to define an identification number for the document.
docstat	**(REVISION | CHANGE | PRELIM | DRAFT | FORMAL)**	**PRELIM**	Author can stipulate what form the manual is in.
verstatpg	**(VER | UN-VER)**	**UNVER**	Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail.
index	**NUMBER**	**0**	Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC
security	**(U | C | S | N)**	**N**	Identifies security level of the element.

caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element. For proper formatting on foldout pages, the caveat should be preceded and succeded with enough "spaces" to occupy the same length as the security classification.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
controlno	**CDATA**	**00000000**	System generated attribute values used included for compliance with the JCALS menu structure.
cycle	**CDATA**	**NEW**	System generated attribute values used included for compliance with the JCALS menu structure.
chglevel	**NUMBER**	**#IMPLIED**	System generated attribute values used included for compliance with the JCALS menu structure.
initlabel	**NUMBER**	**#IMPLIED**	System generated attribute values used included for compliance with the JCALS menu structure.
initpage	**NUMBER**	**1**	System generated attribute values used included for compliance with the JCALS menu structure.
docno	**CDATA**	**#IMPLIED**	System generated attribute values used included for compliance with the JCALS menu structure.
highguid	**NUMBER**	**0**	System generated attribute values used included for compliance with the JCALS menu structure.
labelstyle	**CDATA**	**FAN**	System generated attribute values used included for compliance with the JCALS menu structure.
HyTime	**NAME #FIXED**	**HYDOC**	Used to alert the processing system that this is a HyTime compliant document. This attribute is only required and/or effective with a HyTime aware processor.

doctype

Document Type

Description: Identifies the type of manual on the title page (e.g. maintenance instructions, illustrated parts breakdown, inspection manual, etc.).

Source paragraph: 4.1.7

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

downgrd

Downgrade Notice

Description: Identifies the classification downgrade notice on the title page.

Source paragraph: 4.4

Content Model: `(phrase | oadr)`

Used in Elements: `idinfo`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ecpno

Engineering Change Proposal Number

Description: Identifies the ECP Number in the record of applicable technical directives.

Source paragraph: 4.5.9.4

Content Model:

```
((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
  | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |
  ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink |
  object)+) -(figure | table | foldout | objmedia)
```

Used in Elements: `ratdentry`

Entities used in this element: text, exclus and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

effdatenot

Effective Date Notice

Description: Identifies the effective date notice on the title page.

Source paragraph: 4.5.1.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

emphasis

Emphasis

Description: Identifies portions of text to be highlighted (e.g. italic, bold, etc.). This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: text, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
type	**(B | I | BI | X | O | SUP | SUB)**	**#REQUIRED**	Displays different types of emphasis. b=bold i=italics bi=bold/italics q=quotes x=box o=overscore sup=superscript sub=subscript
fontsize	**NUTOKEN**	**#IMPLIED**	Allows author to set the font size which will be applied to the text within the emphasis tags.
color	**(BLACK | WHITE | RED | ORANGE | YELLOW | GREEN | BLUE | VI-OLET | BROWN | GRAY)**	**#IMPLIED**	Allows author to set the color which will be applied to the text within the emphasis tags.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the ele-ment was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

entry

Table Entry

Description: Identifies a table entry (cell).

Source paragraph: 4.2.7

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist | warning | caution | note )+`

Used in Elements: `row`

Entities used in this element: entry, entryatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
colname	**NMTOKEN**	**#IMPLIED**	Allows the author to specify the name of the column to use
spanname	**NMTOKEN**	**#IMPLIED**	Allows the author to define a span name.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
morerows	**NUMBER**	**0**	Allows you to define a vertical span on entries within a table.
colsep	**NUMBER**	**#IMPLIED**	Allows you to include a vertical line to seperate columns. A value of 1. for this attribute will generate column separators.
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of 1. for this attribute will generate row separators.
rotate	**NUMBER**	**0**	Toggle switch to rotate the contents of the entry 90 degrees.
valign	**(TOP | MIDDLE | BOTTOM)**	**#IMPLIED**	Defines the vertical alignment of text within a cell.
align	**(LEFT | RIGHT | CENTER | JUSTIFY | CHAR)**	**#IMPLIED**	Defines the horizontal alignment of text within a cell.
charoff	**NUTOKEN**	**#IMPLIED**	Determines the distance the cell content should offset from the horizontal alignment character.
char	**CDATA**	**#IMPLIED**	Defines the alignment character that can be used to align values within a column.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

entrytbl

Entry Table

Description: Identifies a table within a table entry. This element allows a table cell to be divided into a sub-table, with its own set of rows, columns, and entries. Use of this element basically allows the author to create a table within a table.

Source paragraph: 4.2.7

Content Model: `(colspec*, spanspec*, thead?, tbody) -(entrytbl)`

Used in Elements: `row`

Entities used in this element: yesorno, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
cols	**NUMBER**	**#REQUIRED**	Allows you to define the number of columns.
colname	**NMTOKEN**	**#IMPLIED**	Allows the author to specify the name of the column to use
spanname	**NMTOKEN**	**#IMPLIED**	Allows the author to define a span name.
colsep	**NUMBER**	**#IMPLIED**	Allows you to include a vertical line to seperate columns. A value of 1. for this attribute will generate column separators.
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of 1. for this attribute will generate row separators.
align	**(LEFT | RIGHT | CENTER | JUSTIFY | CHAR)**	**#IMPLIED**	Defines the horizontal alignment of text within a cell.
charoff	**NUTOKEN**	**#IMPLIED**	Determines the distance the cell content should offset from the horizontal alignment character.
char	**CDATA**	**#IMPLIED**	Defines the alignment character that can be used to align values within a column.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

esds

Electrostatic Discharge Sensitive Symbol

Description: Identifies the ESDS symbol. Use of this element will cause the ESDS symbol to appear at that point in the running text. The esds attribute should be used to place the ESDS symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.4

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

expcont

Export Control Notice

Description: Identifies the export control notice on the title page. Note that the export control notice entity (&expcontnot;) may be used in place of entering the text manually.

Source paragraph: 4.5.1.12

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) +(underline)`

Used in Elements: `idinfo` and `chginssht`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

extapplicabil

External Applicability/Effectivity

Description: Identifies a portion of text as being applicable to a specific model, serial number, part number, etc. Use of this element will cause the applicabilty/effectivity markings to appear at that point in running text.

Source paragraph: 4.3f

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(applicabil | extapplicabil | figure | table | foldout | objmedia)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno,`

`topic`, `tpdrlocation`, `tpdrno`, `typedes`, `typeno`, `underline`, `vollepchg`, `volleppage`, `volnot`, and `volnum`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
targetdoc	**CDATA**	**#IMPLIED**	Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data - this ID must equal the ID of the external document.
targetid	**CDATA**	**#IMPLIED**	Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document.
displayvalue	**CDATA**	**#IMPLIED**	If the author needs to add additional, unique information for purposes of referencing an external document, this attribute should be tagged. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	**NAME #FIXED**	**CLINK**	Used in combination with HyTime to establish contextual link.
HyNames	**CDATA #FIXED**	**LINKEND XREFID**	Used in combination with HyTime to establish contextual link.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

extref

External Reference

Description: Generates a reference to an external document.

Source paragraph: 4.3.1m

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
targetdoc	**CDATA**	**#IMPLIED**	Identifies the external document that you are referencing. This value should equal an ID specified in the List of Related Publications. For implementing external references in digital data - this ID must equal the ID of the external document.
targetid	**CDATA**	**#IMPLIED**	Provides the ID for the element being referenced in the external document. The value of this attribute should equal the ID of an element in the referenced document.
displayvalue	**CDATA**	**#IMPLIED**	If the author needs to add additional, unique information for purposes of referencing an external document, this attribute should be tagged. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	**NAME #FIXED**	**CLINK**	Used in combination with HyTime to establish contextual link.
HyNames	**CDATA #FIXED**	**LINKEND XREFID**	Used in combination with HyTime to establish contextual link.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

fcp

Fracture Critical Parts

Description: Identifies the fracture critical parts.

Source paragraph: 4.3.10.5

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

figno

Figure Number

Description: Identifies the figure number within the illustration list when the illustration list is manually tagged.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `illlistrow, illuslist, and volilluslist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

figure

Figure

Description: Identifies an illustration.

Source paragraph: 4.2.8

Content Model: `(title, (((subfig | subfigfo), (subfig | subfigfo)+) | ((graphic, legend?) | tabdisplay)+)) -(figure | table | foldout | objmedia)`

Used in Elements: `ipbplgrp` and globally `included` in `appendix, chapter, ddchapter, foreword, intro, ipbfwordchap, preface,` and `safesum.`

Entities used in this element: fig, exclus, and figatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pgwide	**NUMBER**	**1**	Defines whether the figure will fill the entire width of the page.
orient	**(PORT | LAND | LAND2)**	**PORT**	Defines the orientation of the figure. The land2 attribute also rotates the figure title.
id	**ID**	**#IMPLIED**	This allows you to identify each element and later reference it by its id value.
applicref	**IDREFS**	**#IMPLIED**	Allows you to assign an applicable reference
legend	**NUMBER**	**0**	This attribute is set to 1 when a legend is tagged as part of the figure.
nxtpg	**NUMBER**	**0**	Indicates whether the legend should appear on the same page as the graphic or on the next page.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.

label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

foldout

Foldout

Description: Identifies a foldout

Source paragraph: 4.2.4.1

Content Model: `(title, (((subfig | subfigfo), (subfig | subfigfo)+) | ((graphic, legend?) | tabdisplay)+)) -(figure | table | foldout | objmedia)`

Used in Elements: `foldsect` and `globally included in appendix, chapter,` and `ddchapter.`

Entities used in this element: fig, exclus, yesorno, and figatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pgstyle	**(11X17 | 11X20.5 | 11X24 | 11X27.5 | 11X31 | 11X34.5 | 11X38 | 11X41.5 | 11X45)**	**#IMPLIED**	Defines the pagesize for the foldout

blankapron	**NUMBER**	**1**	Toggle to indicate whether the foldout includes a blank apron. A value of ’1’ indicates that the foldout will have a blank apron, a value of ’0’ indicates that the foldout will not have a blank apron.
pgwide	**NUMBER**	**1**	Defines whether the figure will fill the entire width of the page.
orient	**(PORT | LAND | LAND2)**	**PORT**	Defines the orientation of the figure. The land2 attribute also rotates the figure title.
id	**ID**	**#IMPLIED**	This allows you to identify each element and later reference it by its id value.
applicref	**IDREFS**	**#IMPLIED**	Allows you to assign an applicable reference
legend	**NUMBER**	**0**	This attribute is set to 1 when a legend is tagged as part of the figure.
nxtpg	**NUMBER**	**0**	Indicates whether the legend should appear on the same page as the graphic or on the next page.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

foldsect

Foldout Section

Description: Identifies the area where foldouts are placed when they are included at the end of the manual. This element is not marked as a chapter or section, but is merely a placeholder for the foldouts.

Source paragraph: 4.2.4.1d

Content Model: `(foldout+) -(note)`

Used in Elements: `rear`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

foreword

Foreword

Description: Identifies the foreword of the manual. This element is identical to the preface and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: `(para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*) +(figure | table)`

Used in Elements: `front` and `auxfront`

Entities used in this element: fpi and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

front

Front

Description: Identifies the front matter of the manual.

Source paragraph: 4.5

Content Model: `(warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro), safesum?) +(ftnote)`

Used in Elements: `doc and volume`

Entities used in this element: frnt and yesorno

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
t2page	**NUMBER**	**0**	A toggle that allows the author to turn the second title page on if necessary.
numcols	**(1 | 2)**	**#REQUIRED**	Allows the author to define the page format as one or two columns for this section of the manual.

ftnote

Footnote

Description: Identifies footnotes to paragraphs and tables. The footnote appears on the same page that the corresponding footnote reference (<ftnref>) occurs. Only the footnote whose id matches the xrefid specified in the footnote reference will appear. Footnotes to text will be displayed at the bottom of the page where the footnote is referenced.

Source paragraph: 4.3.1n & 4.2.2

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist)+ -(ftnote | ftnref | figure | table | foldout | objmedia)`

Used in Elements: `Globally included in appendix, auxfront, body, and front.`

Entities used in this element: text, list, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#REQUIRED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ftnref

Footnote Reference

Description: Identifies a reference to a footnote. This element will cause the footnote number/letter/symbol to appear at the point in the text where used, and will cause the footnote number/letter/symbol and the footnote text to appear at the bottom of the page.

Source paragraph: 4.3.1n

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

xrefid	**IDREF**	**#REQUIRED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
mark	**(NUM | SYM | ALPHA)**	**NUM**	Indicates the type of symbol or mark used to indicate a footnote.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

glossary

Glossary

Description: Identifies the glossary of the manual.

Source paragraph: 4.2.9.7

Content Model: `((letter?, glosslist)+) -(note)`

Used in Elements: `rear`

Entities used in this element: glossry, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the glossary is autogenerated.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

glosslist

Glossary List

Description: Container element for the glossary list of definitions and terms.

Source paragraph: None.

Content Model: `(glossrow | (letter?, (term, def)))+`

Used in Elements: `glossary`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

glossrow

Glossary List Row

Description: Container element for the glosslist element to allow for insertion/deletion or entire rows.

Source paragraph: None.

Content Model: `(letter?, (term, def))`

Used in Elements: `glosslist`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

graphic

Graphic

Description: Identifies a graphic within a figure, or a graphic within running text or tables. If used within running text, no figure number or title will be generated. Note that the HCP and ESDS symbols can be placed in running text by using the hcp and esds elements. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: None.

Content Model: `(bindById | bindByName | bindByCoords)*`

Used in Elements: `figure, icon, subfig, subfigfo, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: graphatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
boardno	**ENTITY**	**#REQUIRED**	Allows the author to place the name of the graphic entity here.
graphsty	**NMTOKEN**	**#IMPLIED**	Graphic style
llcordra	**CDATA**	**#IMPLIED**	Lower left world coordinates (1,1). If scalefit=0 and reprowid is not specified default is lower left.

rucordra	**CDATA**	**#IMPLIED**	Upper right world coordinates (10000,10000). If scalefit=0 and reprodep i not specified default is upper right.
reprowid	**NUTOKEN**	**#IMPLIED**	Specifies the horizontal dimension of a graphic bounding box (width).
reprodep	**NUTOKEN**	**#IMPLIED**	Specifies the vertical dimension of a graphic bounding box (depth).
hscale	**NUMBER**	**#IMPLIED**	Horizontal Scaling
vscale	**NUMBER**	**#IMPLIED**	Vertical Scaling
scalefit	**NUMBER**	**#IMPLIED**	Scale to fit. No affect if hscale and vscale set to zero.
hplace	**(LEFT | RIGHT | CENTER)**	**#IMPLIED**	Horizontal Placement
vplace	**(TOP | MIDDLE | BOTTOM)**	**#IMPLIED**	Vertical Placement. This attribute is not currently supported by the FOSI
coordst	**CDATA**	**#IMPLIED**	Specifies coordinate to start graphic.
coordend	**CDATA**	**#IMPLIED**	Specifies coordinate to end graphic.
color	**NUMBER**	**0**	Option to choose color.
icon	**(YES | NO)**	**NO**	Specifies whether the graphic is full size or icon. Specifying icon will eliminate the textbrk surrounding the graphic.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

hazmat

Hazardous Material Name

Description: Identifies the hazardous material name used with a hazardous material warning icon.

Source paragraph: 4.3.10.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |`

ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: icon

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

hci

Hardness Critical Item

Description: Identifies the HCI symbol. Use of this element will cause the HCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCI symbol in a paragraph. The hci attribute should be used to place the HCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.3

Content Model: EMPTY

Used in Elements: ipbfwordchap, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

hcp

Hardness Critical Process

Description: Identifies the HCP symbol. Use of this element will cause the HCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the HCP symbol in a paragraph. The hcp attribute should be used to place the HCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.3

Content Model: `EMPTY`

Used in Elements: `ipbfwordchap, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

icon

Hazardous Material Warning Icon

Description: Identifies the hazardous material warnings. The hazardous material warning consists of a graphic(s) (e.g fire icon, poison icon, etc.), the hazardous material name, and the sequence number which identifies the order in which the hazardous material warnings are included in the safety summary. See Appendix A for further information on hazardous material warnings.

Source paragraph: 4.3.10.1

Content Model: `(graphic+, hazmat+, seqno)`

Used in Elements: `warning`

Entities used in this element: icon and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

idinfo

Identification Information (Title Page)

Description: Identifies the title page and cover (if used) of the manual.

Source paragraph: 4.5.1

Content Model: `(tmidno+, (chgnum, chgdate)?, chghistory, pretmidno*, volnum?, revnum?, doctype, maintlvl?, prtitle, subtitle?, (mfr+, contractno+)?, seal?, supersed?, suppl*, effdatenot?, volnot?, discl?, distrib, expcont?, destr?, copyright*, cogact?, moveddata?, authnot, downgrd?, pubdate)`

Used in Elements: `front` and `auxfront`

Entities used in this element: idinf

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

ilink

Independent Link

Description: One of several HyTime elements. Used in a situation of indirection where a specific ID is not declared in an external document and must be declared using nameloc and nmlist elements.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot,` and `volnum`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
anchrole	**CDATA**	**#REQUIRED**	Defines the anchor role assumed by the independent link. Used in combination with HyTime.
linkends	**IDREFS**	**#REQUIRED**	References the linkends declared within a nameloc element. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

illlistrow

Illustration List Row

Description: Container element so a row from the illustration list can be added/deleted.

Source paragraph: 4.5.7

Content Model: `(figno, title, pageno)`

Used in Elements: `illuslist`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

illuslist

List of Illustrations

Description: Identifies the list of illustrations in the manual. This information is automatically compiled by the FOSI. If this element is not used, no list of illustrations will appear in the manual.

Source paragraph: 4.5.7

Content Model: `(illlistrow | (figno, title, pageno))* -(note)`

Used in Elements: `front and auxfront`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the list of illustrations is autogenerated.

index

Index

Description: Identifies the index.

Source paragraph: 4.2.9.8

Content Model: `(indexrow | (letter?, (prentry, secentry*)))+ -(note)`

Used in Elements: `rear`

Entities used in this element: secur and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the index is autogenerated.
type	**(PARANO | PAGENO | BOTH)**	**PARANO**	Allows the author to determine whether page numbers, or paragraph numbers, or both page and paragraph numbers, figure, or table numbers are used.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

indexrow

Index Row

Description: Container element to allow a row from the index to be added/deleted.

Source paragraph: 4.2.9.8

Content Model: `(letter?, (prentry, secentry*))`

Used in Elements: `index`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

insertpg

Insert Page Column Entry

Description: Identifies an entry within the Insert Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model:
```
((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
  | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |
  ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink |
  object)+)
```

Used in Elements: `chglist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

internatlstd

International Standardization Agreement Note

Description: Identifies the international standardization agreement note. The paragraph number and title, of this note will be automatically generated by the FOSI.

Source paragraph: 4.5.9.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: text, verified, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

intro

Introduction

Description: Identifies the introduction of the manual. This element is identical to the preface and foreword elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: `(para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*) +(figure | table)`

Used in Elements: `front` and `auxfront`

Entities used in this element: fpi and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbcage

Commercial and Government Entity

Description: Identifies the design activity or government agency whose number appears in the part number column of the MPL.

Source paragraph: 3.6.7.3 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbcagecodes, ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6,` and `ipbpl7`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbcagecodes

Commercial and Government Entity Codes

Description: Identifies the design activity or government agency whose number appears in the part number column of the MPL. Table foot notes and foot note references are globally included on cage codes.

Source paragraph: 3.6.7.3 MIL-PRF-38807

Content Model: `(ipbcage+) +(tfoot | tfnref)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbchap

Illustrated Parts Breakdown Chapter

Description: Identifies the Illustrated Parts Breakdown Chapter

Source paragraph: 4.11

Content Model: `(ipbfwordchap, ipbpl, ipbnumindx?, ipbrfdsindx?)`

Used in Elements: `body`

Entities used in this element: chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbdesc

Description

Description: Identified the description of each part listed in the MPL.

Source paragraph: 3.6.7.4 MIL-PRF-38807

Content Model: `(nomen, ipbrefdes*, ipbsssn*, remarks?)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: descatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbesdsdesc

Illustrated Parts Breakdown Electrostatic Discharge Sensitive

Description: Identifies the esds in the IPB foreword

Source paragraph: 3.5.11 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.

fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbfigindex

Figure and Index Number

Description: Identifies the figure and index numbers in the MPL, the reference index and the numerical index. This element appears second in the Figure & Index/Sheet No column of the Parts List.

Source paragraph: 3.6.7.1, 3.7.2.2, 3.8.2.2 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbnumgrp, ipbnumrow, ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, ipbpl7, ipbrfdsgrp, and ipbrfdsgrprow`

Entities used in this element: text, yesorno, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
shown	**NUMBER**	**1**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
follows	**NUMBER**	**0**	Displays an 'F' and the preceding figure number and index number in the figure/index column when attribute is set to 1.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbfigureno

Figure and Index Number

Description: Identifies the figure and index numbers in the MPL, the reference index and the numerical index. This element appears first in the Figure & Index/Sheet No column of the Parts List.

Source paragraph: 3.6.7.1 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbfinding

Finding

Description: Tag used for finding part numbers, illustrations, and descriptions.

Source paragraph: 3.5.3 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.

hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbfwordchap

Illustrated Parts Breakdown Foreword

Description: Identifies the first section of the ipb chapter

Source paragraph: 3.5 MIL-PRF-38807

Content Model: `(para0+, ipbmodelcover, ipbserialization?, ipbfinding?, ipbsimassem?, ipbquickchgexpl?, ipbshtnoexpl?, ipbuseonexpl, ipbsmrexpl, ipbhcidesc?, ipbesdsdesc?, ipbpartstd, ipbmfrlist?, para0*) +(figure | table)`

Used in Elements: `ipbchap`

Entities used in this element: ipbforwd and chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbgroup10

Group 10

Description: Tag used to create a space beneath every tenth listing in the reference and numerical indexes

Source paragraph: 3.7.2, 3.8.2 MIL-PRF-38807

Content Model: `EMPTY`

Used in Elements: `Globally included in ipbnumindex and ipbrfdsindex`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbhcidesc

IPB hardness Critical Items

Description: Identifies the HCI in the IPB foreword

Source paragraph: 3.5.10 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.

ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbmfrlist

Manufacturer List

Description: Identifies the manufacturer list in the ipb foreword

Source paragraph: 3.5.13 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbmodelcover

Model Covered

Description: Identifies the model(s) covered by the manual in the ipb foreword

Source paragraph: 3.5.1 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0atts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.

oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbnumgrp

Numerical Group

Description: Container tag for the numerical index.

Source paragraph: 3.7 MIL-PRF-38807

Content Model: `((ipbnumgrprow | (partno, ipbfigindex))+)`

Used in Elements: `ipbnumindex`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbnumgrprow

Numerical Group Row

Description: Container tag for a row for the numerical index. Allows for insertion/deletion of entire row.

Source paragraph: 3.7 MIL-PRF-38807

Content Model: `(partno, ipbfigindex)`

Used in Elements: `ipbnumgrp`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbnumindx

Numerical Index

Description: Identifies the third section in the ipb chapter.

Source paragraph: 3.7 MIL-PRF-38807

Content Model: `(ipbnumgrp) -(note) +(ipbgroup10)`

Used in Elements: `ipbchap`

Entities used in this element: secur and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
cols	**(2 | 3)**	**3**	Defines the number of columns desired for the numerical index table.
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the numerical index is autogenerated.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**CDATA**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpartnosym

Illustrated Parts Breakdown Part Number Symbol

Description: Identifies the part number symbol that appears in the part number column of the Maintenance Parts List.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpartstd

Parts Standardization

Description: Identifies a required paragraph in the ipb foreword.

Source paragraph: 3.5.12 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.

fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl

Maintenance Parts List

Description: Identifies the second section in the ipb chapter.

Source paragraph: 3.6 MIL-PRF-38807

Content Model: `(ipbplgrp+) +(ipbplbrk)`

Used in Elements: `ipbchap`

Entities used in this element: chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl0

Parts list - Indenture 0

Description: Indents the first nonindenture in the description column of the MPL

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl1*)`

Used in Elements: `ipbpl0tbl`

Entities used in this element: mpl, verified, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.

ipbpl0tbl

Parts list table

Description: Identifies the parts list table

Source paragraph: 3.6.7 MIL-PRF-38807

Content Model: `(ipbpl0+, ipbuseoncodelist?) +(tfndisplay | note)`

Used in Elements: `ipbplgrp`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl0tblfoot

Parts list table footnote

Description: This is a placeholder for the FOSI generated "Not Illustrated" footnote.

Source paragraph: 3.6.7 MIL-PRF-38807

Content Model: `EMPTY`

Used in Elements: `ipbplgrp`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl1

Parts List - Indenture 1

Description: Idents the first indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl2*)`

Used in Elements: `ipbpl0`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl2

Parts List - Indenture 2

Description: Idents the second indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl3*)`

Used in Elements: `ipbpl1`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl3

Parts List - Indenture 3

Description: Idents the third indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl4*)`

Used in Elements: `ipbpl2`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.

indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl4

Parts List - Indenture 4

Description: Idents the fourth indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl5*)`

Used in Elements: `ipbpl3`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl5

Parts List - Indenture 5

Description: Idents the fifth indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl6*)`

Used in Elements: `ipbpl4`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.

label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl6

Parts List - Indenture 6

Description: Idents the sixth indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+, ipbpl7*)`

Used in Elements: `ipbpl5`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.
kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.

quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbpl7

Parts List - Indenture 7

Description: Idents the seventh indenture in the description column of the MPL.

Source paragraph: 3.6.7.4.1 MIL-PRF-38807

Content Model: `((ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+)`

Used in Elements: `ipbpl6`

Entities used in this element: mpl, bodyatts, and mplatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
sepmanual	**NUMBER**	**0**	Defines whether the mpl table is a separate manual from 38784 or is combined as part of 38784.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
shown	**NUMBER**	**0**	Displays a dash in the figure/index column when attribute is set to 0 and 'Not Illustrated' appears at the bottom of the mpl.
attachpart	**NUMBER**	**0**	Displays '(AP)' following the desc when attachpart is set to 1.
marking	**NUMBER**	**0**	Toggle switch to indicate whether the part is marked.

kit	**NUMBER**	**0**	Displays '(Repair kits available)' following the desc when kit is set to 1.
quickchgexpl	**NUMBER**	**0**	Displays '(QCU available)' following the description when an item is supported by QCU.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbplbrk

Parts List Break

Description: Tag used to put a break in the MPL

Source paragraph: MIL-PRF-38807

Content Model: `EMPTY`

Used in Elements: `Globally included in ipbpl`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbplgrp

Parts List Group

Description: Container tag for the parts list.

Source paragraph: MIL-PRF-38807

Content Model: `(figure, ipbpl0tbl, ipbuseoncodelist?, ipbpl0tblfoot?) -(note)`

Used in Elements: `ipbpl`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbquickchgexpl

Quick Change Explanation

Description: Identifies the parts in kits or quick change units paragraph in the ipbforeword.

Source paragraph: 3.5.5 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbrefdes

Reference Designator

Description: Identifies the first column of the Reference Designator Index.

Source paragraph: 3.6.7.4, 3.8.2.1 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbrfdsgrp` and `ipbrfdsgrprow`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbrfdsgrp

Reference Designator Group

Description: Container tag for the reference designator index.

Source paragraph: 3.8 MIL-PRF-38807

Content Model: `((ipbrfdsgrprow | (ipbrefdes?, ipbsssn?, ipbfigindex))+)`

Used in Elements: `ipbrfdsindx`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbrfdsgrprow

Reference Designator Group Row

Description: Container tag for the reference designator index. Added to allow the insertion/deletion of an entire row.

Source paragraph: 3.8 MIL-PRF-38807

Content Model: `(ipbrefdes?, ipbsssn?, ipbfigindex)`

Used in Elements: `ipbrfdsgrp`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbrfdsindx

Reference Designator Index

Description: Identifies the fourth section of the ipb chapter.

Source paragraph: 3.8.1 MIL-PRF-38807

Content Model: `(ipbrfdsgrp) -(note) +(ipbgroup10)`

Used in Elements: `ipbchap`

Entities used in this element: chapatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the reference designator index is autogenerated.
type	**(REFDES | SSSN | BOTH)**	**REFDES**	Defines whether the reference designator index includes the refdes element, the sssn element or both.
cols	**(2 | 3)**	**3**	Defines the number of columns for the reference designator index.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbserialization

Serialization

Description: Identifies the serialization paragraph in the ipb foreword.

Source paragraph: 3.5.2 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*, ipbsertable)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.

verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbserrow

Serialization Table Row

Description: Container element for the row of the serialization table. Element added to allow for the insertion/deletion of entire rows.

Source paragraph: 3.5.2 MIL-PRF-38807

Content Model: `(nomen, modelno, serno)`

Used in Elements: `ipbsertable`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsertable

Serialization Table

Description: Identifies the serialization table in the ipb foreword.

Source paragraph: 3.5.2 MIL-PRF-38807

Content Model: `(title?, (ipbserrow | (nomen, modelno, serno))+)`

Used in Elements: `ipbserialization`

Entities used in this element: xtabatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
col1width	**CDATA**	**1.75IN**	Specifies the value for the first column width
col2width	**CDATA**	**1.25IN**	Specifies the value for the second column width
tabstyle	**NMTOKEN**	**#IMPLIED**	Describes the type of table.
frame	**(TOP | BOTTOM | TOPBOT | ALL | SIDES | NONE)**	**ALL**	Defines the frame for the table.
colsep	**NUMBER**	**1**	Allows you to include a vertical line to seperate columns. A value of "1" for this attribute will generate column separators.
rowsep	**NUMBER**	**0**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
orient	**(PORT | LAND1)**	**PORT**	Defines orientation of table on the page.
pgwide	**NUMBER**	**1**	Defines whether the figure will fill the entire width of the page.
cellcont	**(CONTINUED | CONT)**	**CONTINUED**	Specifies whether cell contents can be continued.
id	**ID**	**#IMPLIED**	Provides means to specify an ID number for the table.
footnotes	**(PAGE | END)**	**#IMPLIED**	Allows you to specify whether table footnotes appear at the end of the table or at the end of the page.
applicref	**IDREFS**	**#IMPLIED**	Specifies all IDs of elements or data items that have an applicable reference.

leftind	**CDATA**	**#IMPLIED**	Specifies left indent of the table in relationship to the page.
rightind	**CDATA**	**#IMPLIED**	Specifies right indent of the table in relationship to the page.
leftmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
rightmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
topmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
botmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
mindepth	**NUTOKEN**	**#IMPLIED**	Specifies the minimum depth of the table.
pgdeep	**NUMBER**	**0**	Allows you to specify whether that table is equal to the depth of the page.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

ipbshtnoexpl

Sheet Number Explanation

Description: Identifies the sheet number explanation in the ipb foreword.

Source paragraph: 3.5.7 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.

indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsimassem

Similar Assemblies

Description: Identifies the listing of similar assemblies in the ipb foreword.

Source paragraph: 3.5.4 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0atts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.

ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsmrcode

Source, Maintenance, and Recoverability (SMR) Codes

Description: Identifies the SMR codes in the MPL.

Source paragraph: 3.6.7.7 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |`

ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: `ipbsmrcodes`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsmrcodes

Source, Maintenance, and Recoverability (SMR) Codes

Description: Container element for the SMR codes.

Source paragraph: 3.6.7.7 MIL-PRF-38807

Content Model: `(ipbsmrcode)+`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsmrexpl

Source, Maintenance, and Recoverability (SMR) code explanation.

Description: Identifies the SMR codes in the ipb foreword.

Source paragraph: 3.5.9 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.

caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbsssn

System, Subsystem, Sub-Subsystem Number

Description: Identifies the SSSN in the reference designator index.

Source paragraph: 3.6.7.4 & 3.8.2.1 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbdesc, ipbrfdsgrp, and ipbrfdsgrprow`

Entities used in this element: text, secur, yesorno; and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
showinftn	**NUMBER**	**0**	Identifies if the SSSN should be shown in the page footnote.
hidesssn	**NUMBER**	**0**	Identifies if the SSSN show be shown.

ipbunits

Units

Description: Identifies the units per assembly column in the MPL

Source paragraph: 3.6.7.5 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbuseoncode

Usable on code

Description: Identifies the useable on code column in the MPL.

Source paragraph: 3.6.7.6 MIL-PRF-38807

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, and ipbpl7`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbuseoncodelist

Usable on code list

Description: Identifies the usable on code list at the end of the MPL.

Source paragraph: 3.6.7.6 MIL-PRF-38807

Content Model: `(term, def)+ +(note)`

Used in Elements: `ipbpl0tbl and ipbplgrp`

Entities used in this element: bodyatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ipbuseonexpl

Usable on code explanation

Description: Identifies the useable on code paragraphs in the ipb foreword

Source paragraph: 3.5.8 MIL-PRF-38807

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `ipbfwordchap`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.

hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

item

Item

Description: Identifies an item within a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `randlist` and `seqlist`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

label

Label

Description: Identifies the label for a manually tagged table of contents entry.

Source paragraph: 4.5.6

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `cntentry`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

legend

Legend

Description: A tabular listing of the index numbers/letters and their meanings.

Source paragraph: 4.6.17

Content Model: `(tabmat)`

Used in Elements: `figure, foldout, subfig, and subfigfo`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

lep

List of Effective Pages (LEP)

Description: Identifies the list of effective pages for the manual.

Source paragraph: 4.5.3

Content Model: `(lepcontents) -(note)`

Used in Elements: `front and auxfront`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
lepcount	**NUMBER**	**0**	Identifies the number of pages in the manual for a manually tagged LEP

lepchg

LEP Change

Description: Identifies the change number for a page for a manually tagged LEP.

Source paragraph: 4.5.3.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `lepentry`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

lepcontents

LEP Contents

Description: Contains the entries for the lep. The fosi can automatically generate this.

Source paragraph: 4.5.3

Content Model: `(lepentry+)`

Used in Elements: `lep`

Entities used in this element: lepcontents

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the lep is autogenerated.

lepentry

LEP Entry

Description: An entry for a manually tagged LEP

Source paragraph: 4.5.3

Content Model: `(leppage, lepchg)`

Used in Elements: `lepcontents`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

leppage

LEP Page

Description: Identifies the page numbers for a manually tagged LEP entry.

Source paragraph: 4.5.3

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |`

ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: lepentry

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

letter

Letter

Description: Letter heading for the index and glossary

Source paragraph: 4.2.9.8

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: glossary, glosslist, glossrow, index, and indexrow

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

line

Line

Description: This element is used to indicate that a column or line should be forced at that point.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `Globally included in doc`

Entities used in this element: text, lineatt, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
prespace	**CDATA**	**#IMPLIED**	Allows the author to set amount of space before/above the line used.
postspace	**CDATA**	**#IMPLIED**	Allows the authour to set amount of space after/below the line used.
quad	**(LEFT | CENTER | RIGHT | JUSTIFY)**	**LEFT**	Specifies quadding option for the line.
indent	**CDATA**	**#IMPLIED**	Specifies how much indentation is set on the line.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

location

Location (Not Used; Under Review)

Description: Identifies the placement of a floating object such as a figure, table or figure table. This element is globally included on the document element.

Source paragraph: None.

Content Model: `EMPTY`

Used in Elements: `Globally included in doc`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	**IDREF**	**#REQUIRED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

lrp

List of Related Publications

Description: Identifies the paragraph used to list related publications and the associated list.

Source paragraph: 4.5.9.2

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, lrptable?)`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: lrp and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
ltermwidth	**NUTOKEN**	**1.63IN**	Allows you to define the left term width.
rtermwidth	**NUTOKEN**	**1.9IN**	Allows you to set the right term width.
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.

esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

lrpentry

List of Related Publications Entry

Description: Identifies an entry in the list of related publications. When the value of the id attribute is specified via the xrefid attribute of the extref element, the title of the publication appears. Please note: According to spec, only the tmidno and title elements may be used for the lrp. The partno, modelno, and typedes elements were left in only for backwards compatability and possible future expansion.

Source paragraph: 4.5.9.2

Content Model: `((partno | (modelno | typedes))*, tmidno+, title)`

Used in Elements: `lrptable`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

lrptable

List of Related Publications Table

Description: Container element for the list of related publications table.

Source paragraph: 4.5.9.2

Content Model: `(lrpentry+)`

Used in Elements: `lrp`

Entities used in this element: bodyatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

maintlvl

Maintenance Level

Description: Identifies the maintenance level of the manual (e.g. organizational, intermediate, depot, etc.) on the title page.

Source paragraph: 4.5.1.3.3

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mfr

Manufacturer

Description: Identifies the manufacturer of the equipment on the title page.

Source paragraph: 4.5.1.3.6

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

modelno

Model Number

Description: Identifies the model number of the equipment on the title page or difference data sheet.

Source paragraph: 4.7.3.3.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ddsheet, ipbserrow, ipbsertable, and prtitle`

Entities used in this element: text, exclus, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

modreq

Modification Request (Not Used; Under Review)

Description: The modification request element identifies a marking which document editors may place into the document instance to indicate where modification should be made. The element is used only in the review process and will not be used during document composition.

Source paragraph: 4.5.1.3.4, 4.7.3.3

Content Model: `(mrinfo?, mrmod, mrrespns?)`

Used in Elements: `Globally included in doc`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
xrefid	**NMTOKEN**	**#REQUIRED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
refpos	**(PREXREF | POSTXREF | XREF)**	**XREF**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
by	**CDATA**	**#REQUIRED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
date	**CDATA**	**#REQUIRED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.

organiz	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
orgcat	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
cmntrcat	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
priority	**(1|2|3|4|5)**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
category	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
topic	**CDATA**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

moveddata

Moved Data

Description: Provides a means to identify the type of information that will appear on the T-2 page when the title page overflows.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrchgtxt

Modification Request Change Text (Not Used; Under Review)

Description: Identifies the modification request change text used to indicate editorial changes during document production. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `ANY`

Used in Elements: `mrmod`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
chgloc	**NUMBER**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
chglen	**NUMBER**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
action	**(INSERT | DELETE | REPLACE)**	**REPLACE**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.

mrgenmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mrpara | mrlist)+`

Used in Elements: `mrmod`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrinfo

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `Any`

Used in Elements: `modreq`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrinstr

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mrpara | mrlist)+`

Used in Elements: `mrmod`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mritem

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `mrlist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrlist

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mritem+)`

Used in Elements: `mrgenmod, mrinstr, mrreason, and mrrespns`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrmod

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mrreason?, (mrgenmod | (mrinstr?, mrchgtxt)))`

Used in Elements: `modreq`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrpara

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `mrgenmod, mrinstr, mrreason,` and `mrrespns`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrreason

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mrpara | mrlist)+`

Used in Elements: `mrmod`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

mrrespns

(Not Used; Under Review)

Description: This element is part of the electronic review process. Further information on this element will be provided as the documentation matures. The element is used only in the review process and will not be used during document composition.

Source paragraph: None.

Content Model: `(mrpara | mrlist)*`

Used in Elements: `modreq`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
disposn	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.
status	**NMTOKEN**	**#IMPLIED**	Attribute is used to specify information about the modification request. This attribute is not supported by the FOSI at this time. The element is under review.

nameloc

Name Location - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a locator for external references and contains several nmlist elements. Useful for referncing objects that do not have the traditional SGML id.

Source paragraph: None.

Content Model: `(nmlist)*`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
HyBase	**NAME #FIXED**	**NAMELOC**	Assigns nameloc as the HyBase attribute.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

nmlist

Name List - HyTime Element

Description: One of several elements added to facilitate use of HyTime. This element serves as a description of the location of the entity or element reference in the nameloc element. Useful for referncing objects that do not have the traditional SGML id and/or entities that reside in external documents.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `nameloc`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
HyBase	**NAME #FIXED**	**NMSPLOC**	Used in conjunction with HyTime to set up independent and contextual links.
impsrc	**NAME #FIXED**	**GROVERT**	Used in conjunction with HyTime to set up independent and contextual links.
HyBnames	**CDATA #FIXED**	**LOCSRC DOCORSUBNAMESPC NAMETYPE#MAPTOKEN ELEMENTS ELEMENT#MAPTOKEN ENTITIES ENTITY**	Used in conjunction with HyTime to set up independent and contextual links.
nametype	**(ENTITY | ELEMENT)**	**ENTITY**	Identifies whether the external reference is an element or entity.
docorsub	**ENTITY**	**#IMPLIED**	Defines the entity name of the external document as declared in the entity declarations at the top of the tagged instance. Other attributes are not included because at this time - they are not applicable during a period of alpha test and will be added to the TDT as the options are explored and implement.
notspace	**NAME**	**ERROR**	Used in conjunction with HyTime to set up independent and contextual links.
notname	**NAME**	**ERROR**	Used in conjunction with HyTime to set up independent and contextual links.
notprop	**NAME**	**ERROR**	Used in conjunction with HyTime to set up independent and contextual links.
direct	**(DIRECT | INDIRECT)**	**INDIRECT**	Used in conjunction with HyTime to set up independent and contextual links.

locsrc	**CDATA**	**#IMPLIED**	Used in conjunction with HyTime to set up independent and contextual links.
cantcnst	**NAME**	**ERROR**	Used in conjunction with HyTime to set up independent and contextual links.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

nomen

Nomenclature

Description: Identifies the nomenclature of the equipment on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ddsheet, ipbdesc, ipbserrow, ipbsertable, and prtitle`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

none

None

Description: Allows you to opt for none instead of having the tpdrtbl.

Source paragraph: None.

Content Model: `EMPTY`

Used in Elements: `tpdr`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

note

Note

Description: Identifies a NOTE in the manual.

Source paragraph: 4.3.10

Content Model: `(para*) -(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution)`

Used in Elements: `Allowed anywhere except: lep, contents, illuslist, volillustlist, table-list, voltablelist, ipbnumindex, ipbrfdsindx, glossary, foldoutsect, title, index`

Entities used in this element: list, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

nsn

National Stock Number

Description: Identifies the national stock number of the equipment on the title page.

Source paragraph: 4.5.1.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `prtitle`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

nsp

Nuclear Surety Procedures

Description: Identifies the nsp symbol. Use of this element will cause the nsp symbol to appear at that point in the running text. The nsp attribute should be used to place the nsp symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.2

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

oadr

Official Authority Downgrade Review Notice

Description: Identifies the official authority downgrade review notice on the title page. This notice is used only on classified manuals.

Source paragraph: 4.4 & 4.5.1.10

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `downgrd`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

object

Multimedia Object

Description: Developed for use in interactive manuals to evoke multimedia applications.

Source paragraph: None.

Content Model: `(param*)`

Used in Elements: `objmedia, subobjmed, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: secur and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
objectno	**ENTITY**	**#REQUIRED**	References the object number of the application being referenced.
reprowid	**NUTOKEN**	**#IMPLIED**	Provides width of object being invoked, especially if graphic or foldout from external document.
reprodep	**NUTOKEN**	**#IMPLIED**	Provides depth of object being invoked, especially if graphic or foldout from external document.
type	**CDATA**	**#IMPLIED**	Provides details about the type of applications being referenced.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

objmedia

Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph: None.

Content Model: `(title, ((subobjmed, subobjmed+) | object)) -(figure | table | foldout | objmedia)`

Used in Elements: `Globally included in appendix, chapter, and ddchapter`

Entities used in this element: exclus, yesorno, bodyatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.

oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

oci

Observable Critical Item

Description: Identifies the OCI symbol. Use of this element will cause the OCI symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCI symbol in a paragraph. The oci attribute should be used to place the OCI symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.6

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ocp

Observable Critical Process

Description: Identifies the OCP symbol. Use of this element will cause the OCP symbol to appear at that point in the running text. This element should only be used in running text, e.g. to define the OCP symbol in a paragraph. The ocp attribute should be used to place the OCP symbol between a paragraph/step number and text.

Source paragraph: 4.3.10.6

Content Model: `EMPTY`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot,` and `volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type

inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

pageno

Page Number

Description: Identifies the page number associated with each table/figure that appears in the tablelist or illuslist when the list is manually tagged.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `cntentry, ddlist, illlistrow, illuslist, tablelist, tbllistrow, volillustlist, and voltablelist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

para

Paragraph

Description: Identifies text within a paragraph without regard to title, heading, etc. For example, a NOTE consists of a heading and one or more paragraphs.

Source paragraph: 4.2.9.5

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist)+`

Used in Elements: `parazero, abbrsect, applicdef, caution, dddesc, ddindex, ipbesdsdesc, ipbfinding, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbshtnoexpl, ipbsimassem, ipbsmrexpl, ipbuseonexpl, lrp, note, para0, ratddesc, step1, step2, step3, step4, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, subpara8, symsect, tctolist, tmimprep, warning,` and `wpgentry`

Entities used in this element: paracon, chgatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
xrefid	**IDREF**	**#IMPLIED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

para0

Primary Paragraph

Description: Identifies a primary paragraph within the manual.

Source paragraph: 4.2.9.5.1.1

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*) +(note)`

Used in Elements: `appendix, chapter, ddsheet, foreword, intro, ipbfwordchap, preface, safesum, section`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

param

Parameter

Description: Used with Object Media to provide textual information about the application being invoked.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `object`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

partno

Part Number

Description: Identifies the part number of the equipment on the title page and on the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1b

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ddlist, ddsheet, ipbnumgrp, ipbnumgrprow, ipbpl0, ipbpl1, ipbpl2, ipbpl3, ipbpl4, ipbpl5, ipbpl6, ipbpl7, prtitle, and pslist`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

pgbrk

Page Break

Description: Identifies where a page will begin. Page breaks can be placed at the top of each logical page to identify where the page should start.

Source paragraph: 4.2.1.1

Content Model: `EMPTY`

Used in Elements: `Globally included in doc`

Entities used in this element: yesorno and status

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

pgnum	**CDATA**	**#IMPLIED**	Page number generated by the FOSI during a recomposition. Provides data for OmniMark and DataLogics Composer in the script and change package processing.
pgnumber	**CDATA**	**#IMPLIED**	Allows the author to assign the pgnumber.
pgdesc	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgnum	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
nxtpgdesc	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
seqnum	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prefix	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
paraflag	**NUMBER**	**0**	Toggle whether or not last para will split.
hyphflag	**NUMBER**	**#IMPLIED**	Toggle whether or not hyphen will be used fo rthe last word on the last line.
shrink	**NUMBER**	**100**	Used to shrink vertical space so that overflowed text will pull back to the desired page.
rectover	**NUMBER**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chglevel	**CDATA**	**#IMPLIED**	Specifies what level of change the manual is on.
security	**(U | C | S | N)**	**N**	Identifies security level of the document
empty	**NUMBER**	**0**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
ignore	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
chgstatus	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
prevchgstatus	**CDATA**	**#IMPLIED**	Attribute is generated and referenced by the JCALS structure and is incorporated into the instance by the JCALS import process.
emergency	**(0 | 1)**	**#IMPLIED**	If emergency is equal to 1, it will output the emergency border to signify emergency procedures.
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Allows you to specify the status of this element.

phrase

Downgrade Phrase

Description: Identifies the text of the downgrade notice on the title page.

Source paragraph: 4.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `downgrd`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

preface

Preface

Description: Identifies the preface of the manual. This element is identical to the foreword and introduction elements, with the exception of the FOSI-generated title for that portion of the manual.

Source paragraph: 4.5.9

Content Model: `(para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*) +(figure | table)`

Used in Elements: `front` and `auxfront`

Entities used in this element: fpi and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

prentry

Primary Index Entry

Description: Used by author to identify primary entries that will be included in the index.

Source paragraph: 4.2.9.8

Content Model: `(topic) -(figure | table | foldout | objmedia)`

Used in Elements: `index and indexrow`

Entities used in this element: exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

pretmidno

Previous Technical Manual Identification Number (Not Used; Under Review)

Description: Identifies the previous technical manual identification number of the manual on the title page. This element is used only when the manual number has been changed. The FOSI will automatically generate the "Formerly" prefix preceding the former manual number.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text, service, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
service	**(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)**	**#IMPLIED**	Defines the branch of service.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

prindex

Primary Index

Description: Identifies a primary alphabetical index topic in the manual.

Source paragraph: 4.2.9.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(prindex)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright,`

dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum

Entities used in this element: text, yesorno, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pridnbr	**ID**	**#IMPLIED**	Defines a unique identification number that allows an association between items tagged as primary index topics and those tagged as secondary index topics.
display	**NUMBER**	**1**	Determines whether the contents of this element should appear in the text where tagged or just be referenced in the Index. '1' means display in text and index. '0' means display only in index.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

prtitle

Prime Title

Description: Identifies the title of the manual on the title page.

Source paragraph: 4.5.1.3e

Content Model: ((nomen, (modelno | partno | typedes | pslist | nsn)+, serno*) | subject)

Used in Elements: idinfo and chginssht

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

pslist

Part/Serial Number List

Description: Identifies a listing on the title page that corresponds a particular part number with associated serial numbers. This element could also be used to correspond model numbers with serial numbers, etc.

Source paragraph: 4.5.1.3.4

Content Model: `(partno, serno+)+`

Used in Elements: `prtitle`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

pubdate

Publication Date

Description: Identifies the basic date of the manual on the title page.

Source paragraph: 4.5.1.16

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

randlist

Random List

Description: Identifies a random list. All items within the random list will appear unnumbered, on separate lines, in the order they were entered by the author.

Source paragraph: None.

Content Model: `(title?, item+)`

Used in Elements: `entry, ftnote, and para`

Entities used in this element: chgatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
prefix	**CDATA**	**#IMPLIED**	If prefix is used, the bullets will not appear that are generally formatted by the fosi.

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

ratd

Record of Applicable Technical Directives

Description: Identifies the record of applicable technical directives paragraph and the associated table.

Source paragraph: 4.5.9.4

Content Model: `(ratdentry+)`

Used in Elements: `ratddesc`

Entities used in this element: bodyatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ratddesc

Record of Applicable Technical Directives Description

Description: Defines the description of the record of applicable technical directives paragraph and the associated table.

Source paragraph: 4.5.9.4

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, ratd?)`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.

hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

ratdentry

Record of Applicable Technical Directives Table Entry

Description: Defines each entry of the Record of Applicable Technical Directives Table.

Source paragraph: 4.5.9.4

Content Model: `(typeno, date?, title, ecpno?, dateinc?, remarks?)`

Used in Elements: `ratd`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

rear

Rear Matter

Description: Identifies the rear matter of the manual.

Source paragraph: 4.2.9.6, 4.2.9.7, 4.2.9.8, & 4.6

Content Model: `(appendix*, glossary?, index?, foldsect?)`

Used in Elements: `doc` and `volume`

Entities used in this element: rr and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numcols	**(1 | 2)**	**#REQUIRED**	Allows the author to define the page format as one or two columns for this section of the manual.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

remarks

Remarks Entry

Description: Identifies an entry in the remarks column of the record of applicable technical directives or a remark in the IPB parts list.

Source paragraph: 4.5.9.4e

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ipbdesc` and `ratdentry`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

removepg

Remove Page Column Entry

Description: Identifies an entry within the Remove Page column on the change instruction sheet.

Source paragraph: 4.7.3.10.2

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `chglist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

revnum

Revision Number

Description: Identifies the revision number of the manual on the title page.

Source paragraph: 4.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

row

Row

Description: Identifies a row in a table.

Source paragraph: 4.2.7

Content Model: `(entry | entrytbl)+`

Used in Elements: `tbody, tfoot, and thead`

Entities used in this element: yesorno, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
valign	**(TOP | BOTTOM | MIDDLE)**	**#IMPLIED**	Defines the vertical alignment for cell contents.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

safesum

Safety Summary

Description: Identifies the safety summary of the manual. The title is automatically generated by the FOSI. Please note that in a 5x8 Job Guide, a para0 shall be used for the safety summary in place of the safesum element.

Source paragraph: 4.5.10

Content Model: `(para0+) +(figure | table | warning | caution)`

Used in Elements: `front and auxfront`

Entities used in this element: safesum and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

seal

Seal

Description: Department of the Navy Seal, with command identifier.

Source paragraph: 4.5.1.5

Content Model: `EMPTY`

Used in Elements: `idinfo`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

secentry

Secondary Index Entry

Description: Used by author to tag data for inclusion in the index as a secondary topic

Source paragraph: 4.2.9.8

Content Model: `(topic) -(figure | table | foldout | objmedia)`

Used in Elements: `index and indexrow`

Entities used in this element: exclus and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

secindex

Secondary Index

Description: Identifies a secondary alphabetical index topic in the manual.

Source paragraph: 4.2.9.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(secindex)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno,`

`topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: text, yesorno, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
pridnbr	**IDREF**	**#REQUIRED**	References a pridnbr defined in the corresponding prindex
display	**NUMBER**	**1**	Determines whether the contents of this element should appear in the text where tagged or just be referenced in the Index. '1' means display in text and index. '0' means display only in index.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

section

Section

Description: Identifies a section of the manual, the next further breakdown of a chapter.

Source paragraph: 4.2.9.4

Content Model: `(title, para0+) +(note)`

Used in Elements: `chapter`

Entities used in this element: sect and sectatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

seqlist

Sequential List

Description: Identifies a sequential list. All items within the sequential list will appear numbered, on separate lines, in the order they were entered by the author.

Source paragraph: MIL-PRF-28001

Content Model: `(title?, item+)`

Used in Elements: `entry, ftnote, and para`

Entities used in this element: chgatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
numstyle	**(ALPHAUC | ALPHALC | ARABIC | ROMANUC | ROMANLC)**	**ARABIC**	Defines the type of enumeration on the sequential list.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

seqno

Sequence Number

Description: Defines the sequence number for a hazard warning.

Source paragraph: 4.3.10.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `icon`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

serno

Serial Number

Description: Identifies serial numbers of the equipment on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |`

ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)

Used in Elements: ipbserrow, ipbsertable, prtitle, and pslist

Entities used in this element: text, exclus, chgatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

sigblock

Signature Block

Description: Provides signature block.

Source paragraph: 4.7.3.10.2

Content Model: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: chginssht

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

spanspec

Span Specification

Description: Used to join two or more columns in a table. Span specifications are similar to column specifications (<colspec>) except that they describe areas of the table that can be spanned (joined) using a table entry (<entry>). For example, a three-column table may have columns named 1, 2, and 3 respectively. A span named 23 may be declared using spanspec. When spanname=23 is used on an entry, that entry would occupy the space in both columns 2 and 3.

Source paragraph: MIL-PRF-28001 8.4.5.3

Content Model: `EMPTY`

Used in Elements: `entrytbl, tfoot, tgroup, and thead`

Entities used in this element: yesorno and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
namest	**NMTOKED**	**#REQUIRED**	The name of the first column of the set of columns that you want to span.
nameend	**NMTOKEN**	**#REQUIRED**	The name of the last column of the set of columns that you want to span.
spanname	**NMTOKEN**	**#IMPLIED**	Defines a unique name for the span.
align	**(LEFT | RIGHT | CENTER | JUSTIFY | CHAR)**	**CENTER**	Allows the author to align text within the cell.
charoff	**NUTOKEN**	**#IMPLIED**	Determines the distance the cell content should offset from the horizontal alignment character.
char	**CDATA**	**#IMPLIED**	Defines the alignment character that can be used to align values within a column.
colsep	**NUMBER**	**#IMPLIED**	Allows you to include a vertical line to seperate columns. A value of "1" for this attribute will generate column separators.
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

step1

First Level Procedural Step

Description: Identifies a first level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: `(warning*, caution?, note?, para, note?, (step2, step2+)?)`

Used in Elements: `para0, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, and subpara8`

Entities used in this element: stepcon and stepatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.

applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.

step2

Second Level Procedural Step

Description: Identifies a second level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: `(warning*, caution?, note?, para, note?, (step3, step3+)?)`

Used in Elements: `step1`

Entities used in this element: stepcon and stepatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.

fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.

step3

Third Level Procedural Step

Description: Identifies a third level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: `(warning*, caution?, note?, para, note?, (step4, step4+)?)`

Used in Elements: `step2`

Entities used in this element: stepcon and stepatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.

step4

Fourth Level Procedural Step

Description: Identifies a fourth level procedural step.

Source paragraph: 4.2.9.5.3

Content Model: `(warning*, caution?, note?, para, note?)`

Used in Elements: `step3`

Entities used in this element: stepcon and stepatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.

subfig

Subfigure

Description: Identifies a subfigure. This element is used for multisheet illustrations, each sheet being a subfigure. The FOSI will automatically generate the sheet count (e.g Sheet 1 of 10, Sheet 2, etc.)

Source paragraph: 4.2.4.2

Content Model: `((graphic, legend?) | tabdisplay)`

Used in Elements: `figure` and `foldout`

Entities used in this element: chgatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
orient	**(PORT | LAND1)**	**PORT**	Defines the orientation of the figure.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

subfigfo

Subfigure Foldout

Description: Identifies a subfigure used on a foldout. This element allows the author to switch between foldouts and regular page sizes inside a figure.

Source paragraph: 4.2.4.2

Content Model: `((graphic, legend?) | tabdisplay)`

Used in Elements: `figure` and `foldout`

Entities used in this element: yesorno, chgatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
orient	**(PORT | LAND1)**	**PORT**	Defines the orientation of the figure.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
pgstyle	**(11X17 | 11X20.5 | 11X24 | 11X27.5 | 11X31 | 11X34.5 | 11X38 | 11X41.5 | 11X45)**	**#IMPLIED**	Defines the pagesize for the foldout
blankapron	**NUMBER**	**1**	Toggle to indicate whether the foldout includes a blank apron. A value of ’1’ indicates that the foldout will have a blank apron, a value of ’0’ indicates that the foldout will not have a blank apron.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

subject

Subject

Description: Identifies the prime title of the manual on the title page.

Source paragraph: 4.5.1.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `prtitle`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subjinfo

Subject Information (Not Used; Under Review)

Description: Identifies subject information that appears at the top of every column in a chapter. This first subjinfo tag in a chapter should be placed after the chapter tag or the first section tag (if used). Additional subjinfo tags have no restrictions on placement and should be used wherever the information changes.

Source paragraph: None.

Content Model: `EMPTY`

Used in Elements: `Globally included in doc`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
subjup	**CDATA**	**#REQUIRED**	Not currently supported by the FOSI. Element and attributes are under review.
subjlwr	**CDATA**	**#REQUIRED**	Not currently supported by the FOSI. Element and attributes are under review.
infoup	**CDATA**	**#REQUIRED**	Not currently supported by the FOSI. Element and attributes are under review.
infolwr	**CDATA**	**#REQUIRED**	Not currently supported by the FOSI. Element and attributes are under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subobjmed

Sub-Object Media

Description: Developed for use in interactive manuals to evoke multimedia applications. Defines details about the external application being invoked.

Source paragraph: None.

Content Model: `(object)`

Used in Elements: `objmedia`

Entities used in this element: chgatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

subpara1

First Subordinate Paragraph

Description: Identifies a first subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `(title, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara2*)`

Used in Elements: `abbrsect, applicdef, dddesc, ddindex, ipbesdsdesc, ipbfinding, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbshtnoexpl, ipbsimassem, ipbsmrexpl, ipbuseonexpl, lrp, para0, ratddesc, symsect, tctolist, and tmimprep`

Entities used in this element: nparcon and sub1att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.

esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara2

Second Subordinate Paragraph

Description: Identifies a second subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara3*)`

Used in Elements: `subpara1`

Entities used in this element: nparcon1 and sub2att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.

verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara3

Third Subordinate Paragraph

Description: Identifies a third subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara4*)`

Used in Elements: `subpara2`

Entities used in this element: nparcon1 and sub3att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.

esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara4

Fourth Subordinate Paragraph

Description: Identifies a fourth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara5*)`

Used in Elements: `subpara3`

Entities used in this element: nparcon1 and subatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.

verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
moretocspc	**(YES | NO)**	**0**	When this attribute is set to one, more space will occur between the subpara number and the subpara title in the TOC.

subpara5

Fifth Subordinate Paragraph

Description: Identifies a fifth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara6*)`

Used in Elements: `subpara4`

Entities used in this element: nparcon1 and subatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.

id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara6

Sixth Subordinate Paragraph

Description: Identifies a sixth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara7*)`

Used in Elements: `subpara5`

Entities used in this element: nparcon1 and subatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.

verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara7

Seventh Subordinate Paragraph

Description: Identifies a seventh subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?, subpara8*)`

Used in Elements: `subpara6`

Entities used in this element: nparcon1 and subatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.

id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subpara8

Eigth Subordinate Paragraph

Description: Identifies an eigth subordinate paragraph.

Source paragraph: 4.2.9.5.1.2

Content Model: `((title)?, warning*, caution?, note?, para, note?, (step1, step1+)?)`

Used in Elements: `subpara7`

Entities used in this element: nparcon1 and subatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.

verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

subtitle

Subtitle

Description: Identifies the subtitle of the manual on the title page.

Source paragraph: 4.5.1.3.5

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

supersed

Supersedure Notice

Description: Identifies the supersede notice on the title page.

Source paragraph: 4.5.1.6

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

suppl

Supplement Notice

Description: Identifies the supplement notice on the title page.

Source paragraph: 4.5.1.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

symrow

Symbol Row

Description: Identifies a term and def for the Symbol Section. Element added for the insertion/deletion of these elements together.

Source paragraph: 4.5.9 & 4.3.4

Content Model: `(term, def)`

Used in Elements: `symsect`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

symsect

Symbol Paragraph

Description: Identifies the paragraph used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, (symtitle?, (symrow | (term, def))+))`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: symsect and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
rtermwidth	**NUTOKEN**	**2.5IN**	Allows you to define the right term width
ltermwidth	**NUTOKEN**	**1IN**	Allows you to define the left term width
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.

fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

symtitle

Symbol Paragraph Title

Description: Identifies the title used to define symbols (e.g ESDS symbol) and the associated list.

Source paragraph: 4.5.9 & 4.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `symsect`

Entities used in this element: text, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tabdisplay

Table data displayed inside a figure.

Description: Identifies a table data contained within a figure.

Source paragraph:

Content Model: `(tgroup+) -(figure | table | foldout | objmedia) +(tfoot|tfnref|tfndisplay)`

Used in Elements: `figure, foldout, subfig, and subfigfo`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this paragraph manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
frame	**TOP | BOTTOM | TOPBOT | ALL | SIDES | NONE**	**ALL**	Defines the frame for the table.
colsep	**%YESORNO;**	**1**	Allows you to include a vertical line to seperate columns. A value of 1. for this attribute will generate column separators.
rowsep	**%YESORNO;**	**0**	Allows you to include a horizontal line to seperate rows. A value of 1. for this attribute will generate row separators.
tbwidth	**NUTOKEN**	**#IMPLIED**	
tbdepth	**NUTOKEN**	**#IMPLIED**	
horrefpt	**(LEFT | RIGHT)**	**LEFT**	Defines the horizontal reference point for the table.
verrefpt	**(VTOP | VBOTTOM)**	**VTOP**	Defines the vertical reference point for the table.
coordst	**CDATA**	**0,10000**	Ability to define the coordinates to start the table.
assocfig	**IDREF**	**#IMPLIED**	Provides a means to add the id to an associated figure.
deltype	**DELETE | REAL | RESERVE | NA**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**EMPTY | DELETED | RESERVED | NOTAPP**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to 1 to indicate a revision.

security	**(U | C | S | N) N**	Identifies security level of the document

table

Table

Description: Identifies a table.

Source paragraph: 4.2.7

Content Model: `(title, tgroup+) -(figure | table | foldout | objmedia) +(tfnref | tfoot | tfndisplay | tfnid)`

Used in Elements: `Globally included in appendix, chapter, ddchapter, foreword, intro, ipbfwordchap, preface, and safesum`

Entities used in this element: tabl, exclus, tabatts, and yesorno

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
tabstyle	**NMTOKEN**	**#IMPLIED**	Describes the type of table.
frame	**(TOP | BOTTOM | TOPBOT | ALL | SIDES | NONE)**	**ALL**	Defines the frame for the table.
colsep	**NUMBER**	**1**	Allows you to include a vertical line to seperate columns. A value of "1" for this attribute will generate column separators.
rowsep	**NUMBER**	**0**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
orient	**(PORT | LAND1)**	**PORT**	Defines orientation of table on the page.
pgwide	**NUMBER**	**1**	Defines whether the figure will fill the entire width of the page.
cellcont	**(CONTINUED | CONT)**	**CONTINUED**	Specifies whether cell contents can be continued.
id	**ID**	**#IMPLIED**	Provides means to specify an ID number for the table.
footnotes	**(PAGE | END)**	**#IMPLIED**	Allows you to specify whether table footnotes appear at the end of the table or at the end of the page.
applicref	**IDREFS**	**#IMPLIED**	Specifies all IDs of elements or data items that have an applicable reference.
leftind	**CDATA**	**#IMPLIED**	Specifies left indent of the table in relationship to the page.
rightind	**CDATA**	**#IMPLIED**	Specifies right indent of the table in relationship to the page.
leftmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
rightmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
topmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
botmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
mindepth	**NUTOKEN**	**#IMPLIED**	Specifies the minimum depth of the table.

pgdeep	**NUMBER**	**0**	Allows you to specify whether that table is equal to the depth of the page.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
continued	**NUMBER**	**0**	This attribute indicates whether the table is continued from the previous page. This tag was only added to allow for proper formatting of table footnotes. It is to be used in conjunction with the 38784 Table Footnotes script.

tablelist

List of Tables

Description: Identifies the list of tables in the manual. This information is automatically compiled by the FOSI. If this element is not used, no list of tables will appear in the manual.

Source paragraph: 4.5.8

Content Model: `(tbllistrow | (tabno, title, pageno))* -(note)`

Used in Elements: `front and auxfront`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1. when the Table of Contents is autogenerated.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

tabmat

Table Material

Description: Identifies tabular material that is to be displayed without the Table heading.

Source paragraph: 4.3.9

Content Model: `(tgroup+) -(figure | table | foldout | objmedia)`

Used in Elements: `chglist, legend, verstat, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: exclus and tabatts

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
tabstyle	**NMTOKEN**	**#IMPLIED**	Describes the type of table.

frame	**(TOP | BOT-TOM | TOPBOT | ALL | SIDES | NONE)**	**ALL**	Defines the frame for the table.
colsep	**NUMBER**	**1**	Allows you to include a vertical line to seperate columns. A value of "1" for this attribute will generate column separators.
rowsep	**NUMBER**	**0**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
orient	**(PORT | LAND1)**	**PORT**	Defines orientation of table on the page.
pgwide	**NUMBER**	**1**	Defines whether the figure will fill the entire width of the page.
cellcont	**(CONTINUED | CONT)**	**CONTINUED**	Specifies whether cell contents can be continued.
id	**ID**	**#IMPLIED**	Provides means to specify an ID number for the table.
footnotes	**(PAGE | END)**	**#IMPLIED**	Allows you to specify whether table footnotes appear at the end of the table or at the end of the page.
applicref	**IDREFS**	**#IMPLIED**	Specifies all IDs of elements or data items that have an applicable reference.
leftind	**CDATA**	**#IMPLIED**	Specifies left indent of the table in relationship to the page.
rightind	**CDATA**	**#IMPLIED**	Specifies right indent of the table in relationship to the page.
leftmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
rightmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
topmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
botmar	**NUTOKEN**	**#IMPLIED**	Specifies left margin of the table.
mindepth	**NUTOKEN**	**#IMPLIED**	Specifies the minimum depth of the table.
pgdeep	**NUMBER**	**0**	Allows you to specify whether that table is equal to the depth of the page.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will auto-matically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently sup-ported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

tabno

Table Number

Description: Identifies the Table number within the table list when the table list is manually tagged.

Source paragraph: None.

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `tablelist, tbllistrow, and voltablelist`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tbllistrow

Table List Row

Description: Identifies a row in the List of Tables. Element added to allow for the insertion/deletion of an entire row.

Source paragraph: 4.5.8

Content Model: `(tabno, title, pageno)`

Used in Elements: `tablelist` and `voltablelist`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tbody

Table Body

Description: Identifies the body of a table (e.g. material below the boxheads).

Source paragraph: 4.3.9

Content Model: `(row+)`

Used in Elements: `entrytbl,` and `tgroup`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
valign	**(TOP | MIDDLE | BOTTOM)**	**#IMPLIED**	Defines the vertical alignment of text within a cell.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tctolist

Time Compliance Technical Orders Paragraph

Description: Identifies the time compliance technical orders paragraph and the associated table.

Source paragraph: 4.5.9.3

Content Model: `((title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)?, tctotbl?)`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.

verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLI-CABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tctono

Time Compliance Technical Order Number

Description: Identifies an entry in the TCTO Number column in the TCTO table.

Source paragraph: 4.5.9.3

Content Model:

```
((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil
  | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |
  ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink |
  object)+) -(figure | table | foldout | objmedia)
```

Used in Elements: `tctorow`

Entities used in this element: text, exclus, chgatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

tctorow

Time Compliance Technical Orders Row

Description: Identifies a row in the time compliance technical orders table.

Source paragraph: 4.5.9.3

Content Model: `(tctono, title, date)`

Used in Elements: `tctotbl`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tctotbl

Time Compliance Technical Order Table

Description: Identifies the table that lists all TCTOs applicable to the manual. The FOSI will automatically generate the table title and the column headings (boxheads).

Source paragraph: 4.5.9.3

Content Model: `(tctorow+)`

Used in Elements: `tctolist`

Entities used in this element: bodyatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

term

Term

Description: Identifies an entry in the term portion of a list. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: 4.3.4

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `acronym, acronymlist, acronymlistrow, applic, applichd, defhd, deflist, glosslist, glossrow, ipbuseoncodelist, symrow, and symsect`

Entities used in this element: text, exclus, secur and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tfnid

Table Footnote Id

Description: This element is for placing a footnote in a 38784 table model. A superscript will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `tfoot. Globally included in table.`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
tfntype	**(NUM | ALPHA | SYM)**	**NUM**	Defines the type of symbol used to indicate a table footnote.
tfnsymbol	**CDATA**	**#IMPLIED**	Allows you to define the actual symbol to serve as a table footnote reference.
tfnval	**CDATA**	**#IMPLIED**	Defines the text value of the reference. The actual data to be generated at the bottom of the table should be placed with this attribute.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tfnref

Table Footnote Reference

Description: This element is for referencing a footnote in a 38784 table model that was created with a table footnote id. The superscript that was generated from the table footnote id will be placed at this point in the table and the footnote value will be placed at the bottom of the table if a table footnote display is created.

Source paragraph: 4.2.7.5

Content Model: `EMPTY`

Used in Elements: `Globally included in ipbcagecodes and table`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	**IDREF**	**#REQUIRED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tfndisplay

Table Footnote Display

Description: This element is for displaying footnotes in a 38784 table model. Footnotes to tables will be displayed at the end of the table. This element should be placed in a span in the last row of the table.

Source paragraph: 4.2.7.5

Content Model: `EMPTY`

Used in Elements: `Globally included in ipbpl0tbl and table`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tfoot

Table Foot

Description: The foot of the table.

Source paragraph: 4.2.7.5

Content Model: `((colspec*, spanspec*, row+) | tfnid+) -(entrytbl)`

Used in Elements: `tgroup. Globally included in ipbcagecodes and table.`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tgroup

Table Group

Description: Identifies a table group, which consists of a table heading (boxheads) and a table body.

Source paragraph: 4.2.7

Content Model: `(colspec*, spanspec*, (thead?, tfoot?, tbody))`

Used in Elements: `table` and `tabmat`

Entities used in this element: yesorno and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
cols	**NUMBER**	**#REQUIRED**	Defines the number of columns within the table.
colsep	**NUMBER**	**#IMPLIED**	Allows you to include a vertical line to seperate columns. A value of "1" for this attribute will generate column separators.
rowsep	**NUMBER**	**#IMPLIED**	Allows you to include a horizontal line to seperate rows. A value of "1" for this attribute will generate row separators.
align	**(LEFT | RIGHT | CENTER | JUSTIFY | CHAR)**	**LEFT**	Allows the author to align text within the cell.
leftind	**CDATA**	**#IMPLIED**	Defines the left indent of text within the cell.
rightind	**CDATA**	**#IMPLIED**	Defines a right indent of the text within the cell.
leftmar	**NUTOKEN**	**#IMPLIED**	Defines the left margin of the cell.
rightmar	**NUTOKEN**	**#IMPLIED**	Defines the right margin of the cell.
topmar	**NUTOKEN**	**#IMPLIED**	Defines the top margin of the cell.
botmar	**NUTOKEN**	**#IMPLIED**	Defines the bottom margin of the cell.

mindepth	**NUTOKEN**	**#IMPLIED**	Defines the minimum depth of the table.
charoff	**NUTOKEN**	**#IMPLIED**	Determines the distance the cell content should offset from the horizontal alignment character.
char	**CDATA**	**#IMPLIED**	Defines the alignment character that can be used to align values within a column.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

thead

Table Heading (Boxheads)

Description: Identifies a table heading (boxheads). The table heading (boxheads) repeat when the table breaks across a column or page.

Source paragraph: 4.2.7.3

Content Model: `(colspec*, spanspec*, row+) -(entrytbl)`

Used in Elements: `entrytbl` and `tgroup`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
valign	**(TOP | MIDDLE | BOTTOM)**	**#IMPLIED**	Defines the vertical alignment of text within a cell.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

title

Title

Description: Identifies a title (e.g. chapter, paragraph, table, etc.). The title should be tagged exactly as it is to appear in the table of contents. Titles that are placed on tables will appear in the List of Tables, and titles that are placed on figures and figure tables will be placed in the List of Illustrations. This element is included to allow the author flexibility in composing the manual in accordance with this spec.

Source paragraph: MIL-STD-38784

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia | note)`

Used in Elements: `abbrsect, appendix, applicdef, chapter, cntentry, dddesc, ddindex, def-list, figure, foldout, illlistrow, illuslist, ipbesdsdesc, ipbfinding, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbsertable, ipbshtnoexpl, ipbsimassem, ipbsmrexpl, ipbuseonexpl, lrp, lrpentry, objmedia, para0, randlist, ratddesc, ratdentry, section, seqlist, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, subpara8, symsect, table, tablelist, tb-llistrow, tctolist, tctorow, tmimprep, volilluslist, voltablelist, and wpgentry`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tmidno

Technical Manual Identification Number

Description: Identifies the technical manual identification number. When used on the title page (<idinfo>), it will cause the technical manual number to appear on the title page and at the top of each page in the manual. When used in the list of related publications (<lrp>), will cause the technical manual number to be placed in the Publication Number column.

Source paragraph: 4.2.1.5 & 4.5.9.2

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `idinfo` and `lrpentry`

Entities used in this element: chgatt, exclus, service, chgatt, and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
service	**(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)**	**#IMPLIED**	Defines the branch of service.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tmimprep

Technical Manual Improvement Report

Description: Identifies the technical manual improvement report paragraph.

Source paragraph: 4.5.9

Content Model: `(title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, sub-para1*)`

Used in Elements: `foreword, intro, and preface`

Entities used in this element: parazero and para0att

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
emergency	**NUMBER**	**0**	Indicates that the primary paragraph will produce an emergency border on the page when set equal to 1.
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
esds	**NUMBER**	**0**	Electrostatic Discharge Sensitive. All paragraphs which address handling or maintenance which could damage *** ESDS *** parts shall be identified by the esds symbol by setting attribute equal to 1.
nsp	**NUMBER**	**0**	Nuclear Surety Procedures. A **NSP** symbol will appear when set equal to 1.
fcp	**NUMBER**	**0**	Fracture Critical Process. All paragraphs which address Fracture Critical Process shall be identified by the *** FCP *** symbol by setting attribute equal to 1.
hcp	**NUMBER**	**0**	Hardness Critical Process. All paragraphs which address Hardness Critical Process shall be identified by the *** HCP *** symbol by setting attribute equal to 1.
hci	**NUMBER**	**0**	Hardness Critical Item. All paragraphs which address Hardness Critical Item shall be identified by the *** HCI *** symbol by setting attribute equal to 1.
ocp	**NUMBER**	**0**	Observable Critical Process. All paragraphs which address observable critical processes shall be identified by the *** OCP *** symbol by setting attribute equal to 1.
oci	**NUMBER**	**0**	Observable Critical Item. All paragraphs which address observable critical items shall be identified by the *** OCI *** symbol by setting attribute equal to 1.
applicref	**IDREFS**	**#REQUIRED**	Allows you to assign an applicability/effectivity reference to this element.
verdate	**CDATA**	**#IMPLIED**	Identifies the date the element was verified.
verrem	**CDATA**	**#IMPLIED**	Provides a place for the author to make remarks about the verification of the element.
verstatus	**(UNVER | VER | NOTAPPLICABLE)**	**UNVER**	Identifies verification status of the element.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.

indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

topic

Index topic

Description: Used by author to tag topics that will be appear in the index. Used as subelement for prentry and secentry.

Source paragraph: 4.2.9.8

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `prentry` and `secentry`

Entities used in this element: text, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
page	**CDATA**	**#IMPLIED**	Defines the page where the index topic occurs in the manual.
para	**CDATA**	**#IMPLIED**	Defines the paragraph where the index topic occurs in the manual. If this attribute is specified, the page attribute should be ignore.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.

revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tpdr

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: 4.5.9

Content Model: `(tpdrtbl | none)`

Used in Elements: `front` and `auxfront`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tpdrlocation

Technical Publications Deficiency Report Location

Description: Identifies an entry in the Location column of the technical publications deficiency report list.

Source paragraph: 4.5.9

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `tpdrrow` and `tpdrtbl`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description

deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tpdrno

Technical Publications Deficiency Report Number

Description: Identifies an entry in the Report Control Number column of the technical publications deficiency report list.

Source paragraph: 4.5.9

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `tpdrrow` and `tpdrtbl`

Entities used in this element: text, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tpdrrow

Technical Publications Deficiency Report Row

Description: Identifies a row in the techinical publications deficiency report list.

Source paragraph: 4.5.9

Content Model: `(activity, tpdrno, tpdrlocation)`

Used in Elements: `tpdrtbl`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

tpdrtbl

Technical Publications Deficiency Report

Description: Identifies the technical publications deficiency report list.

Source paragraph: 4.5.9

Content Model: `(tpdrrow | (activity, tpdrno, tpdrlocation))+`

Used in Elements: `tpdr`

Entities used in this element: bodyatt and secur

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
id	**ID**	**#IMPLIED**	Allows the author to generate a unique ID for use when referencing this entry.
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.

sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.

typedes

Type Designation

Description: Identifies a type designation on the title page and the difference data sheet.

Source paragraph: 4.5.1.3.4 & 4.7.3.3.1B

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ddsheet` and `prtitle`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

typeno

Directive Type and Number

Description: Identifies an entry in the Type/No column of the record of applicable technical directives table.

Source paragraph: 4.5.9.4a

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `ratdentry`

Entities used in this element: text, exclus, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

underline

Underline

Description: Allows for the underlining of the canned Export Control Notice

Source paragraph: 4.5.1.12

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+) -(figure | table | foldout | objmedia)`

Used in Elements: `expcont`

Entities used in this element: text and exclus

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

verbatim

Verbatim Text

Description: A verbatim element is used to format computer examples or similar text in a typewritten emulation mode. Formatting follows 'asis' quadding with monospaced font.

Source paragraph: MIL-PFR-28001C, B.3.14

Content Model: `(#PCDATA)`

Used in Elements: `abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigure-no, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuse-oncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, vol-leppage, volnot, and volnum`

Entities used in this element: yesorno, secur, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
allowbrk	**NUMBER**	**1**	Defines if a break can be inserted into verbatim text.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

verstat

Verification Status Page

Description: Identifies the verification status page in the manual. This information is automatically compiled by the FOSI. This element should not be used if a verification status page is not desired.

Source paragraph: 4.5.4

Content Model: `(tabmat?)`

Used in Elements: `front` and `auxfront`

Entities used in this element: yesorno and chgat

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the verstat page is autogenerated.
agency	**CDATA**	**#IMPLIED**	Identifies the TO Management Agency
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

volcontents

Volume Contents

Description: Identifies a volume contents.

Source paragraph: None.

Content Model: `((cntentry* | #PCDATA)*) -(note)`

Used in Elements: `front` and `auxfront`

Entities used in this element: cntnt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the Volume Contents is autogenerated.

volilluslist

Volume Illustration List

Description: Identifies a volume list of illustrations.

Source paragraph: 4.2.9.1

Content Model: `(illlistrow | (figno, title, pageno))* -(note)`

Used in Elements: `front` and `auxfront`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the Volume List of Illustrations is autogenerated.

vollep

Volume List of Effective Pages

Description: Identifies the volume List of Effective Pages.

Source paragraph: 4.2.9.1

Content Model: `(vollepcontents) -(note)`

Used in Elements: `front` and `auxfront`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
None.			

vollepchg

Volume LEP Change Number

Description: Volume Change Number for each entry in the VOLLEP.

Source paragraph: 4.5.3

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `vollepentry`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

vollepcontents

Volume Contents

Description: Identifies a volume contents.

Source paragraph: None.

Content Model: `(vollepentry+)`

Used in Elements: `vollep`

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the Volume LEP is autogenerated.
lepcount	**NUMBER**	**0**	Identifies the number of pages in the manual for a manually tagged Volume LEP

vollepentry

Volume LEP Entry

Description: LEP entry that should appear in the volume LEP.

Source paragraph: 4.5.3

Content Model: `(volleppage, vollepchg)`

Used in Elements: `vollepcontents`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

volleppage

Volume LEP Page Number

Description: Volume Page Number for each entry in the vollep.

Source paragraph: 4.5.3

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `vollepentry`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.

delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

volnot

Volume Notice

Description: Identifies the volume notice on the title page.

Source paragraph: 4.2.9.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)`

Used in Elements: `idinfo`

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

volnum

Volume Number

Description: Identifies the volume number on the title page.

Source paragraph: 4.2.9.1

Content Model: `((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci |`

ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+)

Used in Elements: idinfo

Entities used in this element: text and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

voltablelist

Volume Table List

Description: Identifies a volume list of tables.

Source paragraph: 4.2.9.1

Content Model: (tbllistrow | (tabno, title, pageno))* -(note)

Used in Elements: front and auxfront

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
autobuild	**CDATA**	**#CONREF**	This attribute should be set equal to 1 when the list is autogenerated.

volume

Volume

Description: Identifies a volume.

Source paragraph: 4.2.9.1

Content Model: ((front | auxfront), body, rear?)

Used in Elements: doc

Entities used in this element: bodyatt, secur, docatt, service, and yesorno

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
label	**CDATA**	**#IMPLIED**	Allows you to label this item manually. The fosi will automatically do this for you, so its use is not necessary unless a label out of the ordinary is desired.
sssn	**CDATA**	**#IMPLIED**	System, Subsystem, or Subject Number can be assiged to this element.
indexid	**ID**	**#IMPLIED**	Provides an index ID for this element. Not currently supported by the FOSI - this attribute is under review.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.
security	**(U | C | S | N)**	**N**	Identifies security level of the element.
caveat	**CDATA**	**#IMPLIED**	Provides a place to set the caveat for the document. This attribute should be ignored unless on the doc element.
fgi	**CDATA**	**#IMPLIED**	Provides a place for inline FMS portion marking.
docid	**CDATA**	**#IMPLIED**	Allows for the author to define an identification number for the document.
docstat	**(REVISION | CHANGE | PRELIM | DRAFT | FORMAL)**	**PRELIM**	Author can stipulate what form the manual is in.
verstatpg	**(VER | UNVER)**	**UNVER**	Author can stipulate a verified or unverified manual. Use of this attribute will trigger the generation of the verification status page and the temporary file - vsmatter.dat. See the accompanying readme.txt file for verification status for more detail.
index	**NUMBER**	**0**	Indicated whether an index is included in the manual. Attribute should be set to 1 when an index is present. Use of this attribute will affect the level of detail in the TOC
service	**(AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)**	**#REQUIRED**	Defines the branch of service.
volpages	**NUMBER**	**0**	Indicates whether the page numbers within the volume use the volume number prefix. "0" indicates standard page numbers. "1" indicates a volume prefix will be used.

resetnbars	**NUMBER**	**1**	Allows you to reset chapter numbers when continuing to a second or subsequent volume. "1" will reset chapter numbers back to 1. "0" will continue with the chapter numbers.

warning

Warning

Description: Identifies a WARNING in the manual. Multiple warning tags may be used only when it is desired to change the warning icon (standard or hazardous warning graphic).

Source paragraph: 4.3.10

Content Model: `(icon?, para*) -(randlist | deflist | seqlist | figure | table | foldout | objmedia | warning | caution)`

Used in Elements: `abbrsect, applicdef, dddesc, ddindex, entry, ipbesdsdesc, ipbfinding, ipbhcidesc, ipbmfrlist, ipbmodelcover, ipbpartstd, ipbquickchgexpl, ipbserialization, ipbshtnoexpl, ipbsimassem, ipbsmrexpl, ipbuseonexpl, lrp, para0, ratddesc, safesum, step1, step2, step3, step4, subpara1, subpara2, subpara3, subpara4, subpara5, subpara6, subpara7, subpara8, symsect, tctolist,` and `tmimprep`

Entities used in this element: list, exclus, and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

warnpage

Warning Page

Description: Identifies the warning page(s) of the manual.

Source paragraph: 4.5.2

Content Model: `(wpgentry+)`

Used in Elements: `front` and `auxfront`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

wpgentry

Warning Page Entry

Description: Identifies an individual warning on the warning page(s). The FOSI does not currently fully support this element.

Source paragraph: 4.5.2

Content Model: `(title, para+)`

Used in Elements: `warnpage`

Entities used in this element: yesorno and chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
warnbox	**NUMBER**	**#IMPLIED**	Allows you to specify the appearance and size of the warning box.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated
status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

titlefont	**(10PT | 14PT)**	**14PT**	Specifies the font size choices available for a warning page entry.
line	**NUMBER**	**#IMPLIED**	Specifies whether a line should appear between warning page entries.

xref

Cross-reference

Description: Identifies a cross-reference to a paragraph, figure, table, etc.

Source paragraph: 4.3.1

Content Model: `EMPTY`

Used in Elements: `bindByCoords, bindById, bindByName, abbrtitle, activity, address, applicabil, appltitle, authnot, change, chgdate, chgnum, chgpara, chgtxt, clink, cogact, contractno, copyright, dataiden, date, dateinc, def, destr, discl, distrib, doctype, ecpno, effdatenot, emphasis, entry, expcont, extapplicabil, figno, ftnote, hazmat, ilink, insertpg, internatlstd, ipbcage, ipbfigindex, ipbfigureno, ipbpartnosym, ipbrefdes, ipbsmrcode, ipbsssn, ipbunits, ipbuseoncode, item, label, lepchg, leppage, letter, line, maintlvl, mfr, modelno, moveddata, mritem, mrpara, nmlist, nomen, nsn, oadr, pageno, para, param, partno, phrase, pretmidno, prindex, pubdate, remarks, removepg, revnum, secindex, seqno, serno, sigblock, subject, subtitle, supersed, suppl, symtitle, tabno, tctono, term, tfnid, title, tmidno, topic, tpdrlocation, tpdrno, typedes, typeno, underline, vollepchg, volleppage, volnot, and volnum`

Entities used in this element: chgatt

ATTRIBUTE LIST

Only these attributes are applicable and supported by the fosi.

Attribute	Type	Default	Description
xrefid	**IDREF**	**#IMPLIED**	Defines the ID of the element that you are referencing. The value of this attribute should match the value of an ID attribute elsewhere in the manual.
displayvalue	**CDATA**	**#IMPLIED**	If the author needs to add additional, unique information for purposes of referencing an external document, this attribute should be tagged. This attribute should be used for providing paragraph titles, system numbers, task numbers and for author-generated TO numbers where applicable.
HyTime	**NAME #FIXED**	**CLINK**	Used in combination with HyTime to establish contextual link.
HyNames	**CDATA #FIXED**	**LINKEND XREFID**	Used in combination with HyTime to establish contextual link.
deltype	**(DELETE | REAL | RESERVE | NA)**	**#IMPLIED**	Used to generate change packages - Delete Type
inschlvl	**NMTOKEN**	**#IMPLIED**	Used during the change package process to indicate the element was inserted at the change level indicated.
delchlvl	**NMTOKEN**	**#IMPLIED**	Used during change package process to indicate the element was deleted at the change level indicated

status	**(EMPTY | DELETED | RESERVED | NOTAPP)**	**#IMPLIED**	Used during the change package process to indicate the current status of the element.
revchg	**NUMBER**	**0**	Toggle between a revision or a change. Attribute is set to "1" to indicate a revision.

% delstat

Unexpanded: delete | real | reserve | NA

Expanded: delete | real | reserve | NA

% status

Unexpanded: empty | deleted | reserved | notapp

Expanded: empty | deleted | reserved | notapp

% yesorno

Unexpanded: NUMBER

Expanded: NUMBER

% chgatt

Unexpanded:

```
deltype (%delstat;) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (%status;) #IMPLIED
revchg %yesorno; '0'
```

Expanded:

```
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
```

% cgmatts

Unexpanded:

```
id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
%chgatt;
```

Expanded:

```
id ID #IMPLIED
title CDATA #IMPLIED
descript CDATA #IMPLIED
visibility (visible | hidden) 'visible'
interactivity (interactive | none) 'none'
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'
```

% pubatts

Unexpanded:

controlno CDATA ’00000000’
cycle CDATA ’new’
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER ’1’
docno CDATA #IMPLIED
highguid NUMBER ’0’
labelstyle CDATA ’FAN’

Expanded:

controlno CDATA ’00000000’
cycle CDATA ’new’
chglevel NUMBER #IMPLIED
initlabel NUMBER #IMPLIED
initpage NUMBER ’1’
docno CDATA #IMPLIED
highguid NUMBER ’0’
labelstyle CDATA ’FAN’

% descatts

Unexpanded:

attachpart %yesorno; ’0’
kit %yesorno; ’0’
quickchgexpl %yesorno; ’0’
%chgatt;

Expanded:

attachpart %yesorno; ’0’
kit %yesorno; ’0’
quickchgexpl %yesorno; ’0’
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% secur

Unexpanded:

security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

Expanded:

security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% verified

Unexpanded:

verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’

Expanded:

verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) 'unver'

% docatt

Unexpanded:

docid CDATA #IMPLIED
docstat (revision | change | prelim | draft | formal) 'prelim'
verstatpg (ver | unver) 'unver'
index %yesorno; '0'

Expanded:

docid CDATA #IMPLIED
docstat (revision | change | prelim | draft | formal) 'prelim'
verstatpg (ver | unver) 'unver'
index NUMBER '0'

% bodyatt

Unexpanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
%chgatt;

Expanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% chapatt

Unexpanded:

id ID #IMPLIED
%secur;
%bodyatt;

Expanded:

id ID #IMPLIED
security (u | c | s | n) 'n'
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER '0'

% sectatt

Unexpanded: %chapatt;

Expanded:

id ID #IMPLIED
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% para0att

Unexpanded:

emergency %yesorno; ’0’
id ID #IMPLIED
esds %yesorno; ’0’
nsp %yesorno; ’0’
fcp %yesorno; ’0’
hcp %yesorno; ’0’
hci %yesorno; ’0’
ocp %yesorno; ’0’
oci %yesorno; ’0’
applicref IDREFS #IMPLIED
%verified;
%secur;
%bodyatt;

Expanded:

emergency NUMBER ’0’
id ID #IMPLIED
esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% sub1att

Unexpanded: %para0att;

Expanded:

emergency NUMBER ’0’
id ID #IMPLIED
esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% sub2att

Unexpanded: %para0att;

Expanded:

emergency NUMBER ’0’
id ID #IMPLIED
esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% sub3att

Unexpanded: %para0att;

Expanded:

emergency NUMBER ’0’
id ID #IMPLIED

esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% subatts

Unexpanded: %para0att;

Expanded:
emergency NUMBER ’0’
id ID #IMPLIED
esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% graphatt

Unexpanded:
id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED

reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit %yesorno; #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED
color %yesorno; ’0’
icon (yes|no) ’no’
%chgatt;

Expanded:

id ID #IMPLIED
boardno ENTITY #REQUIRED
graphsty NMTOKEN #IMPLIED
llcordra CDATA #IMPLIED
rucordra CDATA #IMPLIED
reprowid NUTOKEN #IMPLIED
reprodep NUTOKEN #IMPLIED
hscale NUMBER #IMPLIED
vscale NUMBER #IMPLIED
scalefit NUMBER #IMPLIED
hplace (left | right | center) #IMPLIED
vplace (top | middle | bottom) #IMPLIED
coordst CDATA #IMPLIED
coordend CDATA #IMPLIED
color NUMBER ’0’
icon (yes|no) ’no’
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% stepatt

Unexpanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
id ID #IMPLIED
esds %yesorno; ’0’
nsp %yesorno; ’0’
fcp %yesorno; ’0’
hcp %yesorno; ’0’
hci %yesorno; ’0’
ocp %yesorno; ’0’
oci %yesorno; ’0’
applicref IDREFS #IMPLIED
%chgatt;
%verified;

Expanded:

label CDATA #IMPLIED
sssn CDATA #IMPLIED
id ID #IMPLIED
esds NUMBER ’0’
nsp NUMBER ’0’
fcp NUMBER ’0’
hcp NUMBER ’0’
hci NUMBER ’0’
ocp NUMBER ’0’
oci NUMBER ’0’
applicref IDREFS #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED

inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’

% entryatt

Unexpanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER ’0’
colsep %yesorno; #IMPLIED
rowsep %yesorno; #IMPLIED
rotate %yesorno; ’0’
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
%chgatt;

Expanded:

colname NMTOKEN #IMPLIED
spanname NMTOKEN #IMPLIED
id ID #IMPLIED
morerows NUMBER ’0’
colsep NUMBER #IMPLIED
rowsep NUMBER #IMPLIED
rotate NUMBER ’0’
valign (top | middle | bottom) #IMPLIED
align (left | right | center | justify | char) #IMPLIED
charoff NUTOKEN #IMPLIED
char CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

% tabatts

Unexpanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) ’all’
colsep %yesorno; ’1’
rowsep %yesorno; ’0’
orient (port | land1) ’port’
pgwide %yesorno; ’1’
cellcont (Continued | Cont) ’Continued’
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep %yesorno; ’0’

applicref IDREFS #IMPLIED
%verified;
%bodyatt;
%secur;

Expanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) ’all’
colsep NUMBER ’1’
rowsep NUMBER ’0’
orient (port | land1) ’port’
pgwide NUMBER ’1’
cellcont (Continued | Cont) ’Continued’
id ID #IMPLIED
footnotes (page | end) #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep NUMBER ’0’
applicref IDREFS #IMPLIED
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% xtabatts

Unexpanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) ’all’
colsep %yesorno; ’1’
rowsep %yesorno; ’0’
orient (port | land1) ’port’
pgwide %yesorno; ’1’
cellcont (Continued | Cont) ’Continued’
id ID #IMPLIED
footnotes (page | end) #IMPLIED
applicref IDREFS #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep %yesorno; ’0’
%verified;
%bodyatt;
%secur;

Expanded:

tabstyle NMTOKEN #IMPLIED
frame (top | bottom | topbot | all | sides | none) ’all’
colsep NUMBER ’1’
rowsep NUMBER ’0’
orient (port | land1) ’port’
pgwide NUMBER ’1’
cellcont (Continued | Cont) ’Continued’
id ID #IMPLIED
footnotes (page | end) #IMPLIED
applicref IDREFS #IMPLIED
leftind CDATA #IMPLIED
rightind CDATA #IMPLIED
leftmar NUTOKEN #IMPLIED
rightmar NUTOKEN #IMPLIED
topmar NUTOKEN #IMPLIED
botmar NUTOKEN #IMPLIED
mindepth NUTOKEN #IMPLIED
pgdeep NUMBER ’0’
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’
security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% figatts

Unexpanded:

pgwide %yesorno; ’1’
orient (port | land | land2) ’port’
id ID #IMPLIED
applicref IDREFS #IMPLIED
legend %yesorno; ’0’
nxtpg %yesorno; ’0’
%verified;
%bodyatt;
%secur;

Expanded:

pgwide NUMBER ’1’
orient (port | land | land2) ’port’
id ID #IMPLIED
applicref IDREFS #IMPLIED
legend NUMBER ’0’
nxtpg NUMBER ’0’
verdate CDATA #IMPLIED
verrem CDATA #IMPLIED
verstatus (unver | ver | notapplicable) ’unver’
label CDATA #IMPLIED
sssn CDATA #IMPLIED
indexid CDATA #IMPLIED
deltype (delete | real | reserve | NA) #IMPLIED
inschlvl NMTOKEN #IMPLIED
delchlvl NMTOKEN #IMPLIED
status (empty | deleted | reserved | notapp) #IMPLIED
revchg NUMBER ’0’

security (u | c | s | n) ’n’
caveat CDATA #IMPLIED
fgi CDATA #IMPLIED

% mpl

Unexpanded: (ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuse-oncode?, ipbsmrcodes)+)+

Expanded: (ipbfigureno?, ipbfigindex, (partno, ipbpartnosym?, (ipbcagecodes | ipbcage), ipbdesc, ipbunits, ipbuseoncode?, ipbsmrcodes)+)+

% mplatts

Unexpanded:
sepmanual %yesorno; ’0’
id ID #IMPLIED
shown %yesorno; ’1’
attachpart %yesorno; ’0’
marking %yesorno; ’0’
kit %yesorno; ’0’
quickchgexpl %yesorno; ’0’

Expanded:
sepmanual NUMBER ’0’
id ID #IMPLIED
shown NUMBER ’1’
attachpart NUMBER ’0’
marking NUMBER ’0’
kit NUMBER ’0’
quickchgexpl NUMBER ’0’

% lineatt

Unexpanded:
quad (left | center | right | justify) left
indent CDATA #IMPLIED

Expanded:
quad (left | center | right | justify) left
indent CDATA #IMPLIED

% icon

Unexpanded: graphic+, hazmat+, seqno

Expanded: graphic+, hazmat+, seqno

% list

Unexpanded: randlist | deflist | seqlist

Expanded: randlist | deflist | seqlist

% text

Unexpanded: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

Expanded: (#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+

% frnt

Unexpanded: warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro), safesum?

Expanded: warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro), safesum?

% auxfrnt

Unexpanded: warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro)?, safesum?

Expanded: warnpage?, idinfo, chginssht?, (lep | vollep), verstat?, tpdr?, chgrec?, (contents | volcontents), (illuslist| volilluslist)?, (tablelist | voltablelist)?, (foreword | preface | intro)?, safesum?

% idinf

Unexpanded: tmidno+, (chgnum, chgdate)?, chghistory, pretmidno*, volnum?, revnum?, doctype, maintlvl?, prtitle, subtitle?, (mfr+, contractno+)?, seal?, supersed?, suppl*, effdatenot?, volnot?, discl?, distrib, expcont?, destr?, copyright*, cogact?, moveddata?, authnot, downgrd?, pubdate

Expanded: tmidno+, (chgnum, chgdate)?, chghistory, pretmidno*, volnum?, revnum?, doctype, maintlvl?, prtitle, subtitle?, (mfr+, contractno+)?, seal?, supersed?, suppl*, effdatenot?, volnot?, discl?, distrib, expcont?, destr?, copyright*, cogact?, moveddata?, authnot, downgrd?, pubdate

% fpi

Unexpanded: para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*

Expanded: para0, (para0 | applicdef | symsect | abbrsect | internatlstd | lrp | tctolist | ratddesc | tmimprep)*

% ddchap

Unexpanded: dddesc, (ddindex, ddsheet+)?

Expanded: dddesc, (ddindex, ddsheet+)?

% rr

Unexpanded: appendix*, glossary?, index?, foldsect?

Expanded: appendix*, glossary?, index?, foldsect?

% wcn

Unexpanded: warning*, caution?, note?

Expanded: warning*, caution?, note?

% cntnt

Unexpanded: (cntentry* | #PCDATA)*

Expanded: (cntentry* | #PCDATA)*

% lepcontents

Unexpanded: lepentry+

Expanded: lepentry+

% safesum

Unexpanded: para0+

Expanded: para0+

% append

Unexpanded: title, para0+

Expanded: title, para0+

% glossry

Unexpanded: (letter?, glosslist)+

Expanded: (letter?, glosslist)+

% fig

Unexpanded: title, (((subfig | subfigfo), (subfig | subfigfo)+) | ((graphic, legend?))+)

Expanded: title, (((subfig | subfigfo), (subfig | subfigfo)+) | ((graphic, legend?))+)

% tabl

Unexpanded: title, tgroup+

Expanded: title, tgroup+

% stepcon

Unexpanded: %wcn;, para, note?

Expanded: warning*, caution?, note?, para, note?

% bodyele

Unexpanded: chapter, chapter+, ipbchap?, ddchapter?

Expanded: chapter, chapter+, ipbchap?, ddchapter?

% service

Unexpanded: (AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

Expanded: (AF | NAVAIR | NAVSEA | SPAWARS | ARMY | MC | DLA | CG | DOD | FRN)

% paracon

Unexpanded: (%text; | %list;)+

Expanded: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist)+

% nparcon

Unexpanded: title, %wcn;, para, note?, (step1, step1+)?

Expanded: title, warning*, caution?, note?, para, note?, (step1, step1+)?

% nparcon1

Unexpanded: (title)?, %wcn;, para, note?, (step1, step1+)?

Expanded: (title)?, warning*, caution?, note?, para, note?, (step1, step1+)?

% parazero

Unexpanded: title, %wcn;, (para, note?)?, (step1, step1+)?

Expanded: title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?

% chap

Unexpanded: title, ((section, (note?, section)+) | para0+)

Expanded: title, ((section, (note?, section)+) | para0+)

% sect

Unexpanded: title, para0+

Expanded: title, para0+

% chgsht

Unexpanded: chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?

Expanded: chgnum, address, date, prtitle, effdatenot?, discl?, distrib, expcont?, destr?, chgpara+, chglist, sigblock?

% entry

Unexpanded: (%text; | %list; | warning | caution | note)+

Expanded: ((#PCDATA | change | tabmat | ftnref | xref | verbatim | emphasis | applicabil | extapplicabil | graphic | extref | dataiden | hcp | hci | esds | nsp | oci | ocp | fcp | acronym | prindex | secindex | nameloc | clink | ilink | object)+ | randlist | deflist | seqlist | warning | caution | note)+

% symsect

Unexpanded: (%parazero;, subpara1*)?, (symtitle?, (symrow | (term, def))+)

Expanded: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)?, (symtitle?, (symrow | (term, def))+)

% exclus

Unexpanded: figure | table | foldout | objmedia

Expanded: figure | table | foldout | objmedia

% inclus

Unexpanded: figure | table | foldout | objmedia

Expanded: figure | table | foldout | objmedia

% lrp

Unexpanded: (%parazero;, subpara1*)?, lrptable?

Expanded: (title, warning*, caution?, note?, (para, note?)?, (step1, step1+)?, subpara1*)?, lrptable?

% ipbforwd

Unexpanded: (para0+, ipbmodelcover, ipbserialization?, ipbfinding?, ipbsimassem?, ipbquickchgexpl?, ipbshtnoexpl?, ipbuseonexpl, ipbsmrexpl, ipbhcidesc?, ipbesdsdesc?, ipbpartstd, ipbmfrlist?, para0*)

Expanded: (para0+, ipbmodelcover, ipbserialization?, ipbfinding?, ipbsimassem?, ipbquickchgexpl?, ipbshtnoexpl?, ipbuse-onexpl, ipbsmrexpl, ipbhcidesc?, ipbesdsdesc?, ipbpartstd, ipbmfrlist?, para0*)

% doc

Unexpanded: (volume, volume+) | (front, body, rear?)

Expanded: (volume, volume+) | (front, body, rear?)

expcontnot

Unexpanded: This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline> <underline>seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

Expanded: This document contains technical data whose export is restricted by the Arms Export Control Act (Title 22, U.S.C. SEC 2751, <underline>et</underline> <underline>seq</underline>.) or the Export Administration Act of 1979, as amended, Title 50, U.S.C., App 2401 <underline>et</underline> <underline>seq</underline>. Violations of these export laws are subject to severe criminal penalties. Disseminate in accordance with provisions of DoD Directive 5230.25.

suppnotice

Unexpanded: A suitable reference to this supplement will be made on the title page of the basic publication.

Expanded: A suitable reference to this supplement will be made on the title page of the basic publication.