## TROUBLESHOOTING

The buzzer is too loud
or too quiet

Turn the potentiometer to adjust the volume.

## The RedBoard thinks one key is always pressed

Check your wiring. You may have GND and 5V backward if one or more buttons behave as though they're pressed all the time.

## The buttons are not working

First, make sure that the wiring is correct. It is easy to misalign a wire with a button leg. Second, make sure that you have declared your buttons as inputs and have enabled the internal pull-up resistors with INPUT\_PULLUP.

## You've completed Circuit 2B!

Continue to circuit 2C and learn how to build your own game using buttons and LEDs.

