CAMPURAN NUTRISI S1 GROW

Sparmanik 4.0 · HST 0 – 24 · EC 2100 · pH 5,8 – 6,3

1 HARI	5 HARI	10 HARI
ember A 5 L + ember B 5 L = 1 tangki · tuang semua	drum A 25 L + drum B 25 L = 5 tangki · BIASA	drum A 50 L + drum B 50 L = 10 tangki

Produk	1 hari ember 5 L	5 hari drum 25 L	10 hari drum 50 L
DRUM A · ORANYE			
YaraTera Calcinit	870 g	**4,35 kg**	8,7 kg
Krista K Plus	345 g	**1,725 kg**	3,45 kg
Berat cek A	**1,215 kg**	**6,075 kg**	**12,15 kg**
DRUM B · BIRU			
Krista MKP	220 g	**1,1 kg**	2,2 kg
Meroke MAG-S	570 g	**2,85 kg**	5,7 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
Berat cek B	**815 g**	**4,075 kg**	**8,15 kg**

CARA BUAT DRUM / EMBER

1. Isi air hangat setengah.
2. 1 produk → aduk sampai **bening** → produk berikutnya.
3. Penuhi sampai garis **5 / 25 / 50 L**. Tulis label: A/B · tahap · hari · tanggal.

CARA BUAT TANGKI 1.000 L

1. Air **900 L**.
2. **5 L A** → aduk → **5 L B** → aduk. (1 hari: tuang **seluruh** ember A, lalu ember B.)
3. **Tanpa SOP** di tahap ini
4. Penuhi 1.000 L → mixer 2 menit → cek EC + pH → foto ke Boyd → baru pompa nyala.

JANGAN ×

A + B dicampur · sendok sama untuk A dan B · SOP atau silika di drum · Boroni tanpa Boyd · **asam borat**

Di bawah 1 kg → **timbangan dapur** (1 g). Pakai drum dalam 2 minggu.

EC salah? Pompa JANGAN nyala → TELEPON BOYD

CAMPURAN NUTRISI S2 FLOWER

Sparmanik 4.0 · HST 25 – 41 · EC 2400 · pH 5,8 – 6,3

1 HARI	5 HARI	10 HARI
ember A 5 L + ember B 5 L = 1 tangki · tuang semua	drum A 25 L + drum B 25 L = 5 tangki · BIASA	drum A 50 L + drum B 50 L = 10 tangki

Produk	1 hari ember 5 L	5 hari drum 25 L	10 hari drum 50 L
DRUM A · ORANYE			
YaraTera Calcinit	945 g	**4,725 kg**	9,45 kg
Krista K Plus	115 g	**575 g**	1,15 kg
Karate Plus Boroni (kantong dari Boyd)	80 g	**400 g**	800 g
Berat cek A	**1,14 kg**	**5,7 kg**	**11,4 kg**
DRUM B · BIRU			
Krista MKP	230 g	**1,15 kg**	2,3 kg
Meroke MAG-S	605 g	**3,025 kg**	6,05 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
Berat cek B	**860 g**	**4,3 kg**	**8,6 kg**

CARA BUAT DRUM / EMBER

1. Isi air hangat setengah.
2. 1 produk → aduk sampai **bening** → produk berikutnya.
3. Penuhi sampai garis **5 / 25 / 50 L**. Tulis label: A/B · tahap · hari · tanggal.

CARA BUAT TANGKI 1.000 L

1. Air **900 L**.
2. **5 L A** → aduk → **5 L B** → aduk. (1 hari: tuang **seluruh** ember A, lalu ember B.)
3. SOP **310 g** setiap tangki (larutkan dulu di ember).
4. Penuhi 1.000 L → mixer 2 menit → cek EC + pH → foto ke Boyd → baru pompa nyala.

JANGAN ×

A + B dicampur · sendok sama untuk A dan B · SOP atau silika di drum · Boroni tanpa Boyd · **asam borat**
Di bawah 1 kg → **timbangan dapur** (1 g). Pakai drum dalam 2 minggu.

EC salah? Pompa JANGAN nyala → TELEPON BOYD

CAMPURAN NUTRISI S3 SIZING

Sparmanik 4.0 · HST 42 – 59 · EC 2550 · pH 5,8 – 6,3

1 HARI	5 HARI	10 HARI
ember A 5 L + ember B 5 L = 1 tangki · tuang semua	drum A 25 L + drum B 25 L = 5 tangki · BIASA	drum A 50 L + drum B 50 L = 10 tangki

Produk	1 hari ember 5 L	5 hari drum 25 L	10 hari drum 50 L
DRUM A · ORANYE			
YaraTera Calcinit	945 g	**4,725 kg**	9,45 kg
Berat cek A	**945 g**	**4,725 kg**	**9,45 kg**
DRUM B · BIRU			
Krista MKP	210 g	**1,05 kg**	2,1 kg
Meroke MAG-S	625 g	**3,125 kg**	6,25 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
Berat cek B	**860 g**	**4,3 kg**	**8,6 kg**

CARA BUAT DRUM / EMBER

1. Isi air hangat setengah.
2. 1 produk → aduk sampai **bening** → produk berikutnya.
3. Penuhi sampai garis **5 / 25 / 50 L**. Tulis label: A/B · tahap · hari · tanggal.

CARA BUAT TANGKI 1.000 L

1. Air **900 L**.
2. **5 L A** → aduk → **5 L B** → aduk. (1 hari: tuang **seluruh** ember A, lalu ember B.)
3. SOP **535 g** setiap tangki (larutkan dulu di ember).
4. Penuhi 1.000 L → mixer 2 menit → cek EC + pH → foto ke Boyd → baru pompa nyala.

JANGAN ×

A + B dicampur · sendok sama untuk A dan B · SOP atau silika di drum · Boroni tanpa Boyd · **asam borat**
Di bawah 1 kg → **timbangan dapur** (1 g). Pakai drum dalam 2 minggu.

EC salah? Pompa JANGAN nyala → TELEPON BOYD

CAMPURAN NUTRISI S4 RIPEN

Sparmanik 4.0 · HST 60 – panen · EC 2700 · pH 5,8 – 6,3

1 HARI	5 HARI	10 HARI
ember A 5 L + ember B 5 L = 1 tangki · tuang semua	drum A 25 L + drum B 25 L = 5 tangki · BIASA	drum A 50 L + drum B 50 L = 10 tangki

Produk	1 hari ember 5 L	5 hari drum 25 L	10 hari drum 50 L
DRUM A · ORANYE			
YaraTera Calcinit	895 g	**4,475 kg**	8,95 kg
Berat cek A	**895 g**	**4,475 kg**	**8,95 kg**
DRUM B · BIRU			
Krista MKP	185 g	**925 g**	1,85 kg
Meroke MAG-S	625 g	**3,125 kg**	6,25 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
Berat cek B	**835 g**	**4,175 kg**	**8,35 kg**

CARA BUAT DRUM / EMBER

1. Isi air hangat setengah.
2. 1 produk → aduk sampai **bening** → produk berikutnya.
3. Penuhi sampai garis **5 / 25 / 50 L**. Tulis label: A/B · tahap · hari · tanggal.

CARA BUAT TANGKI 1.000 L

1. Air **900 L**.
2. **5 L A** → aduk → **5 L B** → aduk. (1 hari: tuang **seluruh** ember A, lalu ember B.)
3. SOP **645 g** setiap tangki (larutkan dulu di ember).
4. Penuhi 1.000 L → mixer 2 menit → cek EC + pH → foto ke Boyd → baru pompa nyala.

JANGAN ×

A + B dicampur · sendok sama untuk A dan B · SOP atau silika di drum · Boroni tanpa Boyd · **asam borat**
Di bawah 1 kg → **timbangan dapur** (1 g). Pakai drum dalam 2 minggu.

EC salah? Pompa JANGAN nyala → TELEPON BOYD

NUTRIENT MIX S1 GROW

Sparmanik 4.0 · HST 0 – 24 · EC 2100 · pH 5.8 – 6.3

1 DAY	5 DAYS	10 DAYS
bucket A 5 L + bucket B 5 L = 1 tank · pour it all in	drum A 25 L + drum B 25 L = 5 tanks · NORMAL	drum A 50 L + drum B 50 L = 10 tanks

Product	1 day 5 L bucket	5 days 25 L drum	10 days 50 L drum
DRUM A · ORANGE			
YaraTera Calcinit	870 g	**4.35 kg**	8.7 kg
Krista K Plus	345 g	**1.725 kg**	3.45 kg
A check weight	**1.215 kg**	**6.075 kg**	**12.15 kg**
DRUM B · BLUE			
Krista MKP	220 g	**1.1 kg**	2.2 kg
Meroke MAG-S	570 g	**2.85 kg**	5.7 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
B check weight	**815 g**	**4.075 kg**	**8.15 kg**

MAKING THE DRUM / BUCKET

1. Half fill with warm water.
2. 1 product → stir until **clear** → next product.
3. Top up to the **5 / 25 / 50 L** line. Label: A/B · stage · days · date.

MAKING THE 1,000 L TANK

1. Water to **900 L**.
2. **5 L A** → stir → **5 L B** → stir. (1 day: pour the **whole** bucket A, then bucket B.)
3. **No SOP** this stage
4. Top up to 1,000 L → mixer 2 min → check EC + pH → photo to Boyd → then pump on.

NEVER ×

A + B mixed · same scoop for A and B · SOP or silica in a drum · Boroni without Boyd · **boric acid**
Under 1 kg → **kitchen scale** (1 g). Use a drum within 2 weeks.

Wrong EC? Pump stays OFF → CALL BOYD

NUTRIENT MIX S2 FLOWER

Sparmanik 4.0 · HST 25 – 41 · EC 2400 · pH 5.8 – 6.3

1 DAY	5 DAYS	10 DAYS
bucket A 5 L + bucket B 5 L = 1 tank · pour it all in	drum A 25 L + drum B 25 L = 5 tanks · NORMAL	drum A 50 L + drum B 50 L = 10 tanks

Product	1 day 5 L bucket	5 days 25 L drum	10 days 50 L drum
DRUM A · ORANGE			
YaraTera Calcinit	945 g	**4.725 kg**	9.45 kg
Krista K Plus	115 g	**575 g**	1.15 kg
Karate Plus Boroni (bag from Boyd)	80 g	**400 g**	800 g
A check weight	**1.14 kg**	**5.7 kg**	**11.4 kg**
DRUM B · BLUE			
Krista MKP	230 g	**1.15 kg**	2.3 kg
Meroke MAG-S	605 g	**3.025 kg**	6.05 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
B check weight	**860 g**	**4.3 kg**	**8.6 kg**

MAKING THE DRUM / BUCKET

1. Half fill with warm water.
2. 1 product → stir until **clear** → next product.
3. Top up to the **5 / 25 / 50 L** line. Label: A/B · stage · days · date.

MAKING THE 1,000 L TANK

1. Water to **900 L**.
2. **5 L A** → stir → **5 L B** → stir. (1 day: pour the **whole** bucket A, then bucket B.)
3. SOP **310 g** every tank (dissolve in a bucket first).
4. Top up to 1,000 L → mixer 2 min → check EC + pH → photo to Boyd → then pump on.

NEVER ×

A + B mixed · same scoop for A and B · SOP or silica in a drum · Boroni without Boyd · **boric acid**
Under 1 kg → **kitchen scale** (1 g). Use a drum within 2 weeks.

Wrong EC? Pump stays OFF → CALL BOYD

NUTRIENT MIX S3 SIZING

Sparmanik 4.0 · HST 42 – 59 · EC 2550 · pH 5.8 – 6.3

1 DAY	5 DAYS	10 DAYS
bucket A 5 L + bucket B 5 L = 1 tank · pour it all in	drum A 25 L + drum B 25 L = 5 tanks · NORMAL	drum A 50 L + drum B 50 L = 10 tanks

Product	1 day 5 L bucket	5 days 25 L drum	10 days 50 L drum
DRUM A · ORANGE			
YaraTera Calcinit	945 g	**4.725 kg**	9.45 kg
A check weight	**945 g**	**4.725 kg**	**9.45 kg**
DRUM B · BLUE			
Krista MKP	210 g	**1.05 kg**	2.1 kg
Meroke MAG-S	625 g	**3.125 kg**	6.25 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
B check weight	**860 g**	**4.3 kg**	**8.6 kg**

MAKING THE DRUM / BUCKET

1. Half fill with warm water.
2. 1 product → stir until **clear** → next product.
3. Top up to the **5 / 25 / 50 L** line. Label: A/B · stage · days · date.

MAKING THE 1,000 L TANK

1. Water to **900 L**.
2. **5 L A** → stir → **5 L B** → stir. (1 day: pour the **whole** bucket A, then bucket B.)
3. SOP **535 g** every tank (dissolve in a bucket first).
4. Top up to 1,000 L → mixer 2 min → check EC + pH → photo to Boyd → then pump on.

NEVER ×

A + B mixed · same scoop for A and B · SOP or silica in a drum · Boroni without Boyd · **boric acid**
Under 1 kg → **kitchen scale** (1 g). Use a drum within 2 weeks.

Wrong EC? Pump stays OFF → CALL BOYD

NUTRIENT MIX S4 RIPEN

Sparmanik 4.0 · HST 60 – harvest · EC 2700 · pH 5.8 – 6.3

1 DAY	5 DAYS	10 DAYS
bucket A 5 L + bucket B 5 L = 1 tank · pour it all in	drum A 25 L + drum B 25 L = 5 tanks · NORMAL	drum A 50 L + drum B 50 L = 10 tanks

Product	1 day 5 L bucket	5 days 25 L drum	10 days 50 L drum
DRUM A · ORANGE			
YaraTera Calcinit	895 g	**4.475 kg**	8.95 kg
A check weight	**895 g**	**4.475 kg**	**8.95 kg**
DRUM B · BLUE			
Krista MKP	185 g	**925 g**	1.85 kg
Meroke MAG-S	625 g	**3.125 kg**	6.25 kg
Meroke Vitaflex	20 g	**100 g**	200 g
MIKRO Fe 6% EDDHA	5 g	**25 g**	50 g
B check weight	**835 g**	**4.175 kg**	**8.35 kg**

MAKING THE DRUM / BUCKET

1. Half fill with warm water.
2. 1 product → stir until **clear** → next product.
3. Top up to the **5 / 25 / 50 L** line. Label: A/B · stage · days · date.

MAKING THE 1,000 L TANK

1. Water to **900 L**.
2. **5 L A** → stir → **5 L B** → stir. (1 day: pour the **whole** bucket A, then bucket B.)
3. SOP **645 g** every tank (dissolve in a bucket first).
4. Top up to 1,000 L → mixer 2 min → check EC + pH → photo to Boyd → then pump on.

NEVER ×

A + B mixed · same scoop for A and B · SOP or silica in a drum · Boroni without Boyd · **boric acid**
Under 1 kg → **kitchen scale** (1 g). Use a drum within 2 weeks.

Wrong EC? Pump stays OFF → CALL BOYD