# SDK API 使用手册

Version 1.7

微目电子科技

2024-05-15

# 升级记录

V1.0 (2023.3.31)

初始版本

V1.1 (2023.5.22)

逻辑分析仪通道触发支持s

V1.2 (2023.6.26)

增加 watchdog 开关

V1.3 (2023.8.19)

增加 MSO21 设备支持

增加 DDS ARB 和门控 API

V1.4 (2023.11.06)

Linux 系统增加稳定性

DLLTest 支持重新拔插,自动连接并采集

V1.5 (2023.12.14)

增加 MSO10 和 MSO21 V2 设备支持

Linux 读取 4MB 以上数据

V1.6 (2024.03.17)

DDS 增加 brust APIs

V1.7 (2024.05.15)

增加示波器和 logic 触发位置读取 API

# 目录

1.	简介	1
2.	初始化和结束	1
3.	设备 ID	1
4.	设备复位	1
5.	设备监测	2
	5.1. 回调函数	2
	5.2. Event	
	5.3. 循环检测	
6	示波器	
٥.	6.1. 采集范围设置	
	6.2. 采样率	
	6.3. 触发(硬件触发)	
	,	
	6.4. AC/DC	7
	6.5. 采集	8
	6.6. 采集完成通知	9
	6.6.1. 回调函数	9
	6.6.2. Event	9
	6.6.3. 循环检测	9
	6.7. 数据读取	9
7.	DDS	10
8.	IO	17
	回调函数	18
	Event	
	循环检测	18

# 1. 简介

作为 MOS 混合信号示波器配备的标准 DLL 接口,通过这个接口可以直接控制混合信号示波器。

该接口支持 widows 系统(X86, X64 和 arm64)和 linux 系统(X64, arm-linux-gnueabi, arm-linux-gnueabihf 和 aarch64-linux)。

# 2. 初始化和结束

调用InitDll()来完成动态库的初始化,初始化的时候会分配内存和资源用于设备监测和数据读取用。

#### int InitDll(unsigned int en\_log, unsigned int en\_hard\_watchdog);

Description Dll initialization

Input: log enable 1 Enable Log

0 Not Enable Log

watchdog enable 1 Enable hard watchdog

0 Not Enable hard watchdog

Output: Init Status

Return value 1 Success

0 Failed

调用FinishDll()来完成动态库的结束,结束的时候,会时释放初始化中申请的内存和相关资源。

#### int FinishDll(void);

Description Dll finished

Input:

Output: -Finished Status

Return value 1 Success

0 Failed

### 3. 设备 ID

每个设备都有一个 64 位的 ID 码。

#### int GetOnlyId0(void);

Description This routines return device id(0-31)

Input: -

Output: - Device ID(0-31)

#### int GetOnlyId1(void);

Description This routines return device id(32-63)

Input:

Output: - Device ID(32-63)

# 4. 设备复位

#### int ResetDevice(void);

Description This routines reset device

Input: -

Output: - Return value 1 success

0 failed

### 5. 设备监测

当 DLL 检测到有设备接入时,有 3 种方式通知主程序,回掉函数、触发 Event 和主程序循环检测。

#### 5.1. 回调函数

当检测到设备插入时,如果主程序注册了回掉函数"addcallback",它就会被调用;当 检测到设备拔出时,如果主程序注册了回掉函数"rmvcallback",它就会被调用。Dll 有一个 函数专门用于设置这个 2 个回掉函数

void SetDevNoticeCallBack(void\* ppara, AddCallBack addcallback, RemoveCallBack rmvcallback);

Description This routines sets the callback function of equipment status changed.

Input: **ppara** the parameter of the callback function

**addcallback** a pointer to a function with the following prototype:

void AddCallBack( void \* ppara)

**rmvcallback** a pointer to a function with the following prototype:

Void RemoveCallBack(void \* ppara)

Output -

#### 5.2. Event

当检测到设备插入时,如果主程序注册了 Event 句柄"addevent",它就会被设置;当检测到设备拔出时,如果主程序注册了回掉函数"rmvevent",它就会被设置。需要注意的是,主程序检测到 Event 后,需要将 Event 复位。Dll 有一个函数专门用于设置这 2 个 Event 句 板

#### void SetDevNoticeEvent(HANDLE addevent, HANDLE rmvevent);

Description This routines set the event handle, these will be set, when equipment status

changed.

Input: addevent the event handle

rmvevent the event handle

Output -

#### 5.3. 循环检测

#### int IsDevAvailable();

Description This routines return the device is available or not.

Input: -

Output Return value 1 available

0 not available

说明: 3 方式只要使用其中的一种就可以了,回掉函数和 Event 都是异步的处理方式,更加的高效,循环检测需要主程序过一定时间就检测设备是否插入或者拔出。

#### 6. 示波器

#### 6.1. 采集范围设置

设备的前级带有程控增益放大器,当采集的信号小于 AD 量程的时候,增益放大器可以

把信号放大,更多的利用 AD 的位数,提高采集信号的质量。DII 会根据设置的采集范围,自动的调整前级的增益放大器。

#### int SetOscChannelRange(int channel, int minmv, int maxmv);

Description This routines set the range of input signal.

Input: channel the set channel

0 channel 11 channel 2

minmv the minimum voltage of the input signal (mV)
maxmv the maximum voltage of the input signal (mV)

Output Return value 1 Success

0 Failed

说明:最大的采集范围为探头 X1 的时候,示波器可以采集的最大电压。比如 MSO20 为 [-12000mV,12000mV]。

注意:为了达到更好波形效果,一定要根据自己被测波形的幅度,设置采集范围。必要时,可以动态变化采集范围。

#### 6.2. 采样率

#### int GetOscSupportSampleNum();

Description This routines get the number of samples that the equipment support.

Input: -

Output Return value the support sample number

#### int GetOscSupportSamples(unsigned int\* sample, int maxnum);

Description This routines get support samples of equipment.

Input: sample the array store the support samples of the equipment

**maxnum** the length of the array

Output Return value the sample number of array stored

#### int SetOscSample(unsigned int sample);

Description This routines set the sample.

Input: sample the set sample

Output Return value 0 Failed

other value new sample

#### unsigned int GetOscSample();

Description This routines get the sample.

Input: -

Output Return value sample

#### 6.3. 触发(硬件触发)

该功能需要设备硬件触发支持。硬件触发的触发点都是采集数据的最中间,比如采集 128K 数据,触发点就是第 64K 的点。

#### 触发模式

#define TRIGGER\_MODE\_AUTO 0
#define TRIGGER\_MODE\_LIANXU 1

#### 触发条件

#define TRIGGER\_STYLE\_NONE 0x0000 //not trigger
#define TRIGGER\_STYLE\_RISE\_EDGE 0x0001 //Rising edge
#define TRIGGER\_STYLE\_FALL\_EDGE 0x0002 //Falling edge
#define TRIGGER\_STYLE\_EDGE 0x0004 //Edge

#define TRIGGER\_STYLE\_P\_MORE 0x0008 //Positive Pulse width(>)
#define TRIGGER\_STYLE\_P\_LESS 0x0010 //Positive Pulse width(>)

#define TRIGGER\_STYLE\_P 0x0020 //Positive Pulse width(<>)
#define TRIGGER\_STYLE\_N\_MORE 0x0040 //Negative Pulse width(>)
#define TRIGGER\_STYLE\_N\_LESS 0x0080 //Negative Pulse width(>)
#define TRIGGER\_STYLE\_N 0x0100 //Negative Pulse width(<>>)

#### int IsSupportHardTrigger();

Description This routines get the equipment support hardware trigger or not .

Input: -

Output Return value 1 support hardware trigger

0 not support hardware trigger

#### unsigned int GetTriggerMode();

Description This routines get the trigger mode.

Input: -

Output Return value TRIGGER\_MODE\_AUTO

TRIGGER\_MODE\_LIANXU

#### void SetTriggerMode(unsigned int mode);

Description This routines set the trigger mode.

Input: mode TRIGGER\_MODE\_AUTO

TRIGGER\_MODE\_LIANXU

Output -

#### unsigned int GetTriggerStyle();

Description This routines get the trigger style.

Input: -

Output Return value TRIGGER\_STYLE\_NONE

TRIGGER\_STYLE\_RISE\_EDGE TRIGGER\_STYLE\_FALL\_EDGE TRIGGER\_STYLE\_EDGE

TRIGGER\_STYLE\_P\_MORE
TRIGGER\_STYLE\_P\_LESS

TRIGGER\_STYLE\_P

TRIGGER\_STYLE\_N\_MORE TRIGGER\_STYLE\_N\_LESS

TRIGGER\_STYLE\_N

#### void SetTriggerStyle(unsigned int style);

Description This routines set the trigger style.

Input: style TRIGGER\_STYLE\_NONE

TRIGGER\_STYLE\_RISE\_EDGE
TRIGGER\_STYLE\_FALL\_EDGE
TRIGGER\_STYLE\_EDGE
TRIGGER\_STYLE\_P\_MORE

TRIGGER\_STYLE\_P\_LESS

TRIGGER\_STYLE\_P

TRIGGER\_STYLE\_N\_MORE
TRIGGER\_STYLE\_N\_LESS
TRIGGER\_STYLE\_N

Output -

#### int GetTriggerPulseWidthNsMin();

Description This routines get the min time of pulse width.

Input: -

Output Return min time value of pulse width(ns)

#### int GetTriggerPulseWidthNsMax();

Description This routines get the max time of pulse width.

Input: -

Output Return max time value of pulse width(ns)

#### int GetTriggerPulseWidthDownNs();

Description This routines get the down time of pulse width.

Input: -

Output Return down time value of pulse width(ns)

#### int GetTriggerPulseWidthUpNs();

Description This routines set the down time of pulse width.

Input: down time value of pulse width(ns)

Output -

#### void SetTriggerPulseWidthNs(int down\_ns, int up\_ns);

Description This routines set the up time of pulse width.

Input: up time value of pulse width(ns)

Output \_

#### unsigned int GetTriggerSource();

Description This routines get the trigger source.

Input: -

Output Return value TRIGGER\_SOURCE\_CH1 0 //CH1

TRIGGER\_SOURCE\_CH2 1 //CH2

TRIGGER\_SOURCE\_LOGIC0 16 //Logic 0

TRIGGER\_SOURCE\_LOGIC1 17 //Logic 1
TRIGGER\_SOURCE\_LOGIC2 18 //Logic 2
TRIGGER\_SOURCE\_LOGIC3 19 //Logic 3
TRIGGER\_SOURCE\_LOGIC4 20 //Logic 4
TRIGGER\_SOURCE\_LOGIC5 21 //Logic 5
TRIGGER\_SOURCE\_LOGIC6 22 //Logic 6
TRIGGER\_SOURCE\_LOGIC7 23 //Logic 7

#### void SetTriggerSource(unsigned int source);

Description This routines set the trigger source.

Input: source TRIGGER\_SOURCE\_CH1 0 //CH1

TRIGGER\_SOURCE\_CH2 1 //CH2

TRIGGER\_SOURCE\_LOGIC0 16 //Logic 0
TRIGGER\_SOURCE\_LOGIC1 17 //Logic 1
TRIGGER\_SOURCE\_LOGIC2 18 //Logic 2
TRIGGER\_SOURCE\_LOGIC3 19 //Logic 3
TRIGGER\_SOURCE\_LOGIC4 20 //Logic 4
TRIGGER\_SOURCE\_LOGIC5 21 //Logic 5
TRIGGER\_SOURCE\_LOGIC6 22 //Logic 6
TRIGGER\_SOURCE\_LOGIC7 23 //Logic 7

#### Output

注意:如果逻辑分析仪和 IO 是复用的 (例如 MSO20、MSO21),需要将对应的 IO 打开,并设置为输入状态。

#### int GetTriggerLevel();

Description This routines get the trigger level.

Input: -

Output Return value level (mV)

#### void SetTriggerLevel(int level);

Description This routines set the trigger level.

Input: level (mV)

Output -

#### int IsSupportTriggerSense();

Description This routines get the equipment support trigger sense or not.

Input: -

Return value 1 support

0 not support

#### int GetTriggerSenseDiv();

Description This routines get the trigger sense.

Input: -

Output Return value Sense (0-1 div)

#### void SetTriggerSenseDiv(int sense);

Description This routines set the trigger sense.

Input: Sense (0-1 div)

Output -

说明: 触发灵敏度的范围为  $0.1 \, \text{Div-}1.0 \, \text{Div} = (采集范围设置最大值-采集范围设置最小值)/10.0。比如你设置的采集范围为[-1000,1000],<math>1 \, \text{Div} = (1000-1000)/10.0=200 \, \text{mV}$ 。

#### bool IsSupportPreTriggerPercent();

Description This routines get the equipment support Pre-trigger Percent or not .

Input:

Output Return value 1 support

0 not support

#### int GetPreTriggerPercent();

Description This routines get the Pre-trigger Percent.

Input: -

Output Return value Percent (5-95)

#### void SetPreTriggerPercent(int front);

Description This routines set the Pre-trigger Percent.

Input: Percent (5-95)

Output -

#### int IsSupportTriggerForce();

Description This routines get the equipment support trigger force or not.

Input: -

Return value 1 support

0 not support

#### void TriggerForce();

Description This routines force capture once.

Input: -

Output: -

#### 6.4. AC/DC

#### int IsSupportAcDc(unsigned int channel);

Description This routines get the device support AC/DC switch or not.

Input: channel 0:channel 1

1:channel 2

Output Return value 0 : not support AC/DC switch

1: support AC/DC switch

#### void SetAcDc(unsigned int channel, int ac);

Description This routines set the device AC coupling.

Input: channel 0:channel 1

1:channel 2

ac 1: set AC coupling

0: set DC coupling

Output -

#### int GetAcDc(unsigned int channel,);

Description This routines get the device AC coupling.

Input: channel 0:channel 1

1:channel 2

Output Return value 1 : AC coupling

0: DC coupling

#### 6.5. 采集

调用Capture函数开始采集数据,length就是你想要采集的长度,以K为单位,比如length=10,就是10K 10240个点。对于采样率的大于等于存储深度的采集长度,取length和存储深度的最小值;对于采样率小于存储深度,取length和1秒采集数据的最小值。函数会返回实际采集数据的长度。force length可以强制取消只能采集1秒的限制。

#### int Capture(int length, unsigned short capture\_channel,char force\_length);

Description This routines set the capture length and start capture.

Input: length capture length(KB)

capture\_channel

ch1=0x0001 ch2=0x0002 ch3=0x0004 ch4=0x0008 logic=0x0100

ch1+ch2 0x0003 ch1+ch2+ch3 0x0007 ch1+logic 0x0101

force\_length 1: force using the length, no longer limits the max collection

1 seconds

Output Return value the real capture length(KB)

使用正常触发模式(TRIGGER\_MODE\_LIANXU)的时候。发送了采集命令,还没有收到采集完成数据通知。现在,想要停止软件。

- 1、推荐方式: 你把触发模式改成TRIGGER\_MODE\_AUTO,等待收到采集完成数据通知,再停止软件。
  - 2、使用 AbortCapture.

#### DLL\_API int WINAPI AbortCapture();

Description This routines set the abort capture

Input:

Output Return value 1:success 0:failed

#### unsigned int GetMemoryLength();

Description This routines get memory depth of equipment (KB).

Input: -

Output memory depth of equipment(KB)

Roll Mode: 该模式下,采样率被固定的设置为最小采样率,采集长度也是固定的设置为 1 秒采集数据长度。正常的调用 Capture, 把每次采集的数据连接在一起显示就是完整的 波形。

#### int IsSupportRollMode();

Description This routines get the equipment support roll mode or not .

Input: -

Output Return value 1 support roll mode

0 not support roll mode

#### int SetRollMode(unsigned int en);

Description This routines enable or disenable the equipment into roll mode.

Input:

Output Return value 1 success

0 failed

#### 6.6.采集完成通知

当数据采集完成时,有3种方式通知主程序,回掉函数、触发 Event 和主程序循环检测。

#### 6.6.1. 回调函数

当数据采集完成时,如果主程序注册了回掉函数"datacallback",它就会被调用。Dll 有一个函数专门用于设置这个回掉函数

#### void SetDataReadyCallBack(void\* ppara, DataReadyCallBack datacallback);

Description This routines sets the callback function of capture complete.

Input: **ppara** the parameter of the callback function

**datacallback** a pointer to a function with the following prototype:

void DataReadyCallBack (void \* ppara)

Output -

#### 6.6.2. Event

当数据采集完成时,如果主程序注册了 Event 句柄"dataevent",它就会被设置。需要注意的是,主程序检测到 Event 后,需要将 Event 复位。Dll 有一个函数专门用于设置这个 Event 句柄

#### void SetDevDataReadyEvent(HANDLE dataevent);

Description This routines set the event handle, these will be set, when capture complete

Input: dataevent the event handle

Output -

#### 6.6.3. 循环检测

#### int IsDataReady();

Description This routines return the capture is complete or not.

Input: -

Output Return value 1 complete

0 not complete

说明: 3 方式只要使用其中的一种就可以了,回掉函数和 Event 都是异步的处理方式,更加的高效,循环检测需要主程序开始采集以后,过一定时间就检测是否采集完成。

#### 6.7. 数据读取

#### unsigned int ReadVoltageDatas(char channel, double\* buffer, unsigned int length);

Description This routines read the voltage datas. (V)
Input: channel read channel 0 :channel 1

1:channel 2

**buffer** the buffer to store voltage datas

**length** the buffer length **Return value** the read length

#### unsigned int ReadVoltageDatasTriggerPoint();

Description This routines read the trigger location where the data collected

Input:

Output

Output Return value the trigger points

#### int IsVoltageDatasOutRange(char channel);

Description This routines return the voltage datas is out range or not.

Input: channel read channel 0 :channel 1

1 :channel 2

Output Return value 0 :not out range

1:out range

#### double GetVoltageResolution(char channel);

Description This routines return the current voltage resolution value

One ADC resolution for the voltage value:

Full scale is 1000mv

the ADC is 8 bits

voltage resolution value = 1000mV/256

Input: channel read channel 0:channel 1

1:channel 2

Output Return value voltage resolution value

#### unsigned int ReadLogicDatas(unsigned char\* buffer, unsigned int length);

Description This routines read the logic data of mso.

Input:

buffer the buffer to store logic datas

length the buffer length

Output Return value the read length

#### unsigned int ReadLogicDatasTriggerPoint();

Description This routines read the trigger location where the data collected

Input:

Output Return value the trigger points

#### 7. DDS

#### int IsSupportDDSDevice();

Description This routines get support dds or not

Input: -

Output Return value support dds or not

#### int GetDDSDepth();

Description This routines set dds depth

Input:

Output: Return value depth

#### void SetDDSOutMode(unsigned char channel\_index, unsigned int out\_mode);

Description This routines set dds out mode Input: **channel\_index** 0:channel 1

1:channel 2

out\_mode DDS\_OUT\_MODE\_CONTINUOUS 0x00

DDS\_OUT\_MODE\_SWEEP 0x01 DDS\_OUT\_MODE\_BURST 0x02

Output

#### unsigned int GetDDSOutMode(unsigned char channel\_index);

Description This routines get dds out mode Input: channel\_index 0 :channel 1

1:channel 2

Output mode DDS\_OUT\_MODE\_CONTINUOUS 0x00

DDS\_OUT\_MODE\_SWEEP 0x01 DDS\_OUT\_MODE\_BURST 0x02

#### int GetDDSSupportBoxingStyle(int\* style);

Description This routines get support wave styles Input: style array to store support wave styles

Output Return value if style==NULL return number of support wave styles

else store the styles to array, and return number of wave

styles

#### void SetDDSBoxingStyle(unsigned char channel\_index, unsigned int boxing);

Description This routines set wave style Input: channel\_index 0 :channel 1

1:channel 2

Input: **boxing W\_SINE = 0x0001,** 

W\_SQUARE = 0x0002, W\_RAMP = 0x0004, W\_PULSE = 0x0008, W\_NOISE = 0x0010, W\_DC = 0x0020,

#### $W_ARB = 0x0040$

Output: -

void UpdateDDSArbBuffer(unsigned char channel\_index, unsigned short\* arb\_buffer, uint32\_t arb\_buffer\_length);

Description This routines update arb buffer Input: **channel index** 0:channel 1

1:channel 2

arb\_buffer the dac buffer

arb\_buffer\_length the dac buffer length need equal to the dds depth

Output: -

void SetDDSPinlv(unsigned char channel\_index, unsigned int pinlv);

Description This routines set frequence

Input: channel\_index 0:channel 1

1:channel 2

Input: pinlv frequence

Output: -

void SetDDSDutyCycle(unsigned char channel\_index, int cycle);

Description This routines set duty cycle

Input: channel\_index 0:channel 1

1:channel 2

Input: cycle duty cycle

Output: -

int GetDDSCurBoxingAmplitudeMv(unsigned int boxing);

Description This routines get dds amplitdude of wave

Input: **boxing** BX\_SINE~BX\_ARB

Output: Return the amplitdude(mV) of wave

void SetDDSAmplitudeMv(unsigned char channel\_index, int amplitdude);

Description This routines set dds amplitdude(mV)

Input: channel\_index 0 :channel 1

1:channel 2

amplitdude amplitdude(mV)

Output: -

int GetDDSAmplitudeMv(unsigned char channel\_index);

Description This routines get dds amplitdude(mV)

Input: channel\_index 0 :channel 1

1:channel 2

Output: return amplitdude(mV)

# int GetDDSCurBoxingBiasMvMin(unsigned int boxing); int GetDDSCurBoxingBiasMvMax(unsigned int boxing);

Description This routines get dds bias of wave
Input: boxing BX\_SINE~BX\_ARB
Output: Return the bias(mV) range of wave

#### void SetDDSBiasMv(unsigned char channel\_index, int bias);

Description This routines set dds bias(mV)

Input: **channel\_index** 0 :channel 1

1 :channel 2

bias bias(mV)

Output: -

#### int GetDDSBiasMv(unsigned char channel\_index);

Description This routines get dds bias(mV)

Input: channel\_index 0 :channel 1

1:channel 2

Output: Return the bias(mV) of wave

#### void SetDDSSweepStartFreq(unsigned char channel\_index, double freq);

Description This routines set dds sweep start freq
Input: channel index 0 :channel 1

1:channel 2

freq

Output: -

#### double GetDDSSweepStartFreq(unsigned char channel\_index);

Description This routines get dds sweep start freq Input: channel\_index 0 :channel 1

1:channel 2

Output: freq

#### void SetDDSSweepStopFreq(unsigned char channel\_index, double freq);

Description This routines set dds sweep stop freq
Input: channel index 0:channel 1

1:channel 2

freq

Output: -

#### double GetDDSSweepStopFreq(unsigned char channel\_index);

Description This routines get dds sweep stop freq Input: **channel\_index** 0 :channel 1

1:channel 2

Output: freq

# void SetDDSSweepTime(unsigned char channel\_index, unsigned long long int time\_ns);

Description This routines set dds sweep time

Input: channel\_index 0 :channel 1

1:channel 2

time/ns

Output: -

#### unsigned long long int GetDDSSweepTime(unsigned char channel\_index);

Description This routines get dds sweep time

Input: channel\_index 0 :channel 1

1:channel 2

Output: time/ns

#### void SetDDSBurstStyle(unsigned char channel\_index, int style);

Description This routines set dds burst style

Input: **channel\_index** 0 :channel 1

1:channel 2

**style** 0--n loops

1--gate

Output: -

#### int GetDDSBurstStyle(unsigned char channel\_index);

Description This routines get dds burst style

Input: s 0:channel 1

1:channel 2

Output: **style** 0--n loops

1--gate

#### void SetDDSLoopsNum(unsigned char channel\_index, unsigned long long int num);

Description This routines set dds loops num

Input: channel\_index 0:channel 1

1:channel 2

num

Output: -

#### unsigned long int GetDDSLoopsNum(unsigned char channel\_index);

Description This routines get dds loops num

Input: channel\_index 0:channel 1

1:channel 2

Output: num

#### void SetDDSLoopsNumInfinity(unsigned char channel\_index, int en);

Description This routines set dds loops num infinity

Input: channel\_index 0:channel 1

1:channel 2

en

Output: -

#### int GetDDSLoopsNumInfinity(unsigned char channel\_index);

Description This routines get dds loops num infinity

Input: channel\_index 0:channel 1

1:channel 2

Output: loops num infinity

#### void SetDDSBurstPeriodNs(unsigned char channel\_index, unsigned long long int

ns);

Description This routines set dds burst period(ns)

Input: channel\_index 0:channel 1

1:channel 2

ns

Output: -

#### unsigned long long int GetDDSBurstPeriodNs(unsigned char channel\_index);

Description This routines get dds burst period(ns)

Input: **channel\_index** 0 :channel 1

1 :channel 2

Output: ns

# $void\ SetDDS BurstDelay Ns (unsigned\ char\ channel\_index,\ unsigned\ long\ long\ int$

ns);

**Description** This routines set dds burst delay time(ns)

Input: channel\_index 0 :channel 1

1:channel 2

ns

Output: -

#### unsigned long int GetDDSBurstDelayNs(unsigned char channel\_index);

Description This routines get dds burst delay time(ns)

Input: channel\_index 0:channel 1

1:channel 2

Output: ns

#### void SetDDSTriggerSource(unsigned char channel\_index, unsigned int src);

Description This routines set dds trigger source Input: **channel index** 0 : channel 1

1: channel 2

src 0: internal

> 1: external 2: manual

Output:

#### unsigned int GetDDSTriggerSource(unsigned char channel\_index);

Description This routines get dds trigger source

channel index Input: 0 : channel 1

> : channel 2 1

0: internal Output: trigger source

> 1: external 2: manual

#### void SetDDSTriggerSourcelo(unsigned char channel\_index, uint32\_t io);

Description This routines set dds trigger source io Input:

channel\_index 0: channel 1

1: channel 2

0: DIO0 io

....

7: DIO7

Output:

Note: 需要使用DIO API,将对应的DIO设置为输入/输出状态

#### uint32\_t GetDDSTriggerSourcelo(unsigned char channel\_index);

Description This routines get dds trigger source io

Input: channel\_index 0 : channel 1

: channel 2

Output: trigger source io 0: DIO0

7: DIO7

#### void SetDDSTriggerSourceEnge(unsigned char channel\_index, unsigned int enge);

Description This routines set dds trigger source enge

Input: channel index 0: channel 1

1: channel 2

0: rising enge

1: falling

Output:

#### unsigned int GetDDSTriggerSourceEnge(unsigned char channel\_index);

Description This routines get dds trigger enge

channel\_index Input: 0: channel 1

1: channel 2

Output: enge 0: rising

1: falling

#### void SetDDSOutputGateEnge(unsigned char channel\_index, unsigned int enge);

Description This routines set dds output gate enge Input: **channel\_index** 0 : channel 1

1: channel 2

enge 0:close

1: rising2: falling

Output: -

#### unsigned int GetDDSOutputGateEnge(unsigned char channel\_index);

Description This routines get dds output gate enge Input: channel\_index 0 : channel 1

1: channel 2

Output: enge 0:close

1: rising2: falling

#### void DDSManualTrigger(unsigned char channel\_index);

Description This routines manual trigger dds

Input: channel\_index 0 : channel 1

1 : channel 2

Output: -

#### void DDSOutputEnable(unsigned char channel\_index , int enable);

Description This routines enable dds output or not Input: **channel\_index** 0 : channel 1

1: channel 2

**enable** 1 enable 0 not enable

Output: -

#### int IsDDSOutputEnable(unsigned char channel\_index);

Description This routines get dds output enable or not

Input: channel\_index 0: channel 1

1: channel 2

Output Return value dds enable or not

#### 8. IO

#### int IsSupportIODevice();

Description This routines get support IO ctrl or not

Input:

Output Return value support io ctrl or not

#### int GetSupportIoNumber();

Description This routines get support io nums of equipment.

Output Return value the sample number of io nums

当 IO 设置为输入时,有3种方式读取 IO 状态,回掉函数、触发 Event 和主程序循环检 测。

#### 回调函数

SDK 会定时读取 IO 状态,如果主程序注册了回掉函数"datacallback",它就会被调用。 DII有一个函数专门用于设置这个回掉函数

#### void SetIOReadStateCallBack(void\* ppara, IOReadStateCallBack callback);

This routines sets the callback function of read io status.

Input: ppara the parameter of the callback function

**callback** a pointer to a function with the following prototype

#### **Event**

SDK 会定时读取 IO 状态,如果主程序注册了 Event 句柄"dataevent",它就会被设置。 需要注意的是,主程序检测到 Event 后,需要将 Event 复位。Dll 有一个函数专门用于设置 这个 Event 句柄

#### void SetIOReadStateReadyEvent(HANDLE dataevent);

Description This routines set the event handle, these will be set, when capture complete

Input: dataevent the event handle

Output

#### 循环检测

#### int IsIOReadStateReady();

Description This routines return read io is complete or not.

Input:

Output Return value 1 complete

0 not complete

说明: 3 方式只要使用其中的一种就可以了,回掉函数和 Event 都是异步的处理方式,更加 的高效;循环检测需要主程序开始采集以后,过一定时间就检测是否采集完成。

#### void IOEnable(unsigned char channel, unsigned char enable);

Description This routines set io enable or not

Input: channel dio0 0

dio11 dio22

enable not enable 0

enable 1

Output:

#### unsigned char IsIOEnable(unsigned char channel);

Description This routines get io enable or not

Input: channel dio0 0

> dio11 dio22

Output: return not enable 0 or enable 1

#### void SetIOInOut(unsigned char channel, unsigned char inout);

Description This routines set io in or out

Input: channel dio0 0

> dio11 dio22

.....

inout in 0

out 1

Output:

# unsigned char GetIOInOut(unsigned char channel);

Description This routines get io in or out

channel dio0 0 Input:

dio11

dio22

Output: return in 0

out 1

#### void SetIOOutState(unsigned char channel, unsigned char state);

Description This routines set io state

channel dio0 0 Input:

> dio11 dio22

.....

**state** 0--0

1--1

2--z

3--pulse

4—dds gate

Output:

#### char GetIOInState(unsigned char channel);

Description This routines get io state

If the SetIOReadStateCallBack setting callback function is used, IOReadStateCallBack will directly notify the IO input status; If use SetIOReadStateReadyEvent and IsIOReadStateReady to read the query, you need to call GetIOState to get the IO input status

Input: channel dio0 0

dio11

dio22

.....

Output: return 0 state

1 state