
## HPBWave EE 方塊圖



## Switch Mode:

	Connect USB Cable(Power +5V IN)			r +5V IN)	Disconnect USB Cable	
	Switch ON		Switch OFF		Switch ON	Switch OFF
Power supply	2.	BT Board & HGR Board 電源由 USB +5V Cable 供應。(不由 Battery 供 電) USB +5V Cable 持續對 Battery 充電(充滿後 此功能結束)。	2.	USB +5V Cable 持續對 Battery 充電(充滿後此功能結束)。 HPBWave Power Dowe	BT Board & HGR Board 電源由 Battery 供應,且 MCU 將偵測 Battery 電量,如電量 不足將提示電量不 足。	HPBWave Power Dowen

## 14pin FFC connector Pin define:

	Pin Name	Pin Function	
Pin1~Pin2	P+	Power IN(+3.3V or Battery supply)	
Pin3	NC	Not Connect	
Pin4~Pin6	P-	Power IN-	
Pin7	,	Charge_5V	
Pin8	,	Charge_LED+	
Pin9	3	Low_BAT_NOTIFY	
Pin10	<b>3</b>	GPIO1	
Pin11	3	GPIO2	
Pin12	3	GPIO3	