

Samsung QMC75 / QM75C Commercial Display Manual

1. Official Samsung Sources

Samsung's official product identifier for the 75-inch QMC Series display is QM75C, with model code LH75QMCEBGCXGO. This manual is based on official Samsung documentation for that model, especially the Samsung 75-Inch QMC Series Commercial Display product page, the QMC Series Crystal UHD Signage leaflet, and the Samsung Business QMC Series page.

The source manual identifies the display as a 75-inch commercial UHD digital signage display designed for indoor business use, meeting rooms, signage, information display, collaboration, and managed commercial content.

Practical installation, setup, operation, troubleshooting, maintenance, and quick-reference notes were added to make this manual more useful for real deployment and support work. Exact menu names and options can vary depending on firmware version, region, MagicINFO/VXT configuration, and installed system software.

2. Device Description

The Samsung QMC75, officially identified as the QM75C, is a 75-inch commercial UHD signage display from Samsung's QMC Series.

It is designed to display business content in indoor commercial environments. It may be used as a meeting room display, signage screen, information board, presentation screen, lobby display, classroom display, or collaboration screen.

Common deployment locations include:

- Meeting rooms
- Conference rooms
- Lobbies
- Reception areas
- Retail spaces
- Hotels
- Education spaces
- Corporate offices
- Public information areas
- Digital signage networks

In a smart office or AV room topology, the QM75C should be treated as the **commercial display / presentation screen**. It receives content from AV sources such as AirMedia receivers, laptops, media players, signage players, DisplayPort sources, HDMI sources, USB media, or network-based signage management systems.

The display is not a router, switch, access point, or AV control processor. Its role is visual output, signage playback, source display, and commercial screen management.

3. Technical Specifications

The display is manufactured by Samsung.

Official model information:

```
Series: QMC Series
Commercial model: QM75C
Model code: LH75QMCEBGCGXGO
Screen class: 75-inch class
Measured screen size: 74.5 inches
```

Main display characteristics:

- 75-inch class commercial display
- UHD / 4K resolution
- 3840 x 2160 resolution
- 16:9 aspect ratio
- 500 nit typical brightness
- 4000:1 contrast ratio
- VA panel
- Non-glare surface
- Dynamic Crystal Color
- Quantum Processor Lite 4K
- Ultra-slim 28.5 mm depth
- Indoor commercial use
- 24/7 operation support
- Portrait and landscape orientation support
- ENERGY STAR 8.0 certified

Network and wireless:

- RJ45 LAN
- Dual-band Wi-Fi 2.4 GHz / 5 GHz
- Bluetooth
- SmartView+ wireless screen sharing

Audio/video and control interfaces:

- HDMI input(s)
- DisplayPort input
- USB input(s)
- RJ45 LAN
- RS232C(IN) control

- IR sensor input
- AC power input

Management and content platforms:

- Tizen platform
- On-screen Home UI
- MagicINFO
- Samsung VXT
- RS-232C control
- Remote controller

Mounting:

- VESA wall mount support
- Compatible with Samsung Slim Fit Wall Mount
- Landscape or portrait orientation

Important note:

The display is intended for indoor commercial use. It should be installed in controlled indoor conditions with proper ventilation and safe mounting.

4. Ports, Buttons, and Indicators

The QM75C includes several ports for source input, network connectivity, USB media, serial control, IR control, and power.

4.1 HDMI Inputs

HDMI inputs are used for digital audio/video sources.

Common HDMI sources:

- Laptop
- Crestron AirMedia receiver
- Media player
- Video conferencing codec
- Digital signage player
- AV switcher
- Cable box or local source device

If the display shows “No Signal,” confirm the correct HDMI input is selected and the connected source is powered on.

4.2 DisplayPort Input

DisplayPort provides another high-quality digital input option.

It may be used for:

- PC sources
- Signage players
- AV systems
- Commercial video devices

4.3 USB Ports

USB ports can be used for media or content input depending on display configuration.

They may support:

- USB media playback
- Firmware or service functions depending on system support
- Content transfer workflows

4.4 RJ45 LAN Port

The RJ45 LAN port connects the display to the wired network.

It is used for:

- MagicINFO management
- Samsung VXT management
- Network content
- Remote monitoring
- Firmware or system connectivity
- Enterprise deployment

Wired LAN is recommended for reliable signage and remote management.

4.5 Wi-Fi and Bluetooth

The display supports dual-band Wi-Fi and Bluetooth.

Wi-Fi may be used for:

- Network connection
- SmartView+
- Remote content workflows
- Wireless management where supported

Bluetooth may be used for compatible accessories or supported features depending on region and configuration.

4.6 RS232C(IN)

The RS232C(IN) port allows external serial control using the included RS232C adapter.

It may be used by:

- AV control systems
- Room automation systems

- Building control systems
- Crestron control processor
- Third-party control systems

If RS-232 control commands are ignored, verify the RS232C adapter, cable, baud/control settings, and command format.

4.7 IR Sensor Input

The IR sensor input accepts the included IR sensor cable. This allows the remote controller to work when the display is mounted or positioned in a way where the built-in IR reception is not convenient.

4.8 AC Power Inlet

The display is powered through AC using the included power cord.

Always connect to a suitable outlet and follow safe installation practices.

4.9 Remote Controller

The included remote controller is used for:

- Power on/off
- Source selection
- Menu navigation
- Settings configuration
- Initial setup
- Troubleshooting
- Reset or system menu access where available

5. Installation and Setup Notes

Before installation, confirm the exact model, mounting hardware, wall structure, power location, source devices, cable routes, ventilation, orientation, and network connection.

Basic installation steps:

1. Confirm the display model is QM75C / LH75QMCEBGCXGO.
2. Select landscape or portrait orientation.
3. Verify the wall can support the display and mounting hardware.
4. Use a compatible VESA wall mount or Slim Fit Wall Mount.
5. Mount the display safely according to Samsung installation guidance.
6. Connect AC power using the included power cord.
7. Connect source devices through HDMI, DisplayPort, or USB.
8. Connect LAN cable or configure Wi-Fi.
9. Connect RS232C control if using an AV control system.
10. Connect the IR sensor cable if required.
11. Power on the display.
12. Complete first-time setup using the on-screen Tizen Home UI.

13. Select the correct input source.
14. Configure network settings.
15. Configure MagicINFO or Samsung VXT if used.
16. Test display output.
17. Test remote control and control-system commands.
18. Document source mapping, IP address, mount orientation, and management platform.

Important installation notes:

- The display is for indoor use.
 - Maintain adequate ventilation.
 - Do not block vents.
 - Use appropriate wall anchors and mounting hardware.
 - Consider service access to ports.
 - Label HDMI, DisplayPort, LAN, USB, and RS-232 cables.
 - Use cable management to avoid strain on ports.
 - Confirm portrait or landscape orientation is supported by the content and mounting design.
-

6. Source and Input Configuration

The display can show content from multiple input sources.

Common sources:

- HDMI laptop input
- Crestron AirMedia HDMI output
- Cisco Codec EQ HDMI output
- Signage player
- DisplayPort PC
- USB media
- Wireless sharing through SmartView+

6.1 Manual Source Selection

Use the on-screen Home UI and Sources menu to choose the correct input.

If the screen is blank, always verify source selection before troubleshooting deeper issues.

6.2 Auto Source Switching and Recovery

The QM75C supports Auto Source Switching and Recovery.

This helps the display switch to an active source or recover when the original source fails, depending on configuration.

Use this feature when:

- A meeting room has multiple sources.
- A signage player should recover automatically.
- Users often switch between HDMI and wireless presentation.

- Display should avoid remaining on a blank inactive input.

If source switching does not behave as expected, check both the display settings and the connected source devices.

7. Network, MagicINFO, and Samsung VXT

The display supports network-based management and content workflows.

7.1 LAN Connection

Wired LAN is recommended for stable commercial display management.

Check:

```
RJ45 cable connected
Switch port active
Correct VLAN
DHCP or static IP configured
Gateway reachable
DNS working
```

7.2 Wi-Fi Connection

Wi-Fi can be used when wired LAN is not available.

Check:

```
Correct SSID
Correct password
2.4 GHz or 5 GHz support
Signal strength
IP address
Gateway and DNS
```

7.3 MagicINFO

MagicINFO is Samsung's signage content and device management platform.

It may be used for:

- Content publishing
- Playlist scheduling
- Device monitoring
- Remote management
- Signage network operation

7.4 Samsung VXT

Samsung VXT is a cloud-based platform for content creation and remote device management.

It may be used for:

- Remote display management
- Cloud signage operation
- Content deployment
- Monitoring
- Centralized administration

If remote management fails, check network connectivity, platform configuration, device registration, account permissions, and firewall settings.

8. SmartView+ Wireless Screen Sharing

SmartView+ allows wireless screen sharing during collaboration.

It may be used for:

- Meeting room collaboration
- Wireless presentation
- Quick content sharing
- Local screen sharing from compatible devices

If SmartView+ does not work, check:

- SmartView+ enabled
- Display connected to network
- Client device compatibility
- Same network or required discovery path
- Wi-Fi signal strength
- Firewall or network isolation settings
- Firmware version

In enterprise networks, wireless sharing may be restricted by VLAN separation, client isolation, or firewall rules.

9. RS-232C and Control-System Integration

The QM75C supports RS232C(IN) serial control using the included adapter.

This is useful when integrating the display with:

- Crestron CP4
- AV control systems
- Room automation systems
- Centralized control panels
- Building systems

Common controlled functions:

- Power on/off
- Source selection
- Volume
- Input status
- Display status
- Menu or system functions depending on command support

Common RS-232 issues:

- Adapter not connected
- Wrong cable
- Wrong serial settings
- Wrong command format
- Incorrect device ID
- Control processor program mismatch
- Display not powered or in unavailable state

Always verify the Samsung control protocol and actual model support before relying on serial commands.

10. Normal Operation

During normal operation:

- Display powers on from AC.
- Selected source appears on screen.
- Home UI provides Favorites, Sources, and Settings.
- LAN or Wi-Fi network connection works.
- HDMI/DisplayPort/USB sources display correctly.
- SmartView+ works if enabled.
- MagicINFO or VXT management works if configured.
- RS-232C control works if connected and programmed.
- Display can operate continuously in 24/7 commercial use.
- Portrait or landscape orientation matches the installation.
- Brightness and picture settings are appropriate for the environment.
- No repeated network or source errors appear.

Useful normal-operation checks:

Check power and remote response
Check source selection
Check HDMI/DisplayPort signal
Check network status
Check MagicINFO or VXT status
Check SmartView+ if used
Check RS-232C control
Check picture quality
Check orientation
Check ventilation

11. Troubleshooting

Troubleshooting should move from simple display checks to source, network, and management checks:

1. AC power
2. Remote control / IR
3. Source selection
4. HDMI/DisplayPort/USB cabling
5. Source device power
6. Network connection
7. SmartView+
8. MagicINFO/VXT
9. RS-232C control
10. Firmware/software
11. Mounting/ventilation
12. Hardware fault

11.1 Display Does Not Power On

Symptom:

- Screen is black
- No response from remote
- Display appears dead
- Power indicator not responding

Possible causes:

- AC power cable disconnected
- Outlet not working
- Remote batteries dead
- Display power issue
- Power strip or breaker issue
- Hardware fault

Checks:

Check AC power cord
Test wall outlet
Check power strip
Replace remote batteries
Try physical/on-screen controls if available
Check power indicator behavior

Fix actions:

- Reseat power cord.
- Use a known-good outlet.
- Replace remote batteries.
- Test with another power source if safe.
- Escalate if display remains off with confirmed AC power.

11.2 No Signal or Blank Screen

Symptom:

- Screen shows no signal
- Screen is blank while powered on
- Source content does not appear

Possible causes:

- Wrong input source selected
- HDMI/DisplayPort cable disconnected
- Source device powered off
- Bad cable
- Unsupported resolution
- Source output disabled
- AV receiver/switcher not passing signal

Checks:

Open Sources menu
Select correct HDMI or DisplayPort input
Check source device power
Reseat cable
Try another cable
Try another input
Check source resolution

Fix actions:

- Choose correct source from Home UI Sources menu.
- Turn on source device.

- Replace cable.
 - Set source device to supported resolution.
 - Check AV switcher or AirMedia receiver if used.
-

11.3 Input Source Does Not Switch

Symptom:

- Display stays on wrong input
- Auto source switching fails
- New source is not detected

Possible causes:

- Auto Source Switching not configured
- Source has no active signal
- Cable issue
- Input priority not set
- HDMI handshake issue
- Source device asleep

Fix actions:

```
Use Sources menu manually
Enable or adjust Auto Source Switching and Recovery
Wake the source device
Reseat cable
Power-cycle source device if needed
Check input priority settings
```

11.4 HDMI or DisplayPort Source Problem

Symptom:

- Image flickers
- No audio/video
- Intermittent signal
- Wrong resolution
- Color looks incorrect

Possible causes:

- Bad HDMI/DisplayPort cable
- Cable too long or low quality
- Source resolution mismatch
- HDMI handshake issue
- Adapter or converter problem

- Source output issue

Checks:

```
Replace cable
Try shorter cable
Try another input
Test source on another display
Check source resolution and refresh rate
Remove unnecessary adapters
```

Fix actions:

- Use a quality cable.
- Match supported 4K resolution settings.
- Avoid unreliable adapters.
- Restart source device.
- Use another display input if needed.

11.5 USB Media Not Working

Symptom:

- USB content not detected
- Files not shown
- Media does not play

Possible causes:

- Unsupported file format
- USB drive not recognized
- USB drive format issue
- Port issue
- File path or content issue

Checks:

```
Try another USB drive
Check supported media format
Check USB file system
Reconnect USB device
Test with a simple supported file
```

Fix actions:

- Use supported media formats.
- Reformat USB drive if appropriate.

- Try another USB port if available.
 - Use MagicINFO/VXT for managed content where appropriate.
-

11.6 LAN Network Problem

Symptom:

- Display not online
- MagicINFO or VXT cannot reach display
- Network apps do not work
- Remote management unavailable

Possible causes:

- LAN cable disconnected
- Switch port down
- Wrong VLAN
- DHCP failure
- Static IP conflict
- Gateway or DNS issue
- Firewall restriction

Checks:

```
Check RJ45 cable
Check switch port
Check display network settings
Verify IP address
Ping display if allowed
Check gateway and DNS
```

Fix actions:

- Reseat LAN cable.
 - Correct IP settings.
 - Use DHCP or valid static IP.
 - Fix VLAN/gateway/DNS.
 - Check firewall rules.
-

11.7 Wi-Fi Network Problem

Symptom:

- Display cannot connect to Wi-Fi
- Wireless management fails
- SmartView+ unstable
- Network drops intermittently

Possible causes:

- Wrong SSID
- Wrong password
- Weak signal
- 2.4/5 GHz coverage issue
- Enterprise network restriction
- DHCP issue
- Interference

Checks:

```
Confirm SSID and password
Check signal strength
Move closer to access point if testing
Check DHCP
Try wired LAN for comparison
Check AP/controller logs if available
```

Fix actions:

- Re-enter Wi-Fi credentials.
- Improve coverage.
- Use LAN for critical signage.
- Check wireless security settings.
- Avoid congested channels if possible.

11.8 Remote Management Not Working

Symptom:

- MagicINFO cannot manage display
- Samsung VXT does not show device online
- Content cannot be pushed
- Display works locally but not remotely

Possible causes:

- Display not registered to platform
- Network offline
- DNS issue
- Gateway issue
- Firewall blocks service
- Wrong account/site assignment
- Firmware outdated
- Time/date issue

Checks:

```
Check display network connection
Check MagicINFO/VXT registration
Check account assignment
Check DNS and gateway
Check firewall access
Check firmware version
```

Fix actions:

- Register or claim display correctly.
- Restore network access.
- Correct DNS/gateway.
- Update firmware.
- Check platform account permissions.
- Use wired LAN for reliability if possible.

11.9 SmartView+ Wireless Sharing Not Working

Symptom:

- Device cannot find display
- Wireless sharing fails
- Screen sharing disconnects
- Lag or poor quality

Possible causes:

- SmartView+ disabled
- Client device unsupported
- Display not on network
- Client and display separated by VLAN/firewall
- Wi-Fi isolation
- Weak signal
- Firmware issue

Checks:

```
Enable SmartView+
Check display network
Check client compatibility
Check Wi-Fi signal
Check VLAN/firewall/client isolation
Restart sharing session
```

Fix actions:

- Enable SmartView+.

- Put devices on an allowed network path.
 - Improve Wi-Fi signal.
 - Disable isolation only if allowed by policy.
 - Update display firmware if needed.
-

11.10 RS-232C Control Not Working

Symptom:

- Control system cannot power display
- Source selection commands fail
- RS-232 commands ignored
- Display does not respond to automation

Possible causes:

- RS232C adapter missing or wrong
- Cable disconnected
- Wrong serial settings
- Wrong command format
- Wrong device ID
- Control processor port mismatch
- Display not in controllable state

Checks:

```
Check RS232C(IN) adapter
Check serial cable
Check control processor port
Verify baud/control settings
Check Samsung command protocol
Check display power state
```

Fix actions:

- Reseat RS-232 adapter.
 - Correct cable and pinout.
 - Match serial settings.
 - Correct command format.
 - Verify control program mapping.
 - Test basic power or source command.
-

11.11 Remote Controller Not Working

Symptom:

- Remote does not control display

- Display does not respond to buttons
- Only close-range control works

Possible causes:

- Dead batteries
- IR sensor blocked
- IR sensor cable not connected
- Wrong remote
- Display not powered
- Strong light interference

Checks:

```
Replace batteries
Aim at IR sensor
Check IR sensor cable
Remove obstruction
Test from closer distance
Check display power
```

Fix actions:

- Replace batteries.
- Connect included IR sensor cable if needed.
- Relocate IR sensor.
- Remove obstruction.

11.12 Picture Quality Problem

Symptom:

- Image is too dim
- Image color looks wrong
- Text is unclear
- Content is stretched
- Flickering or artifacts appear

Possible causes:

- Wrong picture mode
- Wrong brightness settings
- Source resolution mismatch
- Poor cable
- Incorrect aspect ratio
- Low-quality source content
- Environmental lighting issue

Checks:

Check picture settings
Check source resolution
Check aspect ratio
Replace cable
Test another source
Check ambient lighting

Fix actions:

- Adjust picture mode and brightness.
 - Use 3840 x 2160 source where appropriate.
 - Correct aspect ratio.
 - Replace cable.
 - Use high-quality content.
-

11.13 Overheating or Ventilation Issue

Symptom:

- Display feels very hot
- Performance unstable
- Display shuts down unexpectedly
- Long-term reliability concern

Possible causes:

- Vents blocked
- Poor wall clearance
- Installed in hot area
- Indoor ambient conditions unsuitable
- Dust buildup

Checks:

Check ventilation around display
Check wall mount spacing
Check ambient temperature
Check dust and airflow

Fix actions:

- Improve ventilation.
- Keep vents clear.
- Avoid heat sources.
- Clean exterior gently.

- Confirm indoor environment is controlled.
-

11.14 Firmware or Software Issue

Symptom:

- Menus behave incorrectly
- SmartView+ or network features unstable
- Remote management issues persist
- Known bug suspected

Possible causes:

- Outdated firmware
- Platform software mismatch
- Failed update
- Configuration issue

Fix actions:

```
Check firmware version
Update Tizen/web-engine firmware where available
Update MagicINFO/VXT components if used
Restart display after update if required
Retest all sources and management
```

12. Factory Reset and Recovery

Samsung commercial displays provide reset options within the on-screen Tizen settings menu. Specific step-by-step reset instructions were not found in the reviewed official-source manual.

Factory reset may be used when:

- Display is being repurposed
- Configuration is corrupted
- Network settings are incorrect and cannot be repaired
- Source settings are confused
- Remote management must be reconfigured
- Troubleshooting requires a clean state

Before reset:

```
Record current network settings
Record MagicINFO/VXT configuration
Record source settings
Record display orientation
```

Record RS-232 control settings if used
Confirm credentials and platform access are available

After reset:

Run first-time setup
Reconnect LAN or Wi-Fi
Reconfigure MagicINFO or Samsung VXT
Set correct source settings
Reconfigure SmartView+ if used
Re-test HDMI/DisplayPort/USB inputs
Re-test RS-232C control

Use the on-screen Settings menu and Samsung Business support resources for the exact model and firmware version before performing a reset.

13. Maintenance and Best Practices

Recommended practices:

- Keep firmware and Tizen web-engine updated.
- Keep MagicINFO or Samsung VXT updated where deployed.
- Use wired LAN for critical signage when possible.
- Label HDMI, DisplayPort, LAN, USB, and RS-232 cables.
- Document source mapping.
- Document display IP address.
- Keep a record of platform registration.
- Use proper wall mount hardware.
- Maintain ventilation.
- Clean the non-glare panel gently with a soft, dry cloth.
- Avoid harsh chemicals or abrasive cloths.
- Check input sources after changes.
- Test remote management regularly.
- Use Auto Source Switching where appropriate.
- Plan updates outside business hours.
- Power-cycle only when required.
- Keep remote batteries available.
- Check RS-232 control after control-system changes.

Useful maintenance checks:

Check power and display status
Check selected source
Check HDMI/DisplayPort cables
Check LAN or Wi-Fi connection
Check MagicINFO/VXT status

- Check SmartView+
- Check RS-232 control
- Check picture quality
- Check orientation
- Check ventilation
- Check firmware version

14. Quick Reference

Power Check

- Check AC power cord
- Check wall outlet
- Check power strip or breaker
- Check remote batteries
- Check display power indicator

Source Check

- Open Home UI
- Go to Sources
- Select correct HDMI, DisplayPort, USB, or wireless source
- Check source device power

HDMI / DisplayPort Check

- Reseat cable
- Try another cable
- Try another input
- Check source resolution
- Check source output settings

Network Check

- Check LAN cable or Wi-Fi
- Verify IP address
- Check gateway and DNS
- Check MagicINFO/VXT connectivity

SmartView+ Check

- Enable SmartView+
- Check client compatibility
- Check network path
- Check Wi-Fi signal
- Check firewall/client isolation

Remote Management Check

- Check MagicINFO registration
- Check Samsung VXT registration
- Check account/site assignment
- Check DNS and gateway
- Check firewall access

RS-232C Check

- Check RS232C(IN) adapter
- Check serial cable
- Check serial settings
- Check command format
- Check control processor mapping

Picture Check

- Check brightness
- Check picture mode
- Check aspect ratio
- Check source resolution
- Check cable quality

Restart

- Power-cycle display only when required
- Verify selected source after restart
- Verify network and management status

Factory Reset / Recovery

- Use on-screen Tizen Settings menu
- Exact steps were not found in the reviewed official-source manual

Record network, source, and management settings before reset
Reconfigure display after reset
