

Attack Decay Sustain Release

			3 CD	4052		IC/ CD4013												
	Control: Active IN: Outs:					В	Outs:		B INs:				A Outs:			A INs:		
	Pin 9	Pin10		Pin 13	Pin 3	Pin 13	Pin 12	Pin 8	Pin 9	Pin 10	Pin 11	Pin 1	Pin 2	Pin 6	Pin 5	Pin 4	Pin 3	
	В	А	X&Y	X	Υ	Q	Q	S	D	R	CLK	Q	Q	S	D	R	CLK	
	1	0	2	1	0	1	0	Short Pulse at Start	0	0	0	1	0	0	0	0	0	
	0	0	0	Sustain CV	Deccay CV	0	1	0	0	Short Pulse at Start	0	0	1	Short Pulse at Start	0	Short Pulse at Start	0	
	0	0	0	Sustain CV	Deccay CV	0	1	0	0	Short Pulse at Start	0	0	1	0	0	Short Pulse at Start	0	
3	0	1	1	0	Release CV	0	1	0	0	0	0	0	1	0	0	0	0	

IC8 CD40/3												
	(	GATE	Α		(	GATE	В	GATE C				
Pin 1 Pin 2 Pin 8 Pin 9				Pin 3	Pin 6	Pin 11 Pin 12 Pin 13 Pin 10						
IN	IN	IN	OUT	IN	IN	IN	OUT	IN	IN	IN	OUT	
0	0	1	0	1	0	1	0	1	0	0	0	
1	1	1	1	0	1	1	0	1	1	0	0	
0	0	1	0	1	1	1	1	1	0	0	0	
0	1	0	0	1	1	0	0	1	1	1	1	

State Extractor Logic


FLIP\_FLOP\_OUT


TO\_FLIP\_FLOP\_OU


Attack Decay Sustain Release


R120


GND
TO\_SUSTAINING











OSHW LOGO

FLIP\_FLOP\_OUT