

SOP Title:

FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep

1.0 Purpose and scope

This standard operating procedure (SOP) is for the preparation of Agilent SureSelect XT exome sequencing libraries from FFPE at PM-OICR TGL for use on Illumina sequencers.

The modified Agilent protocol uses KAPA Hyper Prep kits for the preparation of pre- and post- capture libraries, employing Agilent SureSelect^{XT} reagents for the hybridization and exome capture steps. The procedure requires 100ng of FFPE DNA as input material and can be used with the following capture libraries:

- SureSelect^{XT} Human All Exon v6 + COSMIC (64Mb)
- SureSelect^{XT} Human All Exon v5 + UTRs (74.6Mb)

Related documents:

- Manufacturer-supplied protocol for library prep and post-capture amplification: *KAPA Hyper Prep Kit for SureSelect*^{XT} *Target Enrichment* (KR1320 v3.17), link to document
- Manufacturer-supplied protocol for hybridization and capture: Agilent SureSelect^{XT} Target Enrichment System for Illumina Paired-End Multiplexed Sequencing Library (Version CO, December 2016), link to document

Related TGL documents:

- YYYY MM DD SAMPLE SUBMISSION FORM PI Lastname Firstname TGL.xls
- SOP_Qubit_Assay_for_Nucleic_Acid_Quantification.doc
- 16_05_11_Kapa_Hyperprep_lot_tracking_sheet.xls
- 17 07 07 Agilent Sureselect XT Library kit lot control.doc
- SOP_TapeStation_4200_V1.0
- SOP_KAPA_Library_Quantification_Illumina_Platforms_V1.0.2_production

Refer to section 5.0 Appendix: design notes for information regarding the modifications and adjustments with respect to the manufacturer-supplied protocols that were incorporated in this SOP.

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2 Page 1 of 10	
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



2.0 Materials

Workspace			
Libr	ary prep room for all the steps prior pre-capture PC	R amplifica	ition
	t-PCR area for the pre-capture PCR amplification and		
Equipment	and associated consumables		
	Covaris M220		
Covaris (DMARK)	Microtube-50 AFAF Fiber screw cap (25 or 250 to	ubes)	PN520166 or PN520167(case of 250)
	Agilent TapeStation 4200		
	Genomic DNA Screen Tape (7 tapes,112 samples)		5067-5365
Agilent	Genomic DNA reagents		5067-5366
	High Sensitivity D1000 Screen Tape (7 tapes,112	High Sensitivity D1000 Screen Tape (7 tapes,112 samples)	
	High Sensitivity D1000 Reagents		5067-5585
Eppendorf	Vacufuge Plus (Speedvac)		022820001
Various	Thermal cycler (i.e. Applied Biosystems Veriti, Bi	oRad T100	, etc)
Medstore	PCR STRIP(8), 0.2ml NEUTRAL, ATT FLAT CAP,120)/pk	72.991.002
ThermoFisher	Dynamag (magnetic rack)		12321D
	Dynamag-96 (96 well magnetic rack)		123331D
Reagent kit	rs		
Dl	KAPA Hyper Prep kit (96 rxns)		7962363001 (KK8504)
Roche	KAPA HiFi HS RM (6.25 mls, for post-capture PCF	l)	7958935001 (KK2602)
	SureSelect Library Prep Kit		
	SureSelect Target Enrichment, Box 1		
	SureSelect Target Enrich. Kit, ILM Ind. Hyb Module Box 2		
Agilent	SureSelect XT Reagent Kit for 96 samples		G9611B
Agnerit	SureSelect XTHuman All Exon V5 +UTR (96rxns)		5190-6213
	or		
	SureSelect XT Human All Exon V6+ COSMIC (96 rxns)		5190-9308
Beckman	AMPure XP beads		A36881 (60 ml)
Coulter/Cedarlane	D		CEC02/40 IV
ThermoFisher	Dynabeads MyOne Streptavidin T1		65602(10 ml)
	1M Tris, pH=8.0, 100 mls		AM9855G
	Qubit dsDNA HS Assay Kit		Q32854
	Qubit Assay Tubes		Q32856
Commonly	used reagents	T -	
	Ethanol anhydrous 100% (brown bottle), case P006EAAN		AN
MedStore/Greenfield	of 12X 500ml		
Specialty Alcohols	Ethanol anhydrous 100%, 4X4L white jugs	P016EA	AN
Madstore	(cleaning only)	14/4503	11
Medstore	Nuclease-free water W4502-1L		IL

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2 Page 2 of 10	
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



3.0 General Guidance:

- When opening a new kit, record all lot numbers in TGL master lot tracking sheet
 (R:\Lot_tracking_forms\17_05_23_Agilent_Sureselect_XT_lot_tracking_sheet.docx, associate all samples to the master lot tracking sheet using a letter key ("A", "B") in sample tracking sheet
- Do not mix and match reagents from multiple kits! Aliquot reagents where appropriate to minimize freeze thaw cycles, indicate freeze thaw with a dot on top of tube
- Before beginning work every day, wipe down all pipetors and bench surfaces with Peroxide wipes, then wipe with 70% ethanol (made from bulk ethanol, 4L)
- Buffers may be heated in Eppendorf thermal block, but ideally within PCR cycler in strip tube
- AMPureXP beads must be allowed to reach room temperature before use (30 mins at room temp)
- Be sure beads are thoroughly bound to magnetic rack when washing, loss of beads will reduce diversity. Before adding ethanol washes to beads, use a 10ul pipette to remove residual supernatant when using multichannel pipetors. This is critical for FFPE samples.
- Wet beads that contain residual ethanol prior to elution in water or RSB will interfere with
 reactions (beads should almost appear to be cracking from dryness). Always add RSB to dry
 beads before lifting from magnetic rack. Dried beads are very electrostatic and can "jump" out
 of the tube and be lost. Always visually confirm that you have re-suspended the dried beads
 entirely.
- Be sure not to carry over beads after elution, if beads do carryover, bind to magnetic rack and transfer again to fresh strip tube
- Record quants, dilutions, and other QC information in individual sample sheet
- Ethanol wash solutions should be made fresh every day and use molecular grade H20 and anhydrous ethanol (brown bottle only!), always use private ethanol and H20 aliquots to minimize risk of contamination between technicians
- When making master mixes a 10% overage should be sufficient
- 10 mM Tris can be made by diluting 100 ul of 1M stock in 9900 ul of molecular grade H20
- Enzyme solutions should be 'flick' mixed and briefly spun (minifuge) down prior to use, buffers should be vortexed and spun down
- Most reactions should be briefly spun to collect material at bottom of reactino well, especially when removed from thermocyclers
- Record all QC steps in original sample submission sheet, not running sample sheet, including MISO LIMS IDs, (LIB, LDI) master lot tracking references, protocol version and include your name so that user/tech can be traced in sample sheet
- Record and highlight all unusual observations, errors, or other issues in sample sheet

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2 Page 3 of 10	
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



4.0 Procedure

Qubit material to verify concentration using Qubit HS dsDNA Assay kit and following SOP_Qubit_Assay_for_Nucleic_Acid_Quantification.docx. If sample concentration is excessively high, dilute stock solution and re-qubit to a reasonable concentration.

Run Agilent Genomic Tapestation and record DIN if sample quantity is sufficient (5-10 ng/ul, 1ul). If sample quantity is low (<100ng), skip this step. Use appropriate concentration, do not go outside of tape concentration recommendation, or DIN will not be accurate.

PRE-PCR AREA

- 1. DNA Shearing (Covaris M220 instrument)
 - a. Use Holder XTU Insert microTUBE 50 (PN500488)
 - b. Use microTUBE-50 AFA Fiber Screw-Cap (PN520166)
 - c. Fill reservoir to appropriate level with AFA water or milliQ water
- 1) Dilute 100 ng of FFPE DNA in 10mM Tris pH 8.0-8.5 to a total volume of 50μ l.
- 2) Transfer sample to Covaris microTUBE 50 AFA tube through septum (Spin down briefly, no bubbles around fiber prior to shearing).
- 3) Load the tube into the sonication chamber, lower tube lever.
- 4) Run protocol: 50ul_shear_300bp (Peak Incident Power:75; Duty factor:10%; Cycles/burst: 200; Treatment Time: 90 seconds; Temp 20°C) (both FFPE and fresh frozen).
- 5) Briefly spin micro tube containing sheared DNA and transfer sheared DNA by "twisting off" cap and aliquoting into PCR tubes strip.

SAFE STOP POINT. Place in -20°C.

2. KAPA HyperPrep End Repair and A-Tailing (ER & AT)

Allow AMPure XP beads to warm to room temp for 30 minutes before use! Proceed immediately to ligation after incubation.

- 1) Prepare "ER & AT Mix" mastermix and keep on ice.
- 2) Add 10ul of the mix to the 50µl of sheared DNA.
- 3) Incubate in a thermal cycler as follows using program "End Repair":

20°C for 30 min; 65°C for 30 min; 4°C HOLD.

Heated lid: 85°C.

ER & AT Mix	1x
ER & AT Buffer	7
ER & AT Enzyme Mix	3
Total Mix>	10
Fragmented FFPE DNA	50
Total Reaction>	60

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2	Page 4 of 10
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



3. KAPA HyperPrep Adapter Ligation

(Minimize freeze thaw of adapters, ie 3-5X max)

- 1) Prepare "AL Mix" mastermix and keep on ice.
- 2) Add 50µl of the mix to the 60µl of ER & AT product.
- 3) Incubate in a thermal cycler as follows using program "Ligation":

20°C for 15 min Heated lid: off; proceed immediately to next step.

Al Mix	1x
Ligation buffer	30
DNA ligase	10
SureSelectXT Adapter Oligo (top stock)	10
Total Mix>	50
ER & AT product	60
Total Reaction>	110

4. Post-Ligation Cleanup

- 1) Add 88uL AMPureXP beads to each 110uL ligation reaction product.
- 2) Pipette to mix and incubate at room temperature for 15 minutes.
- 3) Place on magnet and allow solution to clear (5 minutes); Remove supernatant without disturbing beads. Use 10ul pipette to remove residual supernatant.
- 4) Add 200uL 80% EtOH while still on magnet and let sit for 30 seconds, then remove ethanol. Repeat for a total of 2 washes. Carefully remove and discard the supernatant.
- 5) Dry the beads at room temperature for 15 min, or until ethanol has evaporated (beads almost cracking).
- 6) Re-suspend beads in <u>23µl</u> of nuclease-free water and incubate for 2 min to elute the DNA. Visually confirm resuspension is complete.
- 7) Place the tubes on a magnet and incubate 5 minutes until the liquid is clear. Transfer <u>20ul</u> of the clear supernatant to a new tube.

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2 Page 5 of 10	
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



1x

25

1.25

1.25

2.5

30

20

50

Pre-capture PCR Mix

SureSelect Primer (brown cap)

SureSelect Ilmn rev (clear cap)

Total Mix-->

Total Reaction--->

2x KAPA HiFi mix (

PCR-grade water

Adapter-ligated library

5. KAPA HyperPrep Pre-capture Library Amplification

- 1) Prepare "Pre-capture PCR mix" mastermix and keep on ice
- 2) Add 30µl of the mix to the 20µl of Adapter-ligated library.

Move to Post PCR Work Area

Incubate in a thermal cycler as follows and run program "PCR":

98°C for 45 sec; 12 cycles {98°C for 15 sec; 60C for 30 sec; 72°C for 30 sec}; 72°C for 1 min; 4°C HOLD**

Heated lid: 105°C ** note FFPE annealing and extension time is not the same as standard protocol!!!

6. Post-amplification Cleanup

- 1) Add 50μL AMPureXP beads to each 50 μL PCR reaction product.
- 2) Pipette to mix and incubate at room temperature for 15 minutes.
- 3) Place on magnet and allow solution to clear (5 minutes); Remove supernatant without disturbing beads. Use 10ul pipette to remove residual supernatant.
- 4) Add 200uL 80% EtOH while still on magnet and let sit for 30 seconds, then remove ethanol. Repeat for a total of 2 washes. Carefully remove and discard the supernatant.
- 5) Dry the beads at room temperature for 15 min, or until all of the ethanol has evaporated.
- 6) Re-suspend beads in $34\mu l$ of nuclease-free water, or RSB and incubate for 2 min to elute the DNA. Visually confirm resuspension.
- 7) Place the tubes on a magnet and incubate until the liquid is clear (5 minutes). Transfer 32ul of the clear supernatant to a new tube.

SAFE STOP POINT. Place in -20°C.

7. Assess Quality and Quantity of the Pre-capture Library

- Use Qubit HS DNA assay to quantify pre-capture library following SOP_Qubit_Assay_for_Nucleic_Acid_Quantification.docx. A total of 500ng is required for further processing. If yield is <400ng, repeat library prep and pool material for hyb.
- 2) Optional: Use TapeStation High Sensitivity D1000 to verify that the library has an average <u>region</u> size of approx. 360bp with minimal adapter contamination. If adapter contamination, note in sample sheet.

8. Hybridize DNA Samples to Capture Library

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2 Page 6 of 10	
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	

OICR Ontario Institute for Cancer Research

PM-OICR TGL

1) SpeedVac 500ng of DNA library at <45°C for approx. 35 min to reduce volume to 3.4ul, or until no liquid is present at the bottom of the tube. If completely dry, re-suspend in 3.4 ul of nuclease free water, repeatedly aliquot suspension along lower half of tube to ensure all material is solubilized of wall of tubes after drying. DO NOT OVERDRY!

2) Prepare master mixes for Hyb. Buffer Mix (A), RNase Inhibitor Mix (B) and Block Mix reactions*:

Hyb. Buffer Mix (A)	1x	RNase Inhibitor Mix (B)	1x	Capture Mix (A+B)	1x
Hyb1 (orange cap)	6.63	RNase block	0.5	Hyb Buffer Mix (A)	13
Hyb2 (red cap)	0.27	Nuclease-free water	1.5	RNase Inhibitor Mix (B)	2
Hyb3 (yellow cap)	2.65			Capture Library (Probes)	5
Hyb4 (black cap)	3.45				
Total Mix>	13	Total Mix>	2	Total Mix>	20

*minimum of 4 rxn master mix to prevent pipetting error, upon new kit receipt, ALWAYS aliquot Capture library (probes) into 6 top stock tubes (approx. 82 ul each tube) for storage in -80°C. Make sure no precipitates are visible in solutions prior to making master mixes.

Block Mix	1x
Block1 (green cap)	2.5
Block2 (blue cap)	2.5
ILM Block3 (brown cap)	0.6
Total Mix>	5.6

- 3) Combine Hyb Buffer Mix (A) and RNase Inhibitor Mix (B) to create Capture Mix (A+B).
- 4) To each 3.4µl of KAPA DNA library (step 1), add 5.6 ul of Block Mix, pipette to mix.
- 5) Incubate in a thermal cycler as follows using "HYB" program:

95°C for 5 min; 65°C HOLD (at least 5 min)

Heated lid: 105°C

6) While maintaining DNA + block mix at 65° C in the thermal cycler, add $20\mu l$ of Capture Mix (A+B), pipette to mix.

1x
9
20
29

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2	Page 7 of 10
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



7) Continue the incubation in a thermal cycler as follows:

65°C HOLD (at 16 hours)

Heated lid: 105°C

9. Washing of Captured Exome

- 1) Prewarm SureSelect Wash Buffer 2 at 65°C (Eppendorf block or PCR strip tube)
- 2) Prepare streptavidin-coated magnetic beads as follows:
 - i. Bring Dynabeads MyOne Streptavidin T1 magnetic beads to room temperature for 30 min.
 - ii. Re-suspend beads by vortexing vigorously.
 - iii. Dispense a volume of 50μl (x the number of captures) of beads in an Eppendorf tube.
 - iv. Perform a total of 3 washes in 200μl (x the number of captures) of Binding Buffer.
 - v. After removing the supernatant from the last wash, re-suspend in 200μ l (x the number of captures) of Binding Buffer.
- 3) While maintaining the hybridization tube at 65°C, <u>add hybridization reaction</u> to 200µl of washed streptavidin beads using a multichannel pipette, mix well by slowly pipetting up and down and cap the wells. (NB add hyb to beads, not beads to hyb, order is important)
- 4) Incubate on a plate mixer (1400-1800rpm) at room temperature for 30 min.
- 5) Briefly spin, collect beads on a magnetic stand and discard the supernatant.
- 6) Re-suspend the beads in $200\mu l$ of Wash Buffer 1, mix by pipetting up and down and incubate at room temperature for 15 min.
- 7) Briefly spin, collect beads on a magnetic stand and discard the supernatant.
- 8) Wash the beads with Wash Buffer 2 (pre-warmed at 65°C, and maintain this temperature throughout the wash process to ensure stringency):
 - i. Re-suspend beads in 200µl, mix well by pipetting up and down and cap the wells.
 - ii. Incubate at 65°C for 10 minutes.
 - iii. Capture the beads using a magnetic separator and discard the supernatant.
 - iv. Repeat the process for a total of 3 washes in Wash Buffer 2 (pre-warmed at 65°C).
- 9) Re-suspend the beads in 19μ l of nuclease-free water (Keep bead +H20 mix for on bead amplification!), and maintain on ice.

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2	Page 8 of 10
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	



10. On-bead Post-capture Amplification

- 1) Prepare "Post-capture PCR Mix" master mix.
- 2) Add 5μl of Indexing primer (unique to each library) to library bead suspension from step 9.
- 3) Add 26 μl of "Post-capture PCR mix" to library bead suspension and mix rxn by pipetting up and down.
- 4) Incubate bead suspension in a thermal cycler as follows using program "PCR 2":

98°C for 45 sec; 10cycles {98°C for 15 sec; 60°C for 30 sec; 72°C for 30 sec}; 72°C for 1 min; 4°C HOLD**

Heated lid: 105°C ** note FFPE annealing and extension time is not the same as standard protocol!!!

11	Time!	Claamin
TT.	rinai	Cleanup

- 1) Add 90μL AMPureXP beads to each 50 μL PCR reaction product.
- 2) Pipette to mix and incubate at room temperature for 15 minutes.
- 3) Place on magnet and allow solution to clear (5 minutes); remove supernatant without disturbing beads. Use 10ul pipette to remove residual supernatant.
- 4) Add 200uL 80% EtOH while still on magnet and let sit for 30 seconds, then remove ethanol. Repeat for a total of 2 washes. Carefully remove and discard the supernatant.
- 5) Dry the beads at room temperature for 15 min, or until all of the ethanol has evaporated.
- 6) Re-suspend beads in 34µl of nuclease-free water, or RSB and incubate for 2 min to elute the DNA. Visually confirm resuspension.
- 7) Place the tubes on a magnet and incubate 5 minutes until the liquid is clear. Transfer 32ul of the clear supernatant to a new tube.

SAFE STOP POINT. Place in -20°C.

12. Assess Quality and Quantity of the Post-capture Library

- 1) Use Qubit HS dsDNA assay using TGL SOP to quantify post-capture library (SOP_Qubit_Assay_for_Nucleic_Acid_Quantification.docx.).
- 2) Use High Sensitivity D1000 screen tape and record average library size distribution (set region to 100bp- 1000bp). Average library size will be used to size correct the library after RT-qPCR quantification, and is used in LIMS sample IDs. Record Tapestation file ID in sample tracking sheet.

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2	Page 9 of 10
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	

Post-capture PCR mix	1x
2x KAPA HiFi mix (KK2602)	25
Post-cap. Fwd primer (orange cap)	1
Total Mix>	26
Indexing primer (unique)	5
Library-bead suspension	19
Total Reaction>	50





5.0 Revision History

Version Number	Date (yyyy-mm-dd)	History of change
0.1	2017-03-20	First draft by Alberto Leon
1.2	2017-05-03	Edited by Dax
1.2.1	2017-05-03	Reviewed edited by Kayla
1.3	2017-06-30	Final Edits
1.3.1	2017-07-07	DT added lot control sheet
1.3.2	2017-07-17	Error corrected in oligo adapter in ligation
		2.5ul changed to correct volume of 10ul

SOP Title:	FFPE Agilent SureSelect XT + KAPA Hyper Prep Human Exome Library Prep	
Version:	V1.3.2	Page 10 of 10
Technician approvals	Kayla Marsh 170524, Alberto Leon	
Approved by:	Dax Torti	
Date:	170717	