



Components List

1.1Acrylic Plates
















The acrylic plates are fragile, so please be careful when assembling them in case of breaking.

The acrylic plate is covered with a layer of protective film. You need to remove it first.

Some holes in the acrylic may have residues, so you need to clean them before the use.






1.2 Machinery Parts

M2 Nut X11	M3 Nut X7	M3 Lock Nut X3	M2.5*11 Copper Standoff X2	M2*12 Screw
M2.5*7 Screw X5	M3*5 Screw X4	M3*8 Screw X18	M3*10 Screw X5	M3*18 Screw X1
M3*10 Countersun k Head Screw X2	M3*8 Copper Standoff X1	M3*15 Nylon Standoff X4	M2*18 Screw	M3*30 Nylon Standoff X5
M3*40 Nylon Standoff X2	Sucking disc component Cap Nut X4 Sucking Disc X4		51108 Bearing	




1.3 Electronic Parts










1.4 Tools







1.5 The following parts need to be purchased by yourself:

