



Model: Microflex® Advance™ Device Type: Microphone

TABLE OF CONTENTS

GENERAL INFORMATION	2
INITIAL SETUP	3
PLUGIN CONTROLS (Setup)	4
PLUGIN CONTROLS (Lights)	
PLUGIN CONTROLS (Presets)	9
PLUGIN CONTROLS (Channels / Automix / Loudspeaker)	10
PLUGIN CONTROLS (IntelliMix)	11
KNOWN ISSUES	12
ADDITIONAL INFORMATION	10





GENERAL INFORMATION	
Q-SYS PLUGIN NAME	Shure Microflex® Advance™
VERSION	1.0
AUTHORED BY	Control Concepts, Inc.
SUMMARY	Use this Q-SYS plugin to control Shure Microflex® Advance™ devices in Q-SYS Designer. Settings include gain, mute behavior, status LEDs, and preset recall as well as monitor network information and other device settings.
GENERAL NOTES	 This plugin is designed to support the following models: MXA-MUTE MXA901 MXA902 MXA902 MXA920 Controls will be disabled when they cannot be used for device control. When automatic coverage is on, there aren't any pre- or post-gate channel gain controls. There is 1 gain fader for the automix output. If the Loudspeaker is set to off in the device settings, the plugin Loudspeaker controls will be disabled.
DEVICE USED FOR TESTING	Q-SYS Core 110f (v9.9.0)





Model: Microflex® Advance™

Device Type: Microphone

INITIAL SETUP	
PROPERTIES	Model: Select the model the plugin will connect to. Valid models are: MXA-MUTE MXA710-2FT MXA710-4FT MXA901 MXA902 MXA900 MXA920 [Default] Meter Update Rate (ms): Set the rate for metering updates. Default is 500ms. Valid values are 100-10000. It is recommended to keep this value at 500ms or slower. Debug Level: Indicates the specificity level of messages that appear in the debug window. The options include: 1-Off: No messages will be printed. [Default] 2-Device Communication: Only messages related to commands going to/coming from physical devices will be printed. 3-Troubleshooting: All internal messages will be printed. Log Debug Messages: Indicates whether to also save any messages that are printed to the debug window to the internal Q-SYS processor's logs. [Default: False]
ESTABLISHING CONNECTION	 During design time, set up your programming to input the IP address and port information of your device. Connection will attempt automatically. During run time, select the device to connect to from the auto-discovery dropdown box. The plugin can only discover devices on the local network. During run time, keep the auto-discovery dropdown selection on "Manual" and enter the IP address and port into the fields provided on the plugin. All methods are persistent ways of connecting and will persist through reboots and design pushes.





PLUGIN CONTROLS (Setup)	
Auto-Discovery	Provides a list of "Manual" and discovered Shure devices on the local network that match the model of this plugin. Each discovered device will only show if the model matches the model type of the plugin. Select a device from the dropdown menu to connect and control. [Both String]
Manual-Entry IP Address	If Auto-Discovery is set to "Manual" this address will be used for device connection. [Both String]
Port	Set the port the plugin will use to connect to the device. [Both String]
Status	Indicates the plugin status. [Output String]
Is Communicating	Indicates the plugin established a connection with the device. [Output Boolean]
Is Initialized	Indicates the plugin has synced all states from the device. [Output Boolean]
Control Network IP Address	Reports the IP address of the device connected. [Output String]
Control Network MAC Address	Reports the MAC address of the device connected. [Output String]
Control Network Web Link Access	Reports the address the device can be connected to in a browser. [Output String]
Audio Network IP Address	Indicates the audio network IP address. [Output String]
Audio Network Subnet Mask	Indicates the audio network subnet mask. [Output String]





Audio Network Gateway	Indicates the audio network gateway.
	[Output String]
Dante Device Name	Indicates the Dante device name.
Danie Device Name	fo
	[Output String]
Control Network Device Name	Indicates the control network device name.
	[Output String]
Device Model	Indicates the model.
	[Output String]
Serial Number	Indicates the serial number.
	[Output String]
Firm	Indicates the firmware version.
Firmware	
	[Output String]
Encryption	Indicates audio encryption state. True means audio encryption is on.
	[Output Boolean]
Automatic Coverage	Indicates automatic coverage is true. This is only available on the MXA920.
	[Output Boolean]
Reboot Device	Triggers a device reboot.
	[Input Boolean]
n	Toggles the device mute and reflects the current state.
Device Mute	
	[Both Boolean]
Identify	Flashes device status LEDs and reflects the current state.
	[Both Boolean]





Model: Microflex® Advance™

Device Type: Microphone

Mute Control Mode	Sets the mute control mode of the button. (MXA-MUTE only) Valid values are: Toggle Push-to-talk Push-to-mute
	[Both String]





PLUGIN CONTROLS (Lights)	
Brightness	Set the brightness of the LED on the device. Valid values are 0-5. [Both Number]
Unmute Behavior	Set the behavior of the LED on the device in the unmute state. Valid values are: Off Flashing On [Both String]
Unmute Color	Set the color of the LED on the device in the unmute state. Valid values are: Red Orange Gold Yellow Yellow Yellow Green Green Turquoise Powder Blue Cyan Sky Blue Blue Purple Light Purple Violet Orchid Pink White
Mute Behavior	Set the behavior of the LED on the device in the mute state. Valid values are: Off Flashing On [Both String]





Model: Microflex® Advance™

Device Type: Microphone

Mute Color	the color of the LED on the device in the mute state. id values are: Red Orange Gold Yellow Yellow Green Turquoise Powder Blue Cyan Sky Blue Blue Purple Light Purple Light Purple Orchid Pink White
------------	--





PLUGIN CONTROLS (Presets)	
Preset # Name	Indicates the name of the associated preset number. [Output String]
Preset # Recall	Trigger to recall the associated preset number. [Output Boolean]





Model: Microflex® Advance™ Device Type: Microphone

PLUGIN CONTROLS (Channels / Automix / Loudspeaker) Indicates the current channel name. Read only. Channel (# or Automix or Loudspeaker) [Output | String] Controls the gain of the channel and reports the current gain. Valid values are 0 - 1400 Channel (# or Automix or Loudspeaker) **Gain Fader** [Both | Number] Controls the gain of the channel and reports the current gain in dB. Valid values are -110.0 to Channel (# or Automix or Loudspeaker) **Gain Text** [Both | String] Trigger to increment the channel gain by 0.1 dB. Channel (# or Automix or Loudspeaker) **Gain Increment** [Input | Boolean] Trigger to decrement the channel gain by 0.1 dB. Channel (# or Automix or Loudspeaker) **Gain Decrement** [Input | Boolean] When Channel Metering is enabled, this reports the meter of this channel. Channel (# or Automix or Loudspeaker) Meter [Output | Number] Toggles the mute of this channel and reports the current mute state. Channel (# or Automix or Loudspeaker) Mute [Both | Boolean] Indicates the current channel Dante name. Read only. Channel (# or Automix) Dante Name [Output | String] Toggle to enable/disable metering of channel, automix, and loudspeaker. Meter Channel-Automix-Loudspeaker **Enable**

[Both | Boolean]





PLUGIN CONTROLS (IntelliMix)	
IntelliMix Name	Indicates the current IntelliMix channel name. Read only.
	[Output String]
IntelliMix Gate Out Signal	Indicates if this IntelliMix Channel is actively open.
intellivity date out signal	[Output Boolean]
IntelliMix Gain Fader	Controls the gain of the IntelliMix channel and reports the current gain. Valid values are 0 – 1400.
	[Both Number]
IntelliMix Gain Text	Controls the gain of the IntelliMix channel and reports the current gain in dB. Valid values are -110.0 to 30.0.
	[Both String]
IntelliMix Gain Increment	Trigger to increment the IntelliMix channel gain by 0.1 dB.
	[Input Boolean]
IntelliMix Gain Decrement	Trigger to decrement the IntelliMix channel gain by 0.1 dB.
	[Input Boolean]
IntelliMix Meter	When IntelliMix Metering is enabled, this reports the meter of this IntelliMix channel.
	[Output Number]
Meter IntelliMix Enable	Toggle to enable/disable metering of Channel, Automix, and Loudspeaker.
	[Both Boolean]





Model: Microflex® Advance™ Device Type: Microphone

KNOWN ISSUES

• The MXA710-2FT and MXA710-4FT IntelliMix metering does not work properly on firmware v 1.5.16.

ADDITIONAL INFORMATION

Change Log	v1.0 - Initial Release
Support	Company: Shure Email: support@shure.com