Method
Author: Beckman Coulter
Description:

Start

Instrument Setup
Deck: Multichannel
Pause to confirm setup.
Verify that the pod is set up in its default configuration.
Items:
P1: BC190F named Empty. Discard the tips to "<TipBox>". When done, move the box to "<Home>". Use these tips 0 times.
P10: Nothing
P11: CellCarrier_96 named Plate 2 with known volume: 105 µL of Water in all wellsperkin_elmer_cellplate_lid
P12: Nalgene_Reservoir named Media with known volume: 100000 µL of Water in all wells
P13: Nothing
P14: CellCarrier_96 named Plate 3 with known volume: 105 µL of Water in all wellsperkin_elmer_cellplate_lid
P2: Nothing
P3: ubottom_96_3359 named Waste with known volume: 0 µL of Water in all wells
P4: FullySkirted_Eppendorf_PCR_96 named Lenti with known volume: 70 µL of Water in all wells
P5: Costar_96_3896 named Rearranged with known volume: 0 µL of Water in all wells
P6: CellCarrier_96 named Plate 1 with known volume: 105 µL of Water in all wellsperkin_elmer_cellplate_lid named Cell Plate Lid
P7: Nothing
P8: Nothing
P9: Nothing
Pelt1: Nothing
Shuttle_S8: Nothing
TL1: BC190F named Tips-rearrangments. Discard the tips to "<TipBox>". When done, move the box to "<Home>". Use these tips "999" times.
TL2: BC190F named Tips-stamper. Discard the tips to "<TipBox>". When done, move the box to "<Home>". Use these tips "999" times.
TL3: Nothing
TR1: Nothing
WS1: Water
WS2: Water

Comment
Description:
Add media to rearranged plate
Comment:
Add media to rearranged plate

Multichannel Load Tips
Load tips of type "Tips-stamper" onto pod "Pod1".

Transfer
Using Pod1, execute the following transfer:
From: Media, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 0.2 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 0.3 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 50µL/s
  Mix Aspirate Height: 0.3 mm from the bottom
  Mix Dispense Speed: 50µL/s
  Mix Dispense Height: 0.3 mm from the bottom
  Mix Count: 3

```
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 20 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Rearranged, 147µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 10 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 1 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
Multichannel Unload Tips
Unload the tips from pod "Pod1".
--------------------------------------------------------------------------------
Move Labware
Move the entire stack of labware at "TL2" to "P8" using pod "Pod1" holding the labware
with "A1 near" the gripper.
--------------------------------------------------------------------------------
```

```
Comment
Description:
Begin rearranging BR quadrant of LV into TL of new plate
Comment:
Begin rearranging BR quadrant of LV into TL of new plate
--------------------------------------------------------------------------------
Begin Using Select Tips Step
Begin Using Select Tips on Pod1
 Use "TL3" to rearrange tips.
--------------------------------------------------------------------------------
Advanced Load Tips
column: 7
row: 5
TipType: BC190F
TipsLocation: Tips-rearrangments
_Commented: False
--------------------------------------------------------------------------------
Aspirate With Select Tips Step
 Aspirate 40 µL of Well Contents from Lenti which holds a FullySkirted_Eppendorf_PCR_96.
 With the first tip hitting column 7 and row 5.
  Use the CZJS LV mix 1.5 technique.
--------------------------------------------------------------------------------
Dispense With Select Tips Step
 Empty the tips into the Costar_96_3896 at Rearranged.
 With the first tip hitting column 1 and row 1.
 Use the following custom technique:
    Use the following pipetting template: MC Pipetting Cells Conditioning Volume
Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 0.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 50 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Advanced Unload Tips
column: 1
row: 1
TipsLocation: Empty
_Commented: False
--------------------------------------------------------------------------------
End Using Select Tips Step
```

```
--------------------------------------------------------------------------------
Comment
Description:
Begin diluting BL quadrant into TR of lentivirus
Comment:
Begin diluting 1 quadrant of lentivirus
--------------------------------------------------------------------------------
Begin Using Select Tips Step
Begin Using Select Tips on Pod1
 Use "TL3" to rearrange tips.
--------------------------------------------------------------------------------
Advanced Load Tips
column: 1
row: 5
TipType: BC190F
TipsLocation: Tips-rearrangments
--------------------------------------------------------------------------------
Aspirate With Select Tips Step
 Aspirate 40 µL of Well Contents from Lenti which holds a FullySkirted_Eppendorf_PCR_96.
 With the first tip hitting column 1 and row 5.
  Use the CZJS LV mix 1.5 technique.
--------------------------------------------------------------------------------
Dispense With Select Tips Step
 Empty the tips into the Costar_96_3896 at Rearranged.
 With the first tip hitting column 7 and row 1.
 Use the following custom technique:
    Use the following pipetting template: MC Pipetting Cells Conditioning Volume
Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 0.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 50 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Advanced Unload Tips
column: 7
row: 1
TipsLocation: Empty
--------------------------------------------------------------------------------
End Using Select Tips Step
--------------------------------------------------------------------------------
```

```
Comment
Description:
Begin diluting TL quadrant into BR of lentivirus
Comment:
Begin diluting 1 quadrant of lentivirus
--------------------------------------------------------------------------------
Begin Using Select Tips Step
Begin Using Select Tips on Pod1
 Use "TL3" to rearrange tips.
--------------------------------------------------------------------------------
Advanced Load Tips
column: 7
row: 1
TipType: BC190F
TipsLocation: Tips-rearrangments
--------------------------------------------------------------------------------
Aspirate With Select Tips Step
 Aspirate 40 µL of Well Contents from Lenti which holds a FullySkirted_Eppendorf_PCR_96.
 With the first tip hitting column 1 and row 1.
  Use the CZJS LV mix 1.5 technique.
--------------------------------------------------------------------------------
Dispense With Select Tips Step
 Empty the tips into the Costar_96_3896 at Rearranged.
 With the first tip hitting column 7 and row 5.
 Use the following custom technique:
    Use the following pipetting template: MC Pipetting Cells Conditioning Volume
Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 0.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 50 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Advanced Unload Tips
column: 1
row: 5
TipsLocation: Empty
--------------------------------------------------------------------------------
End Using Select Tips Step
--------------------------------------------------------------------------------
Comment
```

```
Description:
Begin diluting TR quadrant into BL of lentivirus
Comment:
Begin diluting 1 quadrant of lentivirus
--------------------------------------------------------------------------------
Begin Using Select Tips Step
Begin Using Select Tips on Pod1
 Use "TL3" to rearrange tips.
--------------------------------------------------------------------------------
Advanced Load Tips
column: 1
row: 1
TipType: BC190F
TipsLocation: Tips-rearrangments
--------------------------------------------------------------------------------
Aspirate With Select Tips Step
 Aspirate 40 µL of Well Contents from Lenti which holds a FullySkirted_Eppendorf_PCR_96.
 With the first tip hitting column 7 and row 1.
  Use the CZJS LV mix 1.5 technique.
--------------------------------------------------------------------------------
Dispense With Select Tips Step
 Empty the tips into the Costar_96_3896 at Rearranged.
 With the first tip hitting column 1 and row 5.
 Use the following custom technique:
    Use the following pipetting template: MC Pipetting Cells Conditioning Volume
Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 0.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 50 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Advanced Unload Tips
column: 7
row: 5
TipsLocation: Empty
--------------------------------------------------------------------------------
End Using Select Tips Step
--------------------------------------------------------------------------------
Comment
Description:
```

```
Aspirate half the media from all plates and stamp lentivirus
Comment:
Aspirate half the media from all plates and stamp lentivirus
--------------------------------------------------------------------------------
Move Labware
Move the entire stack of labware at "P8" to "TL2" using pod "Pod1" holding the labware
with "A1 near" the gripper.
--------------------------------------------------------------------------------
Multichannel Load Tips
Load tips of type "Tips-stamper" onto pod "Pod1".
--------------------------------------------------------------------------------
Begin Holding Labware Step
Holding the top "1" plate(s) at "P6" using pod "Pod1" with "A1 near" the gripper...
--------------------------------------------------------------------------------
Transfer
Using Pod1, execute the following transfer:
From: Plate 1, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 2.5µL/s
  Mix Aspirate Height: -0.5 mm from the bottom
  Mix Dispense Speed: 2.5µL/s
  Mix Dispense Height: -0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 5 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Waste, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: 96MC Moving Mix THP1 Template
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
```

```
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 50 µL/s
    Blowout Volume: 5 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 2 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
Transfer
Using Pod1, execute the following transfer:
From: Rearranged, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 1.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 1.5 mm from the bottom
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Plate 1, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
```

```
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 10 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 1 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
------------------------------------------------------------------------------
End Holding Labware
------------------------------------------------------------------------------
Begin Holding Labware Step
Holding the top "1" plate(s) at "P11" using pod "Pod1" with "A1 near" the gripper...
------------------------------------------------------------------------------
Transfer
Using Pod1, execute the following transfer:
From: Plate 2, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 2.5µL/s
  Mix Aspirate Height: -0.5 mm from the bottom
  Mix Dispense Speed: 2.5µL/s
  Mix Dispense Height: -0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 5 µL
```

```
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Waste, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: 96MC Moving Mix THP1 Template
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 50 µL/s
    Blowout Volume: 5 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 2 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
Transfer
Using Pod1, execute the following transfer:
From: Rearranged, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 1.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
```

```
  Mix Dispense Height: 1.5 mm from the bottom
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Plate 2, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 10 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 1 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
End Holding Labware
--------------------------------------------------------------------------------
Begin Holding Labware Step
Holding the top "1" plate(s) at "P14" using pod "Pod1" with "A1 near" the gripper...
--------------------------------------------------------------------------------
```

Transfer
Using Pod1, execute the following transfer:
From: Plate 3, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 2.5µL/s
  Mix Aspirate Height: -0.5 mm from the bottom
  Mix Dispense Speed: 2.5µL/s
  Mix Dispense Height: -0.5 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 5 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Waste, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: 96MC Moving Mix THP1 Template
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 50 µL/s
    Blowout Volume: 5 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 50 µL/s

```
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 2 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
Transfer
Using Pod1, execute the following transfer:
From: Rearranged, section 1, Well Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 1.52835
  Calibration Slope: 1.02925
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 25µL/s
  Mix Aspirate Height: 1.5 mm from the bottom
  Mix Dispense Speed: 25µL/s
  Mix Dispense Height: 1.5 mm from the bottom
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: True
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 2.5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

To: Plate 3, 50µL, section 1, Tip Contents
Use the following custom technique:
  Use the following pipetting template: MC Pipetting Cells Conditioning Volume Calibration
  Calibration Offset: 0.522517707
  Calibration Slope: 1.109715355
  Minimum Pipetting Height: 1.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
```

```
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 10 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense up to 1 time(s) per draw.
Keep the current tips
Keep the tips when finished.
Do not split transfer volumes that exceed tip capacity.
Stop when finished with Destinations.
--------------------------------------------------------------------------------
End Holding Labware
--------------------------------------------------------------------------------
Multichannel Unload Tips
Unload the tips from pod "Pod1".
--------------------------------------------------------------------------------
Comment
Description:
CHECK PIPETTING TECHS: VOLs, BOs, CONDITIONING VOLs
--------------------------------------------------------------------------------
Finish
Clear current instrument setup of all labware.
Clear current device setup of all labware.
Unload disposable tips from all pods.
Move all pods and grippers to their park locations.
Clear all global variables.
--------------------------------------------------------------------------------
```