Method
Author: Beckman Coulter
Description:

Start
Define the following values for this method:
  numberofplates = 1

Instrument Setup
Deck: Multichannel
Pause to confirm setup.
Verify that the pod is set up in its default configuration.
Items:
P1: Nothing
P10: CellCarrier_96 named AP5 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid
P11: CellCarrier_96 named AP6 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid
P12: Nalgene_Reservoir named PBS with known volume: 100000 µL of Water in all wells
P13: Nalgene_Reservoir named 8% PFA with known volume: 50000 µL of Water in all wells
P14: Nothing
P2: Nothing
P3: BCUpsideDownTipBoxLid named TipTouch with known volume: 0 µL of Water in all wells
P4: CellCarrier_96 named AP1 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid
P5: CellCarrier_96 named AP2 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid
P6: CellCarrier_96 named AP3 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid
P7: Nothing
P8: Costar_96_3896 named Stains with known volume: 175 µL of Water in all wells
P9: CellCarrier_96 named AP4 with known volume: 150 µL of Water in all wellsperkin_elmer_cellplate_lid named Cell Plate Lid
Pelt1: Nothing
Shuttle_S8: Nothing
TL1: BC190F. Discard the tips to "<TipBox>". When done, move the box to "<Home>". Use these tips "999" times.
TL2: Nothing
TL3: Nothing
TR1: Nothing
WS1: Water
WS2: Water

Comment
Description:
INSTRUCTIONS
Comment:
15ml dead volume for the 8% PFA
10m is not enough

TAKE LID OFF STAINS
Don't add PFA yet!!!

Pause
Pause everything while waiting for a user response to the following prompt: "Remove lid from Stains

Start timer for 30 min when Stains are added to P01

Don't add PFA yet".

Multichannel Load Tips
Load tips of type "BC190F" onto pod "Pod1".

Loop
Loop from "number" = "1" to "=numberofplates", incrementing by "1".

```
Begin Holding Labware Step
Holding the top "1" plate(s) at "="AP"&number" using pod "Pod1" with "A1 near" the
gripper...
--------------------------------------------------------------------------------
Aspirate
Using "Pod1", aspirate "100" µL of "Well Contents" from section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.8 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Dispense
Using "Pod1", dispense "98" µL of "Tip Contents" to section 1 of the "WashStation" labware
at "WS2" using the following technique:
  Use the following pipetting template: Fluotics Wash Station Method
  Calibration Offset: 0
  Calibration Slope: 1
  Minimum Pipetting Height: 10 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 10 mm from the top
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
```

```
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Dispense
Using "Pod1" empty tips into section 1 of the "BCUpsideDownTipBoxLid" labware at
"TipTouch" using the following technique:
  Use the following pipetting template: MC Low-Volume Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 50µL/s
  Mix Aspirate Height: -2 mm from the liquid
  Mix Dispense Speed: 50µL/s
  Mix Dispense Height: -2 mm from the liquid
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2 µL/s
    Dispense Cutoff Velocity: 10 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Aspirate
Using "Pod1", aspirate "50" µL of "Well Contents" from section 1 of the "Costar_96_3896"
labware at "Stains" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.5 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 0.5 mm from the bottom
  Mix: True
  Mix Aspirate Speed: 20µL/s
  Mix Aspirate Height: 0.5 mm from the bottom
  Mix Dispense Speed: 20µL/s
  Mix Dispense Height: 0.5 mm from the bottom
  Mix Count: 5
  Mix Volume: 50 µL
  Operation speed: 50µL/s
  Tip Touch: False
```

```
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 25 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Dispense
Using "Pod1", dispense "50" µL of "Tip Contents" to section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting Cells
  Calibration Offset: 0.154061
  Calibration Slope: 1.104148
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Blowout: True
  Follow Liquid: True
  Height: 1.2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
End Holding Labware
--------------------------------------------------------------------------------
End Loop
--------------------------------------------------------------------------------
Move To
Move "Pod1" to deck position "WS2" at offset (0,0).
--------------------------------------------------------------------------------
Pause
Pause everything while waiting for a user response to the following prompt: "Wait for
Staining timer to expire

Pour 8% PFA into Reservoir (25mL min)
```

```
Start timer for 15 min when 8% PFA is added to P01".
--------------------------------------------------------------------------------
Loop
Loop from "number" = "1" to "=numberofplates", incrementing by "1".
--------------------------------------------------------------------------------
Begin Holding Labware Step
Holding the top "1" plate(s) at "="AP"&number" using pod "Pod1" with "A1 near" the
gripper...
--------------------------------------------------------------------------------
Aspirate
Using "Pod1", aspirate "50" µL of "Well Contents" from section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.8 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
Dispense
Using "Pod1", dispense "48" µL of "Tip Contents" to section 1 of the "WashStation" labware
at "WS2" using the following technique:
  Use the following pipetting template: Fluotics Wash Station Method
  Calibration Offset: 0
  Calibration Slope: 1
  Minimum Pipetting Height: 10 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 10 mm from the top
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: False
  Override Liquid Type Settings
```

    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense
Using "Pod1" empty tips into section 1 of the "BCUpsideDownTipBoxLid" labware at "TipTouch" using the following technique:
  Use the following pipetting template: MC Low-Volume Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 50µL/s
  Mix Aspirate Height: -2 mm from the liquid
  Mix Dispense Speed: 50µL/s
  Mix Dispense Height: -2 mm from the liquid
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 10 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Aspirate
Using "Pod1", aspirate "50" µL of "Well Contents" from section 1 of the "Nalgene_Reservoir" labware at "8% PFA" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.3 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 0.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s

```
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 25 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

------------------------------------------------------------------------------
Dispense
Using "Pod1", dispense "50" µL of "Tip Contents" to section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting Cells
  Calibration Offset: 0.154061
  Calibration Slope: 1.104148
  Minimum Pipetting Height: 1 mm
  Prewet: False
  Blowout: True
  Follow Liquid: True
  Height: 1.2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

------------------------------------------------------------------------------
End Holding Labware
------------------------------------------------------------------------------
End Loop
------------------------------------------------------------------------------
Move To
Move "Pod1" to deck position "WS2" at offset (0,0).
------------------------------------------------------------------------------
Pause
```

Pause everything while waiting for a user response to the following prompt: "Wait for timer to expire".

Loop
Loop from "number" = "1" to "=numberofplates", incrementing by "1".

Begin Holding Labware Step
Holding the top "1" plate(s) at "="AP"&number" using pod "Pod1" with "A1 near" the gripper...

Aspirate
Using "Pod1", aspirate "100" µL of "Well Contents" from section 1 of the "CellCarrier_96" labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.6 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1.2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense
Using "Pod1" empty tips into section 1 of the "Nalgene_Reservoir" labware at "8% PFA" using the following technique:
  Use the following pipetting template: MC Low-Volume Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 50µL/s
  Mix Aspirate Height: -2 mm from the liquid
  Mix Dispense Speed: 50µL/s
  Mix Dispense Height: -2 mm from the liquid
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False

  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Aspirate
Using "Pod1", aspirate "150" µL of "Well Contents" from section 1 of the
"Nalgene_Reservoir" labware at "PBS" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.3 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 0.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 25 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense
Using "Pod1", dispense "150" µL of "Tip Contents" to section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting Cells
  Calibration Offset: 0.154061
  Calibration Slope: 1.104148
  Minimum Pipetting Height: 0.6 mm
  Prewet: False
  Blowout: True
  Follow Liquid: True
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s

```
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
End Holding Labware
--------------------------------------------------------------------------------
End Loop
--------------------------------------------------------------------------------
Loop
Loop from "number" = "1" to "=numberofplates", incrementing by "1".
--------------------------------------------------------------------------------
Begin Holding Labware Step
Holding the top "1" plate(s) at "="AP"&number" using pod "Pod1" with "A1 near" the
gripper...
--------------------------------------------------------------------------------
Aspirate
Using "Pod1", aspirate "150" µL of "Well Contents" from section 1 of the "CellCarrier_96"
labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.6 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: True
  Height: 1.2 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: True
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 2.5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
```

```
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

------------------------------------------------------------------------------
Dispense
Using "Pod1", dispense "148" µL of "Tip Contents" to section 1 of the "WashStation"
labware at "WS2" using the following technique:
  Use the following pipetting template: Fluotics Wash Station Method
  Calibration Offset: 0
  Calibration Slope: 1
  Minimum Pipetting Height: 10 mm
  Prewet: False
  Blowout: False
  Follow Liquid: False
  Height: 10 mm from the top
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 100µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 50 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

------------------------------------------------------------------------------
Dispense
Using "Pod1" empty tips into section 1 of the "BCUpsideDownTipBoxLid" labware at
"TipTouch" using the following technique:
  Use the following pipetting template: MC Low-Volume Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.5 mm
  Prewet: False
  Blowout: True
  Follow Liquid: False
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 50µL/s
  Mix Aspirate Height: -2 mm from the liquid
  Mix Dispense Speed: 50µL/s
  Mix Dispense Height: -2 mm from the liquid
  Mix Count: 3
  Mix Volume: 20 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 10 µL/s
    Blowout Volume: 10 µL
    Blowout Delay: 0 ms
```

    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 10 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Aspirate
Using "Pod1", aspirate "150" µL of "Well Contents" from section 1 of the "Nalgene_Reservoir" labware at "PBS" using the following technique:
  Use the following pipetting template: MC Pipetting
  Calibration Offset: 0.154061
  Calibration Slope: 1.014148
  Minimum Pipetting Height: 0.3 mm
  Prewet: False
  Aspirate Blowout: True
  Follow Liquid: False
  Height: 0.5 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 0 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 0 mm from the bottom
  Mix Count: 1
  Mix Volume: 10 µL
  Operation speed: 50µL/s
  Tip Touch: False
  Trailing Air Gap: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 25 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 5 µL/s
    Dispense Cutoff Velocity: 150 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

Dispense
Using "Pod1", dispense "150" µL of "Tip Contents" to section 1 of the "CellCarrier_96" labware at "="AP"&number" using the following technique:
  Use the following pipetting template: MC Pipetting Cells
  Calibration Offset: 0.154061
  Calibration Slope: 1.104148
  Minimum Pipetting Height: 0.8 mm
  Prewet: False
  Blowout: True
  Follow Liquid: True
  Height: 1 mm from the bottom
  Mix: False
  Mix Aspirate Speed: 100µL/s
  Mix Aspirate Height: 2 mm from the bottom
  Mix Dispense Speed: 100µL/s
  Mix Dispense Height: 5 mm from the bottom
  Mix Count: 4
  Mix Volume: 20 µL
  Operation speed: 50µL/s

```
  Tip Touch: False
  Override Liquid Type Settings
    Trailing Air Gap Volume: 0 µL
    Aspirate Delay: 0 ms
    Aspirate Speed: 5 µL/s
    Blowout Volume: 2 µL
    Blowout Delay: 0 ms
    Prewet Overage: 0 µL
    Prewet Delay: 0 ms
    Dispense Delay: 0 ms
    Dispense Speed: 2.5 µL/s
    Dispense Cutoff Velocity: 5 µL/s
    Tip Touch Height: -1 mm from the top
    Tip Touch Angle: 90
    Tip Touch Speed: 100 %
    Tip Touch Delay: 0 ms

--------------------------------------------------------------------------------
End Holding Labware
--------------------------------------------------------------------------------
End Loop
--------------------------------------------------------------------------------
Finish
Clear current instrument setup of all labware.
Clear current device setup of all labware.
Unload disposable tips from all pods.
Move all pods and grippers to their park locations.
Clear all global variables.
--------------------------------------------------------------------------------
```