

NORDSTROM RACK – TURNKEY PROTOTYPE

SECTION 030133 – CONCRETE SLAB PATCHING

3.1 VAPOR RETARDER

- A. Place, protect, and repair sheet vapor retarder according to ASTM E1643 and manufacturer's written instructions.
- B. Place sheet vapor retarder below slab at location contiguous to adjacent existing vapor retarder.
- C. Lap joints 6 inches and seal penetrations with manufacturer's recommended tape. Provide tie-in at existing vapor retarder to provide for continuous coverage.

3.2 REINFORCING

- A. Place, support, and secure reinforcement against displacement. See Structural Drawings.
- B. Locate reinforcing splices not indicated on the drawings at points of minimum stress.
- C. Infill/Trench/Block-Out Dowels:
 - 1. Dowel into existing slab at minimum 18 inches on center but in not less than 2 places along each side of infill/trench/block-outs.
 - 2. Drill and epoxy dowels into existing slab to achieve a 3 inch embedment at mid-point of slab thickness.

3.3 PLACING CONCRETE

- A. Provide an aggregate base course matching existing base material, composition and thickness.
- B. Place over an aggregate base course in accordance with ACI 301.
- C. Bonding Agent: Mix thoroughly and apply strictly in accord with the manufacturer's instructions; do not use when ambient temperature is below 45 degrees F (7 deg.C). Place concrete in contact immediately while bonding agent is still tacky.
- D. Finishes: Unless indicated otherwise on the Drawings provide the following:
 - 1. Finish concrete slabs level and even with existing floor.
 - 2. Full trowel finish interior floor slab surfaces, unless specified otherwise.
 - 3. Light steel trowel finish interior floor slab surfaces scheduled to receive tile.
- E. Curing: Moisture cure all concrete for a minimum of 7 days, unless approved or specified otherwise.

3.4 INSTALLATION OF BRASS MARKERS

- A. Identify the location where the marker will be placed in the concrete.
- B. Drill a hole into the concrete.
- C. Insert and secure marker in place with mortar or adhesive.
- D. Place plug deep enough into concrete so top of marker does not protrude above the concrete.

END OF SECTION