

RIDGELINE TRAIL SERIES - INSTALLATION GUIDE

Tools you will need: a 7/16" wrench, a 7/16" socket with ratchet, and a helper. Installation takes about 30 minutes. No drilling is required.

Step 1: Unpack and inspect. Lay the panel on a soft blanket. Leave the protective film on until installation is complete.

Step 2: Attach the mounting brackets to the cart's front roof struts using the bolts, washers, and nylon lock nuts from the hardware kit. Place a rubber isolator pad between each bracket and the strut. Hand-tighten only.

Step 3: With your helper holding the panel, align the panel's pre-cut holes with the bracket slots. Insert the thumb-knob latches through the panel and brackets.

Step 4: Center the panel so the gap is even on both sides. Tighten the strut bolts to 8 ft-lb. Do not overtighten; overtightening can crack the panel at the mounting holes.

Step 5: Tighten both thumb-knob latches by hand until snug. Test the fold-down motion once, then return the panel upright.

Step 6: Remove the protective film from both sides.

After the first 25 miles of driving, re-check that all bolts are snug.