




Arhitektura ALU - 8 bit




Booth Radix-2



Non-restoring divider datapath



Central Unit FSM



S ₀	: store-initiale	0000
S ₁	: store-citire-x	0001
S ₂	: store-citire-Y	0010
S ₃	: store-citire-op	0011
S ₄	: em-add	0100
S ₅	: em-sub	0101
S ₆	: em-mul	0110
S ₇	: em-div	0111
S ₈	: lim-mul	1000
S ₉	: lim-dire	1001
S ₁₀	: load-result	1010
S ₁₁	: done	1011