Signal	Wire ID	Wire Status	Pattern A	Edge A	Cursor A	-1ms	-800us	-600us	-400us	-200us	T+20.988ms ↓	+200us	+400us	+600us	+800us	+1ms
Data0	DO	L	×	t	1											
Data1	D1	L	Х		0											
- RS232 Example				10.5		1		$\overline{}$	(0	X V. X	0 >-	-(i) X	FR :		- 1	1
Data0	DO	L	X	t	1											

CLK1 Freq: 0Hz Interval A->B: 2.8468ms

Interval T->C: -1.71ms

D1 Transitions A->B: 92

NRES TEC d0=a2 d1=b2

10/7/2016 4:27:31 PM