



(1) ___" x ___" x ___" REQ'D

All dimensions are in inches			
A X B X C	Part #	"F"	"H"
Size	Part #	"F"	"H"
6 x 3 x 3	1000-6196	9	4 1/2
6 x 4 x 3	1000-6197	9	4 1/2
6 x 4 x 6	1001-9877	11	8
6 x 5 x 3	1000-6199	9	4 1/2
8 x 4 x 3	1000-6230	11	4 1/2
8 x 4 x 4	1000-6231	11	6
8 x 5 x 3	1000-6232	11	4 1/2
8 x 5 x 4	1000-6233	11	6
8 x 5 x 6	1001-3782	11	8
8 x 6 x 3	1000-6234	11	4 1/2
8 x 6 x 4	1000-6235	11	6
10 x 5 x 4	1000-6275	12	6
10 x 5 x 6	1001-9878	12	8
10 x 6 x 4	1000-6277	12	6
10 x 6 x 6	1000-6279	12	8
10 x 8 x 4	1000-6281	12	6
10 x 8 x 6	1000-6282	12	8
12 x 6 x 6	1000-6305	14	8
12 x 6 x 8	1000-6306	14	8
12 x 8 x 4	1000-6307	14	6
12 x 8 x 6	1000-6308	14	8
12 x 8 x 8	1000-6310	14	8
12 x 10 x 6	1000-6311	14	8
12 x 10 x 8	1000-6312	14	8
14 x 8 x 6	1000-6328	16	8
14 x 8 x 8	1000-6329	16	8
14 x 10 x 8	1000-6330	16	8
14 x 12 x 8	1001-9879	16	8
16 x 8 x 8	1001-6665	18	8

Flanges Meet ANSI Standard 125# Flange Drilling.
 "F" dimension $\pm 1/8$ ". Consult Neptune~Benson™ on specific fits.
 Install eccentric reducers with flat up, as detailed.
 Material: Fiberglass

