PROXY CalibrationMarker

Print at 100% / Actual Size. Never ’Fit to page’.

TOP EDGE: toward the pins



BOTTOM EDGE: toward you (front)

This line must measure exactly 50 mm. If not, check the print scale.

Cut along the dashed line, then trim to the marker’s black border.

Matte paper or matte sticker only: gloss causes glare under classroom lights.

Place it in the sync-dock corner guides, black notch at top-left as read from the front.