PROXY Diorama calibration markers (LEFT + RIGHT)

Print at 100% / Actual Size. Never 'Fit to page'.

TOP EDGE: toward the model



LEFT: front-left corner

TOP EDGE: toward the model



RIGHT: front-right corner

This line must measure exactly 50 mm. If not, check the print scale.

1. Trim each marker exactly along its black border (no white margin).
2. Place both on the table in front of the diorama, top edges against the marble base's front face, upright as read from the front (black notch at top-left).
3. LEFT marker: left edge in line with the base's left side.
   RIGHT marker: right edge in line with the base's right side.
4. Matte paper or matte sticker only.