App Inventor + IoT: read button status with Micro:bit I/O pins




Level: advanced

This tutorial will help you work with App Inventor + IoT and read the status of a button connected to a micro:bit controller.

source .aia

Pairing with Micro:bit

First, you will need to pair your phone or tablet to the micro:bit controller, using these directions. Your device must be paired with the micro:bit in order for the app to work.



Hardware list

In this project, we are going to detect whether a button (which is connected to Micro:bit) is pressed using App Inventor. When that button is pressed, the bee icon on screen will change to a random position.


Here are the components you need for this project:

- BBC micro:bit dev board, 1
- breadboard, 1
- wires, 3
- potentiometer, 1




Micro:bit	potentiometer
GND	right pin (grey wire)
P0	middle pin (green wire)
3V	left pin (red wire)

Note: potentiometer is a non-polarized component, which means the difference to connect potentiometer **left** pin to MCU board's 5V pin (another pin to GND pin) is that when you rotate potentiometer shaft clockwise, the pin value will change in opposite way than to connect its **right** pin to MCU board's 5V pin.



Finish as below, let's take a look:



Or you can use extension board, like **DFRobot's BOSON extension board**:



App Inventor

This app will move a imageSprite randomly when you press the button connected to micro:bit's P0 pin. Technically speaking, App Inventor is asking micro:bit to report its pin status and this is where we connect the button to. First, log into MIT App Inventor site and create a new project.


Designer

You should complete the <u>App Inventor + IoT Basic Connection</u> <u>tutorial</u> to make a basic connection to the micro:bit device. If you prefer, you can download the completed .aia file <u>here</u>.

The remaining steps all build off of the the starter code for Basic Connection tutorial and .aia.

First, we need to add the necessary extension.

- In the Palette window, click on Extension at the bottom and then on "Import extension" and click on "URL".
 - Paste in this URL:
 http://iot.appinventor.mit.edu/assets/com.bbc.mi
 cro:bit.profile.aix
- Add a Microbit_IOpin extension to your app by dragging it onto the Viewer, set its BluetoothDevice to "BluetoothLE1"(Don't forget!).




Let's add more components to our app to read the magnetometer status.

From the Drawing and animation palette, add a
 Canvas component. Set its width to "Fill

- parent", height to "200 pixels".
- From the Drawing and animation palette, add an ImageSprite component, set its Picture to some cute image (no bigger than the canvas).
- Add a label component, set its FontSize to 40 and Text to "pin data". We will update the micro:bit P0 pin value here.
- Add one more label component, set its FontSize to 40 and Text to "0, 0". We will update the latest position of the imageSprite here.
- From Sensor palette, add a Clock component, set its TimerInterval to 100, which means its timer will trigger 10 times per second.

After some adjusting, your designer should look similar to this. It doesn't have to be exactly the same. Feel free to modify the component properties, such as background color, position and text size.



Blocks

STEP 1: Request updates when connected

In the **BluetoothLE1.Connected** event, we show messages to tell user that we are connected with micro:bit and set micro:bit's pin status as "digital input". Since we are going to read the button status in this project. Check the **Microbit_lo_Pin.ConfigurePin** method, please specify the **pinNumber** to 0 (means P0 pin of micro:bit and set the **analog** field to **false** and the input field to **true**. And don't forget to set Clock.TimerEnabled to true, which means we are using the Clock component to read micro:bit pin status periodically.

```
when BluetoothLE1 v. Connected

do set Label1 v. Text v to v "Status: Connected "

set ListBLE v. Visible v to false v

call Microbit_lo_Pin1 v. ConfigurePin

pinNumber v

analog false v

input true v

set Clock1 v. TimerEnabled v to true v
```


Let's let a look of Microbit_lo_Pin.WritePinConfiguration method, it has three parameters: pinNumber (pin index), analog (true to analog, false to digital) and input (true to input, false to output).

This is to set micro:bit's P0 pin as **digital output**. You can connect component like LED to this pin. For micro:bit I/O pins detail please check this link: http://microbit.org/guide/hardware/pins/

```
call Microbit_lo_Pin1 · WritePinConfiguration


pinNumber 
analog 
false ·

input 
false ·
```



And this is to set micro:bit's P2 pin as analog input. You can connect component like potentiometer to this pin.





STEP2: read button status periodically

In Clock.Timer event, we call Microbit_Io_Pin.ReadInputPinData method to read a specified micro:bit pin data, which is P0 in our case. Since we've set Clock's TimerInterval property to 100, this means we are reading micro:bit pin data every 100 millisecond (10 times per second).

Note: you must configure the pin as **digital input** (in STEP1) to read its data correctly.

```
when Clock1 v .Timer

do call Microbit_lo_Pin1 v .ReadInputPinData
```

STEP3a:

Microbit_Io_Pin.PinDataReceived event will be called after the pin data is read successfully, and it will return a list (pin index, pin data) as a result. Here we use a pressed variable and use a select list item method to get pin data and show it on the label. pressed variable will be 1 when the button is pressed and will be 0 when the button is released.

```
when Microbit_lo_Pin1 v .PinDataReceived

IO_Pin_Data

do set global pressed v to select list item list get IO_Pin_Data v index 2

set Label_pindata v . Text v to get global pressed v
```

STEP3b: move ImageSprite to random location when button is pressed

To make our app more interactive, we will move the ImageSprite randomly every time the button is pressed (ImageSprite.MoveTo method).

```
then call [mageSprite] • .MoveTo

x random integer from 1 to 320

y random integer from 1 to 200
```

STEP3c: update ImageSprite location on label

We also show the latest ImageSprite position on a label.

STEP4:

Finally, we put things from STEP3a to 3b together, finished as below:

```
when Microbit_lo_Pin1 .PinDataReceived
(IO_Pin_Data)
    set global pressed v to select list item list
                                              get (IO_Pin_Data 🔻
                         Text ▼ to
    set Label_pindata •
                                      get global pressed •
    🔯 if
                get global pressed 🔻
           call ImageSprite1 ▼ .MoveTo
                                         random integer from
                                                                       320
                                         random integer from (
                                                              1 to
                                                                       200
                                  Text ▼ to ( 🌣 join 🖟
           set Label_coordinate •
                                                          ImageSprite1 • X •
                                                          ImageSprite1 🔻
```

STEP5: Disconnect from micro:bit

You can disconnect from micro:bit by clicking the **ButtonDisconnect**. This will reset the app to its initial state to wait for next connect request.


```
when ButtonDisconnect v.Click
do call BluetoothLE1 v.Disconnect
call Microbit_lo_Pin1 v.StopPinDataUpdates

when BluetoothLE1 v.Disconnected
do set Clock1 v.TimerEnabled v to false v
set Label1 v.Text v to false v
```

Tips

Your app should now be working! Make sure you have paired the Bluetooth on your Android device to your micro:bit. Then test it out by connecting your micro:bit device using the MIT AI2 Companion (if you haven't already) or installing it by .apk.

Press the button, you will see the imageSprite flying on the screen and there will be an **1/0** changing according to button status and the latest imageSprite position on the corresponding labels.



Brainstorming

- 1. Modify this project, play one sound effect when the button is pressed and play another sound effect when the button is released.
- 2. Add one more potentiometer to control the ImageSprite to move along the Y-axis.