

AN3108 Application note

STLM75 firmware library for the STM32F10x

Introduction

This application note describes the firmware library implementing the STLM75 interface for the STM32F10xxx (STM32F101x, STM32F103x, STM32F105x, STM32F107x) microcontroller.

This library is a firmware package which contains a collection of routines, data structures and macros covering the features of the STLM75 temperature sensor device. The firmware library allows the STLM75 sensor to be used in the user application without the need for an in-depth study of STLM75 registers and I²C read/write operation steps. As a result, using the firmware library saves significant time which would otherwise be spent in coding, while reducing the application development and integration costs.

The firmware library source code is developed in 'Strict ANSI-C' (relaxed ANSI-C for the example application). Writing the whole library in 'Strict ANSI-C' makes it independent from the software toolchain. In addition, the firmware architecture is developed in separate layers and the HAL (hardware abstraction layer) makes it independent from the microcontroller used in the final application.

Even though the firmware library source code is developed in 'ANSI-C', the code architecture follows an OOP (object oriented programming) approach.

Section 1 describes document and library rules.

Section 2 highlights the features of the STLM75 sensor and explains its hardware interface with a master device microcontroller (STM32 in this case).

Section 3 and 4 highlight the features of the firmware library and describe its architecture and its exported APIs (application programming interfaces) in detail.

Section 5 contains an example application source code describing how to configure and use the library.

October 2010 Doc ID 16793 Rev 1 1/44

Contents

1	Document and library rules		
	1.1	Acronyms 5	
2	STL	M75 temperature sensor6	
	2.1	Sensor introduction 6	
	2.2	Interfacing the sensor with the microcontroller	
3	STL	M75 library	
	3.1	Introduction 8	
	3.2	Library package 8	
	3.3	Library architecture 9	
		3.3.1 API layer9	
		3.3.2 HAL layer	
4	STL	M75 library firmware11	
	4.1	API layer firmware overview	
	4.2	HAL Layer firmware overview	
		4.2.1 HAL types	
		4.2.2 HAL functions	
5	Exa	mple application	
	5.1	main.c	
6	Refe	erences 42	
7	Revi	ision history	

AN3108 List of tables

List of tables

Table 1.	List of abbreviations	5
Table 2.	Signal names and pin descriptions	7
Table 3.	Function description format	
Table 4.	NewTempSensor API function	. 12
Table 5.	DelTempSensor API function	. 13
Table 6.	Init API function	. 19
Table 7.	Reset API function	. 20
Table 8.	SetI2C_Settings API function	. 20
Table 9.	SetSignals	. 21
Table 10.	GetSignals	. 22
Table 11.	SetRegister	. 23
Table 12.	GetRegister	. 24
Table 13.	SetConfiguration	. 25
Table 14.	GetConfiguration	. 25
Table 15.	GetTemperature	. 26
Table 16.	SetTempHysteresis	. 27
Table 17.	GetTempHysteresis	. 27
Table 18.	SetTempOverLimit	. 28
Table 19.	GetTemperatureOverLimit	. 29
Table 20.	TS_ConfigSignal	. 31
Table 21.	TS_InitI2C_Peripheral	
Table 22.	TS_Resetl2C_Peripheral	. 32
Table 23.	TS_CheckEventWithTimeout	. 33
Table 24.	TS_FillDataFromRegister	. 33
Table 25.	TS_FillRegisterFromData	. 34
Table 26.	TS_SetPointerRegister	. 35
Table 27	Document revision history	43

List of figures AN3108

List of figures

Figure 1.	Logic diagram	6
Figure 2.	Typical 2-wire interface connection diagram	7
Figure 3.	Firmware library project files	9
Figure 4.	Firmware library architecture	0
Figure 5.	Firmware library API and types	3
Figure 6.	Application project files	6

1 Document and library rules

This document uses the conventions described in the sections below.

1.1 Acronyms

The following table lists the acronyms used in this document.

Table 1. List of abbreviations

Acronym	Meaning
API	Application programming interface
HAL	Hardware abstraction layer
MCU	Microcontroller unit
l ² C	Inter-integrated circuit
OOP	Object oriented programming

2 STLM75 temperature sensor

2.1 Sensor introduction

The STLM75 is a high-precision digital CMOS temperature sensor IC with a sigma-delta temperature-to-digital converter and an I 2 C-compatible serial digital interface. It is targeted at general applications such as personal computers, system thermal management, electronics equipment, and industrial controllers, and is packaged in the industry standard 8-lead TSSOP and SO8 packages. The device contains a band-gap temperature sensor and 9-bit ADC which monitor and digitize the temperature to a resolution up to 0.5 °C. The STLM75 is typically accurate to ± 3 °C - max over the full temperature measurement range of -55 °C to 125 °C with ± 2 °C accuracy in the -25 °C to + 100 °C range (max). The STLM75 is factory-calibrated and requires no external components to measure temperature.

Refer to the STLM75 (Digital temperature sensor and thermal watchdog) datasheet for more information.

2.2 Interfacing the sensor with the microcontroller

The STLM75 has a simple 2-wire I²C-compatible digital serial interface which allows the user to access the data in the temperature register at any time. It communicates via the serial interface with a master controller which operates at speeds up to 400 kHz. Three pins (A0, A1, and A2) are available for address selection, and enable the user to connect up to 8 devices on the same bus without address conflicts. In addition, the serial interface gives the user easy access to all STLM75 registers to customize the operation of the device.

Figure 2 shows how the SMT32F10xxx microcontroller (master device) must be connected to the STLM75 device.

Refer to the STLM75 datasheet for more information.

SDA⁽¹⁾
SCL
A₀
A₁
A₂

GND

STLM75

AM05751v1


Figure 1. Logic diagram

Note: SDA and OS/INT are open drain.

Table 2. Signal names and pin descriptions

Pin	Sym	Type/direction	Description
1	SDA	Input/output	Serial data input/output
2	SCL	Input	Serial clock input
3	OS/INT	Output	Over-limit signal/interrupt alert output
4	GND	Supply ground	Ground
5	A ₂	Input	Address2 input
6	A ₁	Input	Address1 input
7	A ₀	Input	Address0 input
8	V _{DD}	Supply power	Supply voltage (2.7 V to 5.5 V)

Figure 2. Typical 2-wire interface connection diagram



Note: SDA and OS/INT are open drain

STLM75 library AN3108

3 STLM75 library

3.1 Introduction

The STLM75 firmware library is fully developed in 'Strict ANSI-C' following an OOP approach. This means the final application using this library uses an instance of a temperature sensor object (TempSensor), and uses it according to its public methods and properties. The TempSensor is a structure containing public properties (data fields) and methods (functions pointers). The OOP encapsulation feature is assured.

The final application can create more than one TempSensor instance, and each instance can be matched with a different STLM75 temperature sensor assembled on the board. Therefore, the same library can be used to manage more temperature sensors simultaneously without communication and data conflict problems.

The library may be included in the final application as a library file (STLM75.a) and used as a black box through its exported public API, or can be included in the final application as source files (.c and .h), if the user wants to debug the library itself, or if it's necessary to change the HAL functions in order to port the library on an alternative microcontroller to the STM32F10xxx.

3.2 Library package

The library was developed using the IAR EWARM 5.20 and the related workspace/project files are included in the delivered package. As all the firmware is written in 'Strict ANSI-C', the library porting on another toolset doesn't require any change in the library.

The library folder contains all the subdirectories and files that make up the core of the library:


- The included sub-folder contains the firmware library header files. They don't need to be modified by the user:
 - TempSensorObj.h: API layer file; this contains the Temperature Sensor Object structure description in terms of methods and properties; The API functions are declared in this file.
 - TempSensorTypes.h: API layer file; this contains all the defined types used by TempSensorObj.xxx files and related to the STLM75 temperature sensor.
 - TempSensorHal.h: HAL layer file; this contains all the Temperature Sensor functions declaration whose implementation depends on the MCU used (STM32 for this delivery). The final user should change these files in order to reuse this STLM75 library with other microcontrollers
 - TempSensorHalTypes.h HAL layer file; this contains all the Temperature Sensor types mapped on the used MCU library types (STM32 for this delivery). The final

AN3108 STLM75 library

user should change this type mapping in order to reuse this STLM75 library with other microcontrollers

- The source sub-folder contains the firmware library source files. They don't need to be modified by the user:
 - TempSensorObj.c: API layer file; this contains the exported public API (Application Programming Interface) and the related private internal functions. No direct reference to the Hardware and Micro firmware library occur in this file.
 - TempSensorHal.c: HAL layer file; this contains all the temperature sensor functions implementation whose source code depends on the MCU used (STM32 for this delivery). The final user should change these file in order to reuse this STLM75 library with other microcontrollers
 - The STM32_Include sub-folder contains the STM32F10xxxV2.0.3 firmware library included files. If the final user wants to use another microcontroller library version, replace this folder and check the HAL types and the microcontroller library function calls inside the HAL layer files (TempSensorHal.h, TempSensorHalTypes.h, TempSensorHal.c)
- EWARMv5 sub-folder contains the IAR EWARM 5.20 workspace and project files:
 - STLM75_Lib.eww: The IAR workspace file
 - STLM75_Lib.ewp: The IAR project file





3.3 Library architecture

The library architecture is devised and developed in two separate layers:

- API layer
- HAL layer

This layer architecture improves the code reusability splitting the application programming interface code (fully portable and reusable) from the hardware abstraction layer code (hardware dependent and written onto the STM32F10xxx libraries).

3.3.1 API layer

The application programming interface layer allows the final application to use the library as a black-box. The library firmware encapsulation feature and exported API allow full control of

STLM75 library AN3108

the STLM75 temperature sensor without the need of an in-depth study of sensor registers and I²C read/write operation steps.

The API layer includes the following files:

- TempSensorObj.h
- TempSensorTypes.h
- TempSensorObj.c;

See Section 4.1 for a more detailed description.

3.3.2 HAL layer

The hardware abstraction layer is directly built on the specific microcontroller firmware library and allows the built-upon layers, like the API layer, to implement its functions without the need of an in-depth study of the microcontroller used. This improves the library code reusability and guarantees easy portability on other microcontrollers.

The HAL layer includes the following files:

- TempSensorHal.h
- TempSensorHalTypes.h
- TempSensorHal.c

See *Section 4.2* for a more detailed description.

Main Application Application Layer Temperature Sensor Layer TempSensor STLM75 Library Types Object TempSensor HAL STLM75 Temperature Sensor Hardware dependent App HAL STM32F10xxx Libraries I2C STM32 Microcontroller HW AM05754v1

Figure 4. Firmware library architecture

4 STLM75 library firmware

This section describes the API and HAL layer implementation. Each library firmware function is described in detail. API and HAL layer functions are fully described. An example of how to use API functions is included. No example for HAL functions is provided because the final application should manage the STLM75 temperature sensor through the API layer functions only, without any direct access to the HAL functions.

The functions are described in the following format:

Table 3. Function description format

Name	Description
Function name	The name of the peripheral function
Function prototype	Prototype declaration
Behavior description	Brief explanation of how the function is executed
Input parameter {x}	Description of the input parameters
Output parameter {x}	Description of the output parameters
Return value	Value returned by the function
Required preconditions	Requirements before calling the function
Called functions	Other library functions called

4.1 API layer firmware overview

The application programming interface layer allows the final application to easily use the STLM75 temperature sensor. An OOP approach is used, making it possible for the application to create and use one or more instances of a TempSensor object.

The TempSensor structure is seen by the application as an object with encapsulate properties and methods. All read/write operations on the temperature sensors are executed through this object. It is an advanced structure containing:

- Properties as data fields
- Methods as functions pointers

In this way, each API function belongs to the related TempSensor object instance and more instances, and then more temperature sensors, can be managed without any conflicts.

In addition, the library exports two public API global functions in order to create/destroy a TempSensor structure instance:

- NewTempSensorObj function
- DelTempSensorObj function

NewTempSensorObj API global function

Table 4 describes the NewTempSensorObj function:

Table 4. NewTempSensor API function

Name	Description	
Function name	NewTempSensorObj	
Function prototype	TempSensorType* NewTempSensorObj (void)	
Behavior description	Create and initialize a new TempSensor object (a C structure)	
Input parameter {x}	None	
Output parameter {x}	None	
Return value	The created object pointer or null if the object cannot be created	
Required preconditions	None	
Called functions	No API/HAL layers functions;	

Example:

Once a TempSensor object instance is created using the NewTempSensorObj function, the TempSensor object itself provides all its features through its internal function pointers.

Figure 2 shows the TempSensor object properties and methods in detail, which the final application can use to interact with the temperature sensor.

12/44 Doc ID 16793 Rev 1

DelTempSensorObj API global function

Table 5 describes the DelTempSensorObj function:


Table 5. DelTempSensor API function

Name	Description
Function name	DelTempSensorObj
Function prototype	TS_ErrStatus DelTempSensorObj (TempSensorType** ppTempSensor)
Behavior description	Destroy the Object internal members and free the memory allocated when NewTempSensorObj function is called.
Input parameter {x}	ppTempSensor - Object pointer
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj must have been called before
Called functions	No API/HAL layers functions;

Example:

```
TempSensorType* pObjTempSensor;
TS_ErrStatus errStatus;
...
errStatus = DelTempSensorObj(pTempSensorObj);
```

Figure 5. Firmware library API and types



TempSensorObj API types/properties/functions

This section describes the TempSensor structure, all its exported API functions and all the defined types. See *Figure 2*.

Below you can find a description of the defined types used by the TempSensor object source code and a description of its properties and methods. Except for TempSensorType, all API layer types are defined in the TempSensorTypes.h file.

TempSensorType type

The TempSensorType is defined in the following TempSensorObj.h file. The final TempSensor object is an instance of this defined structure.

The following described structure type can be considered as an OOP-class including private and public properties and public methods.

All the structure fields with a prefix name of 'm_' can be considered as private properties. This means these structure fields must not be directly accessed by the final application and Getxxx methods should be used instead. Clearly the final application could access these private members, but it should NEVER do so.

The final application must interact with this library using the following public properties and methods only, as described in *Figure 2* and in the following sections.

```
#define TEMP_SENSOR_OBJ
                               /* Temperature Sensor definition */ \
/* PRIVATE PROPERTIES */ \
TS u8
                    m_Configuration;
TS_TemperatureType m_Temperature;
TS TemperatureType m TempHysteresis;
TS_TemperatureType m_TempOverLimit;
TS_RegistersType
                    m_Registers;
TS I2C SettingsType m I2C Settings;
/*
                     */\
/* PUBLIC PROPERTIES */ \
                                  /* The Micro/STLM75 signals */ \
TS SignalsType
                    TimeoutTicks; /* Timeout in ticks */ \
TS_u32
/*
                     */\
/* PUBLIC METHODS
                     */\
TS ErrStatus
                    (*Init)
                                         (TempSensorType*);
TS ErrStatus
                    (*Reset)
                                         (TempSensorType*);
TS ErrStatus
                    (*SetI2C_Settings)
                                         (TempSensorType*,
TS_I2C_SettingsType* pI2C_Settings); \
TS_ErrStatus
                    (*SetSignals)
                                         (TempSensorType*,
TS_SignalsType* pSignals); \
```

14/44 Doc ID 16793 Rev 1

```
(*GetSignals)
                                         (TempSensorType*); \
TS SignalsType*
TS_ErrStatus
                    (*SetRegister)
                                         (TempSensorType*,
TS_RegSelectionType, TS_u16);\
TS u16
                    (*GetRegister)
                                         (TempSensorType*,
TS_RegSelectionType eRegSelection); \
TS TemperatureType* (*GetTemperature)
                                         (TempSensorType*,
TS Boolean bForceRegisterRead);
TS ErrStatus
                    (*SetConfiguration) (TempSensorType*, TS u8
uConfigValue);
TS_u8
                   (*GetConfiguration) (TempSensorType*, TS_Boolean
bForceRegisterRead);
                    (*SetTempHysteresis) (TempSensorType*,
TS_ErrStatus
TS_TemperatureType* pTemperature);
TS_TemperatureType* (*GetTempHysteresis)(TempSensorType*,
TS_Boolean bForceRegisterRead);
TS_ErrStatus
                    (*SetTempOverLimit) (TempSensorType*,
TS_TemperatureType* pTemperature);
TS_TemperatureType* (*GetTempOverLimit) (TempSensorType*,
TS_Boolean bForceRegisterRead);
/*
                     */\
/* PUBLIC EVENTS
                     */\
TS_ErrStatus
                    (*OnOverLimitIrq)
                                         (TempSensorType*);
typedef struct TempSensor TempSensorType; /* Forward declaration
for circular typedefs */
struct TempSensor {
    TEMP_SENSOR_OBJ
};
TS Boolean type
/* Boolean types */
typedef enum {
TS_FALSE = 0,
TS_TRUE = !TS_FALSE
} TS_Boolean;
TS_ErrStatus type
/* Error status types */
typedef enum {
TS\_ERROR = 0,
```

57

```
TS OK = !TS ERROR
} TS_ErrStatus;
TS_Reg8Type and TS_Reg16Type types
/* Register types */
typedef TS_u8
               TS_Reg8Type;
typedef TS_u16
                TS_Reg16Type;
TS_RegLengthType type
/* Register length type */
typedef enum{
   TS_REG_1BYTE_LEN = 1,
   TS_REG_2BYTE_LEN
} TS_RegLengthType;
TS_RegPointerType type
/* Command/Pointer register type */
typedef enum{
   TS_P_REG_TEMP = 0x00, /* P1=0 P2=0 */
   TS_P_REG_CONF = 0x01, /* P1=0
                                      P2=1 */
   TS_P_REG_Thys = 0x02, /* P1=1 P2=0 */
   TS_P_REG_Tos = 0x03
                           /* P1=1
                                       P2=1 */
} TS_RegPointerType;
TS_RegSelection type
/* Register selection type */
typedef enum{
                     = 0 \times 00,
   TS_SEL_CONF_REG
                     = 0x01,
   TS_SEL_TEMP_REG
   TS_SEL_HYST_REG
                      = 0x02,
   TS_SEL_OVER_REG
                     = 0 \times 04
} TS_RegSelectionType;
TS_SignType type
```

16/44 Doc ID 16793 Rev 1

/* Temperature value sign type */

typedef enum{

TS_PLUS_SIGN,
TS_MINUS_SIGN

```
} TS_SignType;
```

TS_RegistersType type

TS_TemperatureType type

TS_SignalsType type

```
/* The STLM75 Signals */
typedef struct {
    TS_SignalType    TS_SCL;
    TS_SignalType    TS_SDA;
    TS_SignalType    TS_OS_INT;
} TS_SignalSType;
```

TempSensor:: Signals API property

The TempSensor structure exports the following public property:

```
TS_SignalsType Signals;
```

The signals property contains the SCL, SDA, and OS_INT pin configuration. This property is redundant because the final application can use GetSignals and SetSignals API layer functions in order to manage signals property. The property has been left as public for utility scope only. It is recommended that the final application instead uses GetSignals and SetSignals functions to directly access signals public property.

TempSensor::TimeoutTicks API property

The TempSensor structure exports the following public property:

```
TS_u32 TimeoutTicks;
```

The TimeoutTick property allows the final application to avoid application block in case of I²C communication problems. TimeoutTick is the number of g_TempSensorTick to wait during an I²C communication between the microcontroller and the STLM75 before considering that an error has occurred and resetting the I²C peripheral.

Warning:

TimeoutTicks must be set to >0 as following ONLY if g_TempSensorTick is defined as: <code>extern volatile u32</code> g_TempSensorTick; in the final application source code, and it is incremented in a scheduler timer IRQ handler. If you don't want to use timeout feature, don't configure the TimeoutTicks property or set it to 0.

The following is an example of TimeoutTicks property:

. . .

File: main.c

File: stm32f10x_it.c

```
extern volatile u32 g_TempSensorTick;
...
void SysTickHandler(void)
{
    // Increment Temperature Sensor tick for Timeout purpose
    g_TempSensorTick ++;
```

18/44 Doc ID 16793 Rev 1

}

TempSensor:: Init API function

Table 6 describes the Init function of the TempSensor structure:

Table 6. Init API function

Name	Description		
Function name	Init		
Function prototype	TS_ErrStatus Init (TempSensorType* pThis, TS_SignalsType* pSignals, TS_I2C_SettingsType* pI2C_Settings)		
Behavior description	Initialize the TempSensor object.		
Input parameter {x}	pThis - Object pointer; pSignals - A Signal collection structure pointer; pI2C_Settings - A I2C peripheral structure pointer;		
Output parameter {x}	None		
Return value	TS_OK if successful, TS_ERROR otherwise		
Required preconditions	NewTempSensorObj, must have been called before.		
Called functions	API function: TS_ErrStatus SetSignals (TempSensorType* pThis, TS_SignalsType* pSignals); TS_ErrStatus SetI2C_Settings (TempSensorType* pThis, TS_I2C_SettingsType* pI2C_Settings); HAL function: void TS_InitI2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings);		

Example:

```
TS_SignalsType TempSensorSignals;
TS_I2C_SettingsType TempSensorI2C_Settings;
...
/* Initialize the temperature sensor according to previous Signals and I2C_Settings */
pObjTempSensor->Init(pObjTempSensor, &TempSensorSignals, &TempSensorI2C_Settings);
```

TempSensor:: Reset API function

Table 7 describes the reset function of the TempSensor structure:

Table 7.	Recet	ΛDI	function
Table 7.	nesei	AFI	IUIICUOII

Name	Description
Function name	Reset
Function prototype	TS_ErrStatus Reset (TempSensorType* pThis)
Behavior description	Reset the Micro/Sensor I ² C communication.
Input parameter {x}	pThis - object pointer
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: void TS_ResetI2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings); void TS_InitI2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings);

```
/* Reset the I2C communication */
pObjTempSensor->Reset(pObjTempSensor);
```

TempSensor:: SetI2C_Settings API function

Table 8 describes the SetI2C_Settings function of the TempSensor structure.

This function is called by the TempSensor:Init function during the initialization phase, therefore it's not necessary to directly call it. The final application can specifically call this function in order to change the I^2C peripheral settings after initialization.

Table 8. SetI2C_Settings API function

Name	Description
Function name	SetI2C_Settings
Function prototype	TS_ErrStatus Setl2C_Settings (TempSensorType* pThis, TS_I2C_SettingsType* pI2C_Settings)
Behavior description	Set the STLM75 I2C peripheral settings copying the right values from the passed parameter
Input parameter {x}	pThis - Object pointer; pI2C_Settings - A I2C peripheral structure pointer;
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj function must have been called before.
Called functions	HAL function: void TS_InitI2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings);

20/44 Doc ID 16793 Rev 1

```
TS_I2C_SettingsType TempSensorI2C_Settings;

/* Enable I2C2 clock */
RCC_APB1PeriphClockCmd(RCC_APB1Periph_I2C2, ENABLE);

/* I2C Peripheral settings initialization */
TempSensorI2C_Settings.TS_I2C_Ptr = I2C2;
TempSensorI2C_Settings.TS_I2C_Clock = 0x90;
TempSensorI2C_Settings.TS_I2C_Address = 400000;

pObjTempSensor->SetI2C_Settings(pObjTempSensor, &TempSensorI2C_Settings);
```

TempSensor:: SetSignals API function

Table 9 describes the SetSignals function of the TempSensor structure.

This function is called by the TempSensor:Init function during the initialization phase, therefore it's not necessary to directly call it. The final application can specifically call this function in order to change the microcontroller signal (port, pin, mode) settings after initialization.

Table 9. SetSignals

Name	Description
Function name	SetSignals
Function prototype	TS_ErrStatus SetSignals (TempSensorType* pThis, TS_SignalsType* pSignals)
Behavior description	Set the STLM75 signals (port and pin) using the right values from the passed parameter
Input parameter {x}	pThis - Object pointer; pSignals - A Signal collection structure pointer;
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj function must have been called before.
Called functions	HAL function: void TS_ConfigSignal(TS_SignalType* pSignal)

```
TS_SignalsType TempSensorSignals;
/* Enable GPIOB clock */
RCC_APB2PeriphClockCmd(RCC_APB2Periph_GPIOB, ENABLE);
/* GPIO signals configuration */
/* Configure PB.10 as alternate function Open-Drain */
TempSensorSignals.TS_SCL.Port
                               = GPIOB;
TempSensorSignals.TS_SCL.Pin
                               = GPIO_Pin_10;
TempSensorSignals.TS_SCL.Mode
                               = GPIO_Mode_AF_OD;
/* Configure PB.11 as alternate function Open-Drain */
TempSensorSignals.TS_SDA.Port
                               = GPIOB;
TempSensorSignals.TS_SDA.Pin
                               = GPIO_Pin_11;
TempSensorSignals.TS_SDA.Mode
                                = GPIO Mode AF OD;
/* Configure PB.12 as alternate function Open-Drain */
TempSensorSignals.TS_OS_INT.Port = GPIOB;
TempSensorSignals.TS_OS_INT.Pin = GPIO_Pin_12;
TempSensorSignals.TS_OS_INT.Mode = GPIO_Mode_AF_PP;
pObjTempSensor->SetSignals(pObjTempSensor, &TempSensorSignals);
```

TempSensor:: GetSignals API function

Table 10 describes the GetSignals function of the TempSensor structure.

Table 10. GetSignals

Name	Description
Function name	GetSignals
Function prototype	TS_SignalsType* GetSignals (TempSensorType* pThis)
Behavior description	Return the Signal collection structure pointer
Input parameter {x}	pThis - Object pointer
Output parameter {x}	None
Return value	The signals structure pointer

22/44 Doc ID 16793 Rev 1

Table 10. GetSignals (continued)

Name	Description
Required preconditions	NewTempSensorObj function must have been called before.
Called functions	None

```
TS_SignalsType* pTempSensorSignals;

/* Get the Signals */
pTempSensorSignals = pObjTempSensor->GetSignals(pObjTempSensor);
```

TempSensor:: SetRegister API function

Table 11 describes the SetRegister function of the TempSensor structure.

This function can be considered as an advanced function for the final user who knows STLM75 internal registers. This function call can be avoided by calling one of the following specific functions:

SetConfiguration, SetTempHysteresis, SetTempOverLimit;

Note that calling the SetRegister advanced function instead of a specific one, internal TempSensor object data (m_Configuration, m_TempHysteresis, m_TempOverLimit) is not assigned.

Table 11. SetRegister

Name	Description
Function name	SetRegister
Function prototype	TS_ErrStatus SetRegister (TempSensorType* pThis, TS_RegSelectionType eRegSelection, TS_u16 uRegValue)
Behavior description	Set the STLM75 register identified by eRegSelection type with the value passed as parameter
Input parameter {x}	pThis - Object pointer; eRegSelection - The type associated to the register to be set; uRegValue - The value to be assigned to the register. This is a 16-bit value, so for the 8-bit register, only the LSB must be considered
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillRegisterFromData();

. . .

pObjTempSensor->SetRegister(pObjTempSensor, TS_SEL_CONF_REG, 0);

TempSensor:: GetRegister API function

Table 12 describes the GetRegister function of the TempSensor structure.

This function can be considered as an advanced function for the final user who knows STLM75 internal registers. This function call can be avoided by calling one of the following specific functions:

GetConfiguration, GetTemperature, GetTempHysteresis, GetTempOverLimit;

Table 12. GetRegister

Name	Description
Function name	GetRegister
Function prototype	TS_u16 GetRegister (TempSensorType* pThis, TS_RegSelectionType eRegSelection)
Behavior description	Return a 16-bit register value. The right register is identified by eRegSelection type passed as parameter. For the 8-bit register, only the LSB must be considered in the return value.
Input parameter {x}	pThis - Object pointer; eRegSelection - The type associated to the register to be set
Output parameter {x}	None
Return value	Register value if successful, TS_NULL_REG_VALUE otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillDataFromRegister ();

Example:

```
TS_u16 uTemperatureRegisterValue;
uTemperatureRegisterValue = pObjTempSensor-
>GetRegister(pObjTempSensor, TS_SEL_TEMP_REG);
```

TempSensor:: SetConfiguration API function

Table 13 describes the SetConfiguration function of the TempSensor structure.

Table 13. SetConfiguration

Name	Description
Function name	SetConfiguration
Function prototype	TS_ErrStatus SetConfiguration (TempSensorType* pThis, TS_u8 uConfigValue)
Behavior description	Set the 8-bit Configuration register value.
Input parameter {x}	pThis - Object pointer; uConfigValue - The 8-bit value to write in the register
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillRegisterFromData();

Example:

TempSensor:: GetConfiguration API function

Table 14 describes the GetConfiguration function of the TempSensor structure.

Table 14. GetConfiguration

Name	Description
Function name	GetConfiguration
Function prototype	TS_u8 GetConfiguration (TempSensorType* pThis, TS_Boolean bForceRegisterRead)
Behavior description	Return the 8-bit Configuration register value.
Input parameter {x}	pThis - Object pointer; bForceRegisterRead - if TS_TRUE reads the value from the register otherwise the last read value returns
Output parameter {x}	None

Table 14. GetConfiguration (continued)

Name	Description
Return value	Configuration value if successful, TS_NULL_REG_VALUE otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillDataFromRegister ();

u8 uTestConfigurationValue;

TempSensor:: GetTemperature API function

Table 15 describes the GetTemperature function of the TempSensor structure.

Table 15. GetTemperature

Name	Description
Function name	GetTemperature
Function prototype	TS_TemperatureType* GetTemperature (TempSensorType* pThis, TS_Boolean bForceRegisterRead)
Behavior description	Return Temperature structure pointer.
Input parameter {x}	pThis - Object pointer; bForceRegisterRead - if TS_TRUE reads the value from the register otherwise the last read value returns
Output parameter {x}	None
Return value	Temperature pointer if successful, TS_NULL_PTR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillDataFromRegister ();

Example:

TS_TemperatureType* pStrTemperature;

 $/^{\star}$ Get the read temperature structure pointer forcing a STLM75 register reading $^{\star}/$

26/44 Doc ID 16793 Rev 1

TempSensor:: SetTempHysteresis API function

Table 16 describes the SetTempHysteresis function of the TempSensor structure.

Table 16. SetTempHysteresis

Name	Description
Function name	SetTempHysteresis
Function prototype	TS_ErrStatus SetTempHysteresis (TempSensorType* pThis, TS_TemperatureType* pTemperature)
Behavior description	Set the 16-bit Hysteresis temperature register value.
Input parameter {x}	pThis - Object pointer; pTemperature - Hysteresis temperature structure pointer
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillRegisterFromData();

Example:

TempSensor:: GetTempHysteresis API function

Table 17 describes the GetTempHysteresis function of the TempSensor structure.

Table 17. GetTempHysteresis

Name	Description
Function name	GetTempHysteresis
Function prototype	TS_TemperatureType* GetTempHysteresis (TempSensorType* pThis, TS_Boolean bForceRegisterRead)

Table 17. GetTempHysteresis (continued)

Name	Description
Behavior description	Return the Hysteresis temperature structure pointer.
Input parameter {x}	pThis - Object pointer; bForceRegisterRead - if TS_TRUE reads the value from the register otherwise the last read value returns
Output parameter {x}	None
Return value	Hysteresis temperature pointer if successful, TS_NULL_PTR otherwise
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillDataFromRegister ();

```
TS_TemperatureType* pStrTemperature;

/* Get the Hysteresis temperature structure pointer forcing a STLM75
  register reading */
```

TempSensor:: SetTempOverLimit API function

Table 18 describes the SetTempOverLimit function of the TempSensor structure.

(pObjTempSensor, TS_TRUE);

pStrTemperature = pObjTempSensor->GetTempHysteresis

Table 18. SetTempOverLimit

Name	Description	
Function name	SetTempOverLimit	
Function prototype	TS_ErrStatus SetTempOverLimit (TempSensorType* pThis, TS_TemperatureType* pTemperature)	
Behavior description	Set the 16-bit Over-limit temperature register value.	
Input parameter {x}	pThis - Object pointer; pTemperature - Over-limit temperature structure pointer	
Output parameter {x}	None	
Return value	TS_OK if successful, TS_ERROR otherwise	
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been call before.	
Called functions	HAL function: TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillRegisterFromData();	

```
TS_TemperatureType strTestTemperature;
...

/* Write the following value for Over-Limit register: +75.5° C */

strTestTemperature.TS_Sign = TS_PLUS_SIGN;

strTestTemperature.TS_IntegerValue = 75;

strTestTemperature.TS_DecimalValue = 5;  /* 0 or 5 only */

pObjTempSensor->SetTempOverLimit (pObjTempSensor,

&strTestTemperature);
```

TempSensor:: GetTempOverLimit API function

Table 19 describes the GetTempOverLimit function of the TempSensor structure.

Table 19. GetTemperatureOverLimit

Name	Description	
Function name	GetTempOverLimit	
Function prototype	TS_TemperatureType* GetTempOverLimit (TempSensorType* pThis, TS_Boolean bForceRegisterRead)	
Behavior description	Return the Over-limit temperature structure pointer.	
Input parameter {x}	pThis - Object pointer; bForceRegisterRead - if TS_TRUE reads the value from the register otherwise the last read value returns	
Output parameter {x}	None	
Return value	Over-limit temperature pointer if successful, TS_NULL_PTR otherwise	
Required preconditions	NewTempSensorObj, TempSensor:: Init functions must have been called before.	
Called functions	HAL function: functions TS_ErrStatus TS_SetPointerRegister(); TS_ErrStatus TS_FillDataFromRegister ();	

Example:

4.2 HAL Layer firmware overview

This section describes the hardware abstraction layer function used by the upper API layer described in the previous section. All the library microcontroller hardware dependent functions and related defined types are described in this section. See *Figure 2*.

The final application should NEVER directly use these HAL functions, and it should manage the STLM75 temperature sensor through the API layer functions as described above.

4.2.1 HAL types

Standard types redefinition

```
/* Standard type redefinition in order
    to maintain code portability */
typedef signed long    TS_s32;
typedef signed short    TS_s16;
typedef signed char    TS_s8;
typedef unsigned long    TS_u32;
typedef unsigned short    TS_u16;
typedef unsigned char    TS_u8;
```

STM32 library types redefinition

```
/* Redefine micro specific types */
typedef GPIO_TypeDef* TS_PortType;
typedef GPIOMode_TypeDef TS_ModeType;
typedef u32 TS_PinType;
typedef I2C_TypeDef* TS_I2CType;
```

TS_SignalActionType type

```
/* Signal state enumeration */
typedef enum
{ TS_SIGNAL_LOW = Bit_RESET,
   TS_SIGNAL_HIGH = Bit_SET
} TS_SignalActionType;
```

TS_StateType type

```
/* State type */
typedef enum
{
   TS_DISABLE = DISABLE,
   TS_ENABLE = ENABLE
```

30/44 Doc ID 16793 Rev 1

```
} TS_StateType;
```

TS_SignalType type

```
/* The STLM75 Single Signal type */
typedef struct {
   TS_PortType Port;
   TS_PinType Pin;
   TS_ModeType Mode;
} TS_SignalType;
```

TS_I2C_SettingsType type

```
/* The STLM75 I2C Peripheral settings */
typedef struct {
    TS_I2CType   TS_I2C_Ptr;
    TS_u32    TS_I2C_Clock;
    TS_u16    TS_I2C_Address;
} TS_I2C_SettingsType;
```

4.2.2 HAL functions

TS_ConfigSignal HAL function

Table 20 describes the TS_ConfigSignal function of the hardware abstraction layer.

Table 20. TS_ConfigSignal

Name	Description
Function name	TS_ConfigSignal
Function prototype	void TS_ConfigSignal(TS_SignalType* pSignal)
Behavior description	Config the signal pin according to the passed parameters
Input parameter {x}	pSignal - Signal structure pointer
Output parameter {x}	None
Return value	None
Required preconditions	None
Called functions	None

TS_InitI2C_Peripheral HAL function

Table 21 describes the TS_Initl2C_Peripheral function of the hardware abstraction layer.

Table 21. TS_Initl2C_Peripheral

Name	Description
Function name	TS_Initl2C_Peripheral
Function prototype	void TS_Initl2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings)
Behavior description	Initialize and configure the I2C peripheral used by the micro in order to manage the STLM75 temperature sensor device
Input parameter {x}	pl2C_Settings - I2C peripheral settings structure pointer
Output parameter {x}	None
Return value	None
Required preconditions	None
Called functions	None

TS_Resetl2C_Peripheral HAL function

Table 22 describes the TS_ResetI2C_Peripheral function of the hardware abstraction layer.

Table 22. TS_Resetl2C_Peripheral

Name	Description
Function name	TS_Resetl2C_Peripheral
Function prototype	void TS_ResetI2C_Peripheral(TS_I2C_SettingsType* pI2C_Settings)
Behavior description	Apply a software Reset on the I2C peripheral, e.g. in order to exit from an I2C blocking error
Input parameter {x}	pl2C_Settings - I2C peripheral settings structure pointer
Output parameter {x}	None
Return value	None
Required preconditions	None
Called functions	None

TS_CheckEventWithTimeout HAL function

Table 23 describes the TS_CheckEventWithTimeout function of the hardware abstraction layer.

Table 23. TS_CheckEventWithTimeout

Name	Description
Function name	TS_CheckEventWithTimeout
Function prototype	TS_ErrStatus TS_CheckEventWithTimeout(TS_I2C_SettingsType* pI2C_Settings, u32 I2C_EVENT, u32 uTimeoutTicks)
Behavior description	Check the I2C event inside a max timeout time. This function requires that the g_TempSensorTick variable is defined as extern in the main application, and it is incremented in SysTickHandler Interrupt or another scheduler time.
Input parameter {x}	pl2C_Settings - I2C peripheral settings structure pointer;
Output parameter {x}	None
Return value	TS_OK if event occurs inside the timeout time, TS_ERROR otherwise
Required preconditions	g_TempSensorTick variable is defined as extern in the main application, and it is incremented in a scheduler time.
Called functions	None

TS_FillDataFromRegister HAL function

Table 24 describes the TS_FillDataFromRegister function of the hardware abstraction layer.

Table 24. TS_FillDataFromRegister

Name	Description	
Function name	TS_FillDataFromRegister	
Function prototype	TS_ErrStatus TS_FillDataFromRegister(TS_I2C_SettingsType* pl2C_Settings,TS_u16* pReadRegValue, TS_RegLengthType eRegLenType, u32 uTimeoutTicks)	
Behavior description	Read from the specified STLM75 a register value (8 or 16 bits) and return the value in output parameter.	
	Warning: SetPointerRegister function MUST be called before calling this one.	
Input parameter {x}	pI2C_Settings - I2C peripheral settings structure pointer; eRegLenType - Register byte-length type (Can be 1-Byt or 2-Byte); uTimeoutTicks - The g_TempSensorTick to wait before returning an error; uTimeoutTicks must be >=1.	

Table 24. TS_FillDataFromRegister (continued)

Name	Description
Output parameter {x}	pReadRegValue - Read register value pointer;
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	SetPointerRegister function MUST be called before calling this one.
Called functions	TS_ErrStatus TS_CheckEventWithTimeout()

TS_FillRegisterFromData HAL function

Table 25 describes the TS_FillRegisterFromData function of the hardware abstraction layer.

Table 25. TS_FillRegisterFromData

Name	Description	
Function name	TS_FillRegisterFromData	
Function prototype	TS_ErrStatus TS_FillRegisterFromData(TS_I2C_SettingsType* pl2C_Settings,TS_u16 uWriteRegValue, TS_RegLengthType eRegLenType, u32 uTimeoutTicks)	
Behavior description	Write the data passed in input parameter on the specified STLM75 register value (8 or 16 bits).	
	Warning: WARNING: SetPointerRegister function MUST be called before calling this one.	
Input parameter {x}	pI2C_Settings - I2C peripheral settings structure pointer; eRegLenType - Register byte-length type (Can be 1-Byt or 2-Byte); uWriteRegValue - Data value to write on the right register; uTimeoutTicks - The g_TempSensorTick to wait before returning an error; uTimeoutTicks must be >=1.	
Output parameter {x}	None	
Return value	TS_OK if successful, TS_ERROR otherwise	
Required preconditions	SetPointerRegister function MUST be called before calling this one.	
Called functions	TS_ErrStatus TS_CheckEventWithTimeout()	

TS_SetPointerRegister HAL function

Table 26 describes the TS_SetPointerRegister function of the hardware abstraction layer.

Table 26. TS_SetPointerRegister

Name	Description
Function name	TS_SetPointerRegister
Function prototype	TS_ErrStatus TS_SetPointerRegister(TS_I2C_SettingsType* pI2C_Settings, TS_RegPointerType eRegPointer, u32 uTimeoutTicks)
Behavior description	Set the STLM75 Command/Pointer register, before executing a Read/Write operation on STLM75 register
Input parameter {x}	pl2C_Settings - I2C peripheral settings structure pointer; eRegLenType - Register byte-length type (Can be 1-Byt or 2-Byte); uTimeoutTicks - The g_TempSensorTick to wait before returning an error; uTimeoutTicks must be >=1.
Output parameter {x}	None
Return value	TS_OK if successful, TS_ERROR otherwise
Required preconditions	None
Called functions	TS_ErrStatus TS_CheckEventWithTimeout()

Example application AN3108

5 Example application


Together with the STLM75 firmware library package, an example application is delivered in order to provide the final user with a real example of STLM75 library use. See *Figure 6*.

The delivered example application has been developed using IAR EWARM 5.20 IDE and can be built for both STM32F10xxx Medium-density and High-density microcontroller families.

An application project which wants to use the STLM75 library must:

- Include the STLM75.a file in the project generated compiling the STLM75_LIB library firmware delivered in the final library package. See Section 3.2. The 2STLM75 library source code can be included instead of the STLM75.a object file
- Implement a main function as described in the following section.





5.1 main.c

An example of a main application is reported below. The main function contains an example of the STLM75 library initialization/configuration and implements temperature sensor registers read/write operations:

```
/* Includes -----*/
#include "stm32f10x_lib.h"
#include "TempSensorObj.h"
#include <stdio.h>
/* Private typedef ------*/
/* Private define ------*/
```

```
// STLM75 TEMPERATURE SENSOR DEFINES
// Temperature sensor controller signal
#define TMP I2C PERIPHERAL
#define TMP_I2C_SLAVE_ADDR7 0x90
                           // 1001 0000
#define TMP_I2C_CLOCK_SPEED 400000 //400Khz
#define TMP_SCL_PORT
                      GPIOB
#define TMP SCL PIN
                      GPIO Pin 10
#define TMP_SCL_MODE
                      GPIO_Mode_AF_OD
#define TMP_SDA_PORT
                      GPIOB
#define TMP_SDA_PIN
                       GPIO_Pin_11
#define TMP_SDA_MODE
                      GPIO_Mode_AF_OD
#define TMP_OS_INT_PORT
                       GPIOB
#define TMP_OS_INT_PIN
                      GPIO_Pin_12
#define TMP_OS_INT_MODE
                       GPIO_Mode_AF_PP
/* Private macro -----*/
/* Private variables -----*/
ErrorStatus HSEStartUpStatus;
/* Private function prototypes -----*/
void RCC_Configuration
                    (void);
void NVIC_Configuration (void);
void SysTick_Configuration(void);
void STLM75_Configuration (TempSensorType* pObjTempSensor);
/* Private functions -----*/
/***********************
* Function Name : Main
* Description : Main program.
* Input
            : None
* Output
             : None
* Return
             : None
********************
int main(void)
```

5/

```
{
   TempSensorType*
                     pObjTempSensor;
   TS_TemperatureType* pStrTemperature;
   TS_TemperatureType strTestTemperature;
   u8
                     uTestConfigurationValue;
   char
                     cTemperatureSign;
                     uReadingNumber = 0;
   1116
   #ifdef DEBUG
     debug();
   #endif
   /* System clocks configuration -----*/
   RCC_Configuration();
   /* NVIC configuration -----*/
   NVIC_Configuration();
   /* STLM75 configuration -----*/
   pObjTempSensor = NewTempSensorObj ();
   STLM75_Configuration(pObjTempSensor);
/* You can configure timeout to avoid application block in case of
I2C communication problems. TimeoutTick is the number of
g_TempSensorTick to wait during an I2C communication between Micro
and STLM75 before considering an error has occurred and resetting
the I2C peripheral.
WARNING: TimeoutTicks must be set >0 as following ONLY if
g_TempSensorTick is defined as "extern volatile u32
g_TempSensorTick" in this Application, and is incremented in
SysTickHandler or another timer irq handler. */
   pObjTempSensor->TimeoutTicks = 2; /* 2ms:we have a
                                     g_TempSensorTick each
                                     millisecond */
   /* STLM75 Library use example -----*/
```

38/44 Doc ID 16793 Rev 1

```
/* TEST: Write the following value for the Configuration
register:
            0x00 */
   uTestConfigurationValue = 0x00;
   pObjTempSensor->SetConfiguration (pObjTempSensor,
                                      uTestConfigurationValue);
    /* TEST: Write the following value for the Hysteresis register:
            75.5° C */
                                    = TS_PLUS_SIGN;
   strTestTemperature.TS_Sign
   strTestTemperature.TS_IntegerValue = 75;
   strTestTemperature.TS_DecimalValue = 5;
                                             /* 0 or 5 only */
   pObjTempSensor->SetTempHysteresis (pObjTempSensor,
                                     &strTestTemperature);
    /* TEST: Write the following value for the Over-Limit register:
            50.5° C */
   strTestTemperature.TS_Sign
                                = TS_PLUS_SIGN;
   strTestTemperature.TS_IntegerValue = 50;
   strTestTemperature.TS_DecimalValue = 5;
                                             /* 0 or 5 only */
   pObjTempSensor->SetTempOverLimit (pObjTempSensor,
                                      &strTestTemperature);
 /* TEST: Read STLM75 values for the Configuration, Hysteresis
         and Over-Limit temp. registers */
   uTestConfigurationValue = pObjTempSensor->GetConfiguration
                            (pObjTempSensor, TS_TRUE);
                           = pObjTempSensor->GetTempHysteresis
   pStrTemperature
                            (pObjTempSensor, TS_TRUE);
                           = pObjTempSensor->GetTempOverLimit
   pStrTemperature
                            (pObjTempSensor, TS_TRUE);
   /* Infinite main loop -----*/
   while(1)
       /* TEST: Read observed STLM75 temperature and show the read
                value */
       pStrTemperature = pObjTempSensor->GetTemperature
                        (pObjTempSensor, TS_TRUE);
```

Doc ID 16793 Rev 1 39/44

Example application AN3108

```
cTemperatureSign = (pStrTemperature->TS_Sign ==
                          TS_PLUS_SIGN) ? '+' : '-';
      /* Send Temperature read data to the debugger Terminal Output
          Window */
      printf ("Read Temperature (%d): %c%d.%d\r\n",
                               uReadingNumber++,
                                                              \
                              cTemperatureSign,
                              pStrTemperature->TS_IntegerValue, \
                               pStrTemperature->TS_DecimalValue);
   }
}
/************************
* Function Name : STLM75_Configuration
* Description
              : Configure the Micro I2C peripheral and GPIO pins
                 in order to use
               : the TempSensor hardware components present on the
                 application board
                : pObjTempSensor - The STLM75 temperature sensor
* Input
                 object pointer
* Output
                : None
* Return
               : None
************************
void STLM75_Configuration (TempSensorType* pObjTempSensor)
{
   TS_SignalsType
                      TempSensorSignals;
   TS_I2C_SettingsType TempSensorI2C_Settings;
   /* Enable I2C2 clock */
   RCC_APB1PeriphClockCmd(RCC_APB1Periph_I2C2, ENABLE);
   /* Enable GPIOB clock */
   RCC_APB2PeriphClockCmd(RCC_APB2Periph_GPIOB, ENABLE);
   /* GPIO signals configuration */
```

}

```
/* Configure PB.10 as alternate function Open-Drain */
TempSensorSignals.TS_SCL.Port
                               = TMP_SCL_PORT;
TempSensorSignals.TS_SCL.Pin
                               = TMP_SCL_PIN;
TempSensorSignals.TS_SCL.Mode = TMP_SCL_MODE;
/* Configure PB.11 as alternate function Open-Drain */
TempSensorSignals.TS_SDA.Port
                               = TMP SDA PORT;
TempSensorSignals.TS_SDA.Pin
                               = TMP_SDA_PIN;
TempSensorSignals.TS_SDA.Mode
                                = TMP_SDA_MODE;
/* Configure PB.12 as alternate function Open-Drain */
TempSensorSignals.TS_OS_INT.Port = TMP_OS_INT_PORT;
TempSensorSignals.TS_OS_INT.Pin = TMP_OS_INT_PIN;
TempSensorSignals.TS_OS_INT.Mode = TMP_OS_INT_MODE;
//OverLimitConfigIrq();
// I2C Peripheral settings configuration
TempSensorI2C_Settings.TS_I2C_Ptr = TMP_I2C_PERIPHERAL;
TempSensorI2C_Settings.TS_I2C_Clock = TMP_I2C_CLOCK_SPEED;
TempSensorI2C_Settings.TS_I2C_Address = TMP_I2C_SLAVE_ADDR7;
/* Initialize the Temperature Sensor Object */
pObjTempSensor->Init(pObjTempSensor, &TempSensorSignals,
                    &TempSensorI2C_Settings);
```

Doc ID 16793 Rev 1 41/44

References AN3108

6 References

1. STLM75; Digital temperature sensor and thermal watchdog, datasheet

- 2. RM0008; STM32F101xx, STM32F102xx, STM32F103xx, STM32F105xx and STM32F107xx advanced ARM-based 32-bit MCUs, reference manual
- 3. STM32F10xFWLib 2.0.3, AN2953; *How to migrate from the STM32F10xxx firmware library V2.0.3 to the STM32F10xxx standard peripheral library V3.0.0*, application note

AN3108 Revision history

7 Revision history

Table 27. Document revision history

Date	Revision	Changes
12-Oct-2010	1	Initial release.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2010 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan -Malaysia - Malta - Morocco - Philippines - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

44/44 Doc ID 16793 Rev 1

