QUICK COMMANDS REFERENCE

DIRECT—MODE Commands				
↑↑ p. 8-1	restores defaults			
ACTIVATE p. 8-2	erases and re-creates bam and index for existing LU ACTIVATE			
AUTOCOPY p. 8-3	copies file(s) between LUs AUTOCOPY			
AUTODEL p. 8-4	deletes file(s) from LU AUTODEL			
AUTOMOVE p. 8-5	moves files between USER partitions AUTOMOVE			
BUILD p. 8-6	creates 'formatted' RELative file BUILD_filename,nrecs,recl			
BUILDCPM p. 8-7	constructs CP/M on the CP/M LU BUILDCPM			
BUILDINDEX p. 8-8	builds a KEY file for indexed RELative files BUILDINDEX			
CHANGE p. 8-9	changes file's characteristics CHANGE[lu:[filename			
CHECKSUM p. 8-10	verifies DOS integrity CHECKSUM			
CLEAR p. 8-11	clears archive bits for file(s) CLEAR			
CONFIG p. 8-12	changes power-up default system settings and LU parmeters CONFIG			
COPY p. 8-13	copies oldfilename into newfilename COPY_[''][lu:][newfilename]=[lu:]oldfileneme['']			
D p. 8-14	sets temporary hardware device # for hard disk D[drynum]			
DEL p. 8-15	deletes lines of BASIC program in memory DELline number or DEL[beg.line]—[end.line]			
DI p. 8-16	lists keys within the specified KEY file DI			
DIR p. 8-17	lists directory of files on hard disk DIR[[lu:[user:]]:[Tfiltyp][P][S][S][G][C]][filename]			
DUMP p. 8-19	writes editable text image of BASIC in memory to disk file DUMP[range][lu:]seqfile			

erases one file from disk

ERA_[lu:[user:]]filename

ERA p. 8-20

DIRECT—MODE Commands continued

EXEC p. 8-21	provides an easy way to automate procedures EXEC_[lu:[user:]]filename	SAVE p. 8-46
FASTCOPY p. 8-22	fast 1541 back-up/restore utility FASTCOPY	SHIP p. 8-47
FETCH p. 8-23	creates memory BASIC programs from disk resident text file FETCH [lu:]filename	TYPE p. 8-48
FIND p. 8-24	finds text or tokens in BASIC FIND_delimSTRINGdelim[, < line-range >	UPDATEDOS p. 8-49
GO64 p. 8-25	sends CPU to the C-64 mode GO64	USER p. 8-50
GO128 p. 8-26	sends CPU to 128 mode GO128	VALIDATE p. 8-51
GOCPM p. 8-27	sends CPU to the CPM mode GOCPM	
ICQUB p. 8-28	captures or runs captured copy protected software ICQUB or filename	BUILDKEY p. 7-4
L p. 8-31	(abbreviated LOAD) Loads file from disk L_["][lu:]filename["]	COPY p. 8-13
LOAD p. 8-31	loads file from disk LOAD "[lu:]filename",dev[,sa]	DELETE p. 7-5
LKOFF p. 8-32	turns off Host Adaptor LKOFF	INSERT p. 7-6
LKREV p. 8-33	reports DOS version LKREV	LDLU p. 7-7
LU p. 8-34	changes logged logical device # LU[lunum]	LG p. 7-8
MERGE p. 8-35	merges disk-based BASIC programs into memory program MERGE[lu:]filename	LOAD p. 7-9
OOPS p. 8-36	recovers last erased file OOPS	OPEN p. 7-10
QUERY p. 8-37	lists characteristics of file QUERY[lu:]filename	SAVE p. 7-11
RECOVERY p. 8-38	rebuilds the index on selected LU. RECOVER	SCRATCH p. 7-12
RENUM p. 8-39	renumbers BASIC program in memory RENUM[incr[,newstart[,oldstart-oldend]]]	SEARCH p. 7-13 Match
S	saves & replaces BASIC programs in memory under same name	Greater-that Less-than
p. 8-45	S	SHUFFLE
S	(abbreviated SAVE) Saves program or range of memory to disk	p. 7-14
p. 8-45	S_[range][lu:filename	

DIRECT—MODE Commands continued					
	SAVE p. 8-46	SAVEs program or range of memory to disk SAVE "[range][lu;]filename",dev			
	SHIP p. 8-47	locks head in preparation to transport hard disk SHIP			
	TYPE p. 8-48	lists disk resident file program to screen TYPE[lu;]filename			
	UPDATEDOS p. 8-49	refreshes all DOS image files with new version of DOS (automatic)			
	USER p. 8-50	changes logged subdirectory number USER[user#]			
	VALIDATE p. 8-51	performs 60 integrity checks on each file of LU VALIDATE			
	RUN—MODE Commands				
	BUILDKEY p. 7-4	creates key files SYS64628:0,lfn,directory,Stringvar,recl,rech,status			
	COPY p. 8-13	copies sourcefile to destfile OPEN #lfn,dev,15, "C[lu]:dfilename = [lu:]sfilename"			
	DELETE p. 7-5	deletes key from specified directory of a KEY file SYS 64628:2,lfn,directory,Stringvar,recl,rech,status			
	INSERT p. 7-6	inserts new key into specified directory of a KEY file SYS 64628:1,lfn,directory,Stringvar,recl,rech,status			
	LDLU p. 7-7	changes operating characteristics OPEN #lfn,dev,15, "ldev#LU#USR#"			
	LG p. 7-8	'gets' current status of selected LU OPEN 15,8,15, "LG" or OPEN 15,8,15, "LG#"			
	LOAD p. 7-9	loads program file from disk LOAD ''[lu:]filename'',dev[,sa]			
	OPEN p. 7-10	opens disk file for i/o OPEN #lfn,dev,sa,"[lu:]filename"			
	SAVE p. 7-11	saves program (or memory range) to disk SAVE "[<range>][lu:]filename",dev</range>			
	COD A MOTE	. 1 / \ C1 C 1' 1			

scratches (erases) file from disk OPEN #lfn,dev,15,"S[lu]:filename

searches KEY file for key entry match, > condition, or < condition
SYS 64628:3,lfn,directory,Stringvar,recl,rech,status
SYS 64628:4,lfn,directory,Stringvar,recl,rech,status
SYS 64628:5,lfn,directory,Stringvar,recl,rech,status

re-distributes keys within a directory of a KEY file for optimum space usage within the file SYS 64628:7,lfn,directory,Stringvar,recl,rech,status

Greater-than