


# POSEIDON PRO

## USER MANUAL & TROUBLESHOOTING GUIDE

Power That Survives the Extreme

**NOT WORKING? TRY THIS FIRST.**

Hold down the battery indicator button to reset the electronics. This fixes most issues.

## 01 WHAT'S IN THE BOX





- Poseidon Pro Power Bank
- 3 ft. (0.91 m) USB-C Charging Cable

## 02 PRODUCT SPECS




| | |
|---|---|
| Battery Capacity | 10,000 mAh / 37.74 Wh |
| Size | 6" x 3.25" x 0.63" |
| Weight | 0.56 lb. / 254 g |
| USB-A Output | 12W, 5V ⎓ 2.4A |
| USB-C Input | 18W, 5V ⎓ 2.4A / 9V ⎓ 2A / 12V ⎓ 1.5A |
| USB-C Output | 18W, 5V ⎓ 3A / 9V ⎓ 2A / 12V ⎓ 1.5A |

## 03 DURABILITY RATINGS



**IP68**
WATERPROOF, FULLY SEALED

**MIL-STD-810G**
DROP PROOF

**1,000 lbs.**
CRUSH PROOF

**8+ years**
CHARGE RETENTION

**-20°F to 120°F / -29°C to 49°C**
OPERATING TEMPERATURE

## 04 GETTING STARTED




- We recommend charging to 100% at first use.
- To recharge: Use the center USB-C port via wall adapter or solar panel (optimized for the Spectre 18W).

## 05 BUTTONS AND CONTROLS







### MODE BUTTON (LEFT BUTTON)

- Double-tap = 1-hour timer mode
- Long press = Low Power Mode (for small electronics)

### BATTERY INDICATOR (RIGHT BUTTON)

- Press once = check charge level
- Hold = reset electronics (solves most issues)

## 06 LED INDICATOR LIGHTS




| | |
|---|---|
| ● ● ● ● | **75–100%** |
| ● ● ● ○ | **50–74%** |
| ● ● ○ ○ | **25–49%** |
| ● ○ ○ ○ | **1–25%** |
| ◌ ○ ○ ○ | **0%**<br>Flashing or none: recharge immediately |

## 07 CHARGING YOUR GEAR

- Plug into USB-C or USB-A output port.
- Works with phones, radios, GPS units, cameras, and other small electronics.
- Compatible with Spectre 18W solar panel for off-grid charging.

## 08 CARE AND MAINTENANCE

- Top off battery at least once per year.
- With the port cover closed = IP68 waterproof.
- With the port cover open = IPX7 waterproof only.
- Do not fully submerge with ports exposed.
- For replacement port covers, email support@darkenergy.com.

## 09 TROUBLESHOOTING

1. Most issues are solved by a reset: hold down the battery indicator button.
2. Try a different cable if your device doesn't charge.
3. If problems persist, email support@darkenergy.com.

## 10 FREQUENTLY ASKED QUESTIONS

**HOW MANY PHONE CHARGES DO I GET?**
2-3 full charges for most smartphones, depending on the model.

**CAN I USE IT WHILE IT'S CHARGING?**
Yes. It supports pass-through charging.

**CAN I FLY WITH IT?**
Yes. It's airplane safe (below 100Wh).

**HOW LONG DOES IT HOLD A CHARGE?**
Charge retention is 8+ years. Top off the battery at least once per year.

**HOW DEEP CAN IT GO UNDERWATER?**
Up to 6 feet (2 meters) for up to 45 minutes, with the port cover closed.

**WHAT DEVICES CAN IT CHARGE?**
Devices with USB-C, Micro-USB, or Lightning connectors, including several at once.

**WHAT TEMPERATURES CAN IT HANDLE?**
It operates from -20˚F to 120˚F / -29˚C to 49˚C.

**WHAT WARRANTY DO I GET?**
2-Year Warranty against defects.

## 11 WARRANTY AND SUPPORT

**2-Year Warranty**
AGAINST DEFECTS

**support@darkenergy.com**
CONTACT US

**YouTube: @DarkEnergyTech**
VIDEO TUTORIALS FOR RESET, CHARGING, INDICATOR LIGHTS, LOW POWER MODE, AND TIMER