

## **S88-N Pinouts**

DESKTOP STATION	PIN 5	PIN 4	PIN 3	A0	GND	+5 V
IC-Connector	DATA IN RESET	PS / LOAD	CLOCK	DATA OUT	GND	+5V
ARDUINO	PIN 12	PIN 3	PIN 2	PIN 13	GND	+5 V






**Usable PINs for S88-Feedback** 

A0, A1, A2, A3, A4, A5,

0, 1, 4, 5, 6, 7, 8, 9, 10, 11



## S88-RJ45-Bridge



## Märklin CS2 Station → Arduino CAN-BUS-Shield

Table: Assignment table of miniDIN pin and D-Sub pin.

	miniDIN 10pin	D-Sub 9Pin	RJ45
CAN_H	4	3	1
CAN_L	8	5	2
VCC	1	9	8
GND	2	2	7
Note	beside 60113	Seeedstudio, Sparkfun	watterott

Sega Saturn to SCART Cable

