


Week 1-15

Review

What organic electronics are good for

- Low cost
- Large area
- Flexible
- Conformable/Stretchable
- Light weight
- Optoelectronics



This Chart Explains Why Organic Semiconductors are Unique

Property	Organics	Inorganics
Bonding	van der Waals	Covalent/Ionic
Charge Transport	Polaron Hopping	Band Transport
Mobility	$\sim 1 \text{ cm}^2/\text{V}\cdot\text{s}$	$\sim 1000 \text{ cm}^2/\text{V}\cdot\text{s}$
Absorption	$10^5\text{-}10^6 \text{ cm}^{-1}$	$10^4\text{-}10^5 \text{ cm}^{-1}$
Excitons	Frenkel	Wannier-Mott
Binding Energy	$\sim 500\text{-}800 \text{ meV}$	$\sim 10\text{-}100 \text{ meV}$
Exciton Radius	$\sim 10 \text{ \AA}$	$\sim 100 \text{ \AA}$

Organic Materials are Interesting

Because...


- They have properties that bridge between their individual molecular and collective (solid state) properties
- They provide deep insights into how the properties of molecules transform into band structure (via tight binding), conductivity and excitonic states
- Almost all physical properties result from electrostatic, van der Waals bonds (vs. chemical bonds) between molecules in the solid state
- Disorder governs characteristics in the solid state
- Their mechanical fragility leads to film growth and patterning that differ from more robust, inorganic semiconductors




Organic Electronics
Stephen R. Forrest

van der Waals bonding

- Purely electrostatic *instantaneous* induced dipole-induced dipole interaction between π -systems of nearby molecules.



Medium around the dipole is *polarized*



$$U(r_{12}) = -\frac{A_{disp}}{r_{12}^6} \quad : \text{Dispersion interaction}$$


$$U(r) = 4\epsilon \left[\left(\frac{\sigma}{r} \right)^{12} - \left(\frac{\sigma}{r} \right)^6 \right] \quad : \text{Lennard-Jones 6-12 potential (includes core repulsion)}$$

Organic Semiconductors are Excitonic Materials

Inorganics → Organics

Wannier exciton

Inorganic semiconductors



SEMICONDUCTOR PICTURE

CONDUCTION BAND



VALENCE BAND



GROUND STATE WANNIER EXCITON


Dielectric constant ~15

binding energy ~10meV (unstable at RT)
radius ~100Å

Organics

Frenkel exciton


Organic materials



MOLECULAR PICTURE

treat excitons as **chargeless particles** capable of diffusion.

Transport of energy (not charge)




GROUND STATE

FRENKEL EXCITON

Štefan R. Černák

Dielectric constant ~2
binding energy ~1eV (stable at RT)
radius ~10Å

Band Structure is Replaced by Energy Levels



It is essential to keep your terminology clear: **Band gaps** exist in inorganics, **energy gaps** without extended bands are the rule (but with important exceptions) in organics.⁷

Singlet and triplet states

Spatially symm. Spin antisymm.

$$\psi(\mathbf{r}_1, \mathbf{r}_2; 0, 0) = \frac{1}{\sqrt{2}} (\phi_a(\mathbf{r}_1)\phi_b(\mathbf{r}_2) + \phi_a(\mathbf{r}_2)\phi_b(\mathbf{r}_1)) (\alpha_1\beta_2 - \alpha_2\beta_1)$$

S m_s

Singlet
 $S=0$
 $m_s = 0$

$$\psi(\mathbf{r}_1, \mathbf{r}_2; 1, 1) = \frac{1}{\sqrt{2}} (\phi_a(\mathbf{r}_1)\phi_b(\mathbf{r}_2) - \phi_a(\mathbf{r}_2)\phi_b(\mathbf{r}_1)) \alpha_1\alpha_2$$


$$\psi(\mathbf{r}_1, \mathbf{r}_2; 1, 0) = \frac{1}{\sqrt{2}} (\phi_a(\mathbf{r}_1)\phi_b(\mathbf{r}_2) - \phi_a(\mathbf{r}_2)\phi_b(\mathbf{r}_1)) (\alpha_1\beta_2 + \alpha_2\beta_1)$$

Triplet
 $S=1$
 $m_s = \pm 1, 0$

and


$$\psi(\mathbf{r}_1, \mathbf{r}_2; 1, -1) = \frac{1}{\sqrt{2}} (\phi_a(\mathbf{r}_1)\phi_b(\mathbf{r}_2) - \phi_a(\mathbf{r}_2)\phi_b(\mathbf{r}_1)) \beta_1\beta_2$$

180° out of phase




(a)

In phase




(b)




Organic Electronics
Stephen R. Forrest

Understanding molecular spectra



Jablonski Diagrams: Life Histories of Excitons




Kasha's rule

The radiative transition from a given spin manifold occurs from the lowest excited state.

100% Internal Efficiency via Spin-Orbit Coupling


Heavy metal induced electrophosphorescence ~100% QE

Baldo, et al., Nature 395, 151 (1998)



Energy Transfer

- If excitons are mobile in the solid, they must move from molecule to molecule
 - ✧ The microscopic “hopping” between neighboring molecules = energy transfer




Different transfer ranges accessed by different processes


Energy Transfer from Host to Dopant: A Review

Förster:


- resonant dipole-dipole coupling
- donor and acceptor transitions must be allowed



Donor* Acceptor




Donor Acceptor*




Electron Exchange (Dexter):

- diffusion of excitons from donor to acceptor by simultaneous charge exchange: short range




Donor* Acceptor




Donor Acceptor*

spin is conserved: e.g. singlet-singlet or triplet-triplet



Jablonski Diagrams





Kasha's rule

The radiative transition from a given spin manifold occurs from the lowest excited state.

Energy Gap Law

- The larger the energy gap, the lower the probability for non-radiative recombination.
 ⇒ As the energy gap of a molecular species decreases, radiative transitions have a higher probability for non-radiative decay.




Carbene = MAC*

R, R' = CN (1)

R = CN, R' = H (2)

R, R' = H (3)




Carbene = DAC*

R, R' = CN (4)

R = CN, R' = H (5)

R, R' = H (6)






$$k_{if} = A \exp\left(-\gamma E_g / \hbar \omega_p\right)$$




$$\gamma = \log\left(\frac{E_g}{\Omega E_p}\right) - 1$$

Ω = number of modes contributing to the maximum phonon energy,
 $= \frac{1}{2}$ the Stokes shift.




Bad things happen to good excitons



Delayed fluorescence
Triplet fusion




Singlet fission when
 $E_S \geq 2E_T$




Modes of Conduction

Band transport



- Coherent
- Charge mean free path $\lambda \gg a$
- $BW > k_B T, \hbar\omega_0$


Hopping and tunneling transport



- Incoherent (each step independent of previous)
- Charge mean free path $\lambda \sim a$
- Tunneling between states of equal energy is band-like
- $BW < k_B T, \hbar\omega_0$

Transport Bands in Organics


- **Tight binding** approximation is useful due to importance of only nearest neighbor interactions
- Recall case of dimers and larger aggregates on exciton spectrum. Close proximity of neighbors results in:
 - Coulomb repulsion
 - Pauli exclusion➤ Splitting leads to broadening of discrete energies into bands



Photoinduced Charge-Transfer at a Type II HJ

The Basis of OPV Operation

Processes occurring at a Donor-Acceptor heterojunction





- ① Exciton generation by absorption of light ($1/\alpha$)
- ② Exciton diffusion over $\sim L_D$
- ③ Exciton dissociation by rapid and efficient charge transfer
- ④ Charge extraction by the internal electric field

Typically: $L_D \ll 1/\alpha$


Organic Electronics
Stephen R. Forrest

Purification by Thermal Gradient Sublimation

Useful for obtaining very high purity small molecule materials



Tetracene after sublimation



Pyrene

- Reasonably fast and simple
- Material must be sublimable
- Multiple cycles result in higher purity
- Can occur in vacuum or under inert gas flow
- Small crystal growth on chamber walls possible

Film Deposition

Vacuum Thermal Evaporation (VTE)

- Most common method to date
- Simple
- Precise
- Multilayer structures possible
- Small molecules, not polymers
- Wasteful of materials
- High vacuum: 10^{-7} torr
- Oil-free pumps

