Advanced Computer Architecture

COMP 5123

Fall 2016

Computer Science Department

Prairie View A&M University

Mary Heejin Kim (aka Heejin Lim), Ph.D.

Chapter 4
Cache Memory

Memory System Characteristics

Location

Internal (e.g. processor registers, cache, main memory)

External (e.g. optical disks, magnetic disks, tanes)

Capacity

Number of words Number of bytes

Unit of Transfer

Word Block Access Method Sequential Direct Random

Associative

Performance

Access time Cycle time

Transfer rate **Physical Type**

Semiconductor Magnetic Optical

Magneto-optical

Physical Characteristics

Volatile/nonvolatile Erasable/nonerasable

Organization

Memory modules

3

1. Where are the memories?

- CPU
 - Register
 - Control Unit own memory
- Internal
 - Cache
 - RAM
- External
 - Disk
 - Tape

2. Capacity

- Measured in Bytes or Words
- Word size
 - The natural unit of organization
 - 8, 16, 32 bits
 - Typically
 - Word size = integer size (int in C = word size)
 - Word size = instruction size
- Addressable unit
 - Smallest location which can be uniquely addressed
 - · Mostly bytes, but may be word

5

3. Unit of Transfer

- Internal
 - Usually governed by data bus width
 - Equal to the number of electrical lines into and out of the memory module
 - Could be same size as word or larger (64, 128, 256 bits)
- External
 - Usually a block which is much larger than a word

4. Access Methods (1)

1. Sequential

- · Start at the beginning and read through in order
- Access time depends on location of data and previous location
- Uses shared read/write mechanism (i.e., only one location can be read at one time)
- e.g. Tape

2. Direct

- Shared read/write mechanism
- Individual blocks or records have unique address
- Access is by jumping to vicinity + sequential search, counting, waiting, etc.
- Access time depends on location and previous location
- e.g. Disk

7

4. Access Methods (2)

3. Random

- Dedicated read/write mechanism (not shared) for each addressable location
- Access time is independent of location or previous access = constant
- · e.g. Main memory, Cache

4. Associative

- Data is located by a comparison with contents of a portion of the store (Content-Addressable Memory, CAM)
- Access time is independent of location or previous access
- · e.g. Cache

5. Memory Performance

Access time (latency)

- Time between presenting the address and getting the valid data
- For non-random access memory, time to position the R/W head to the desired location

Memory Cycle time

- Cycle time is access time + recovery
- Time may be required for the memory to "recover" before next access
 - · Waiting for the transient signal to die out
 - · Regeneration of the destroyed content
 - · Concerned with the system bus, not the processor

Transfer Rate

- Rate at which data can be moved (bps)
- · For random access memory,
 - = 1/(cycle time) bps

ç

6. Physical Type, Characteristics

Types

- Semiconductor
 - Either volatile (RAM) or non-volatile (ROM)
- Magnetic surface (disk, tape)
- Optical (CD-ROM, DVD)
- Other (Flash, Bubble, Hologram)

Characteristics

- Volatile vs. Non-volatile
 - Volatile memory: Information is lost at power-off
- Erasable vs. Non-erasable
 - · Non-erasable memory cannot be altered (ROM, CD-ROM)

Memory Selection


- Want a fast machine?
 - It is possible to build a computer which uses only static RAM (SRAM)
 - This would be very fast, and need no cache
 - This would cost a lot of \$\$\$\$\$\$!
- Trade-off across different memory technologies
 - Faster, more expensive
 - Larger, less expensive, but slower
- Need to consider all
 - · Capacity (How much?)
 - Access time (How fast?)
 - Cost (How expensive?)
- How can you solve the dilemma?

11

Hint - Locality of Reference

- Locality
 - If it rains at PVAMU campus, it may rain at the Houston (spatial)
 - If it rained at PVAMU campus at 12:30PM, it may still rain at 12:45PM (temporal)
- During the course of the execution of a program, memory references tend to cluster
 - For both data and instructions
 - e.g. loops, subroutines, tables, arrays
 - Spatial locality
 - Temporal Locality
 - Processor tends to access memory locations that have been used recently
 - It will change over long time, but will be there for a short while

Memory Hierarchy - Diagram



- Cheaper
- Larger
- Slower
- Less frequently used by processor


13

2-level memory example

- Faster memory (smaller, expensive)
 - Currently accessed cluster
 - If the data/instruction is found, it is called hit. Otherwise, miss
- Slower memory (larger, cheap)
 - Contains whole data, program


Performance improvement with 2-level memory

- Level 1: 1000 words with **0.01us** (**T**₁)
- Level 2: 100,000 words with **0.1us (T₂)**
- 95% time → found in Level 1
- 5% time → need to access Level 2
 - Access time for 95% time =
 0.95 * 0.01 us = 0.0099
 - Access time for 5% time =0.05 * (0.01 us + 0.1 us) = 0.0055
- then average access time = 0.0095 + 0.0055 = 0.015 us
 Not bad!




Faster memory → Cache

- · Small amount of fast memory
 - SRAM (flip-flop), similar logic as processor, power-hungry
- Sits between normal main memory and CPU
- May be located on CPU chip or module




Location of Cache




17

The Differences


- · L1 cache
 - Operates at register speed (e.g. 0.3 ns for 3GHz speed)
 - Memory accesses within a single processor cycle
- · L2 cache
 - SRAM
 - Accessed within two to four processor cycle
- L3 cache
 - May reside on the motherboard (some have on-chip)
 - 8-10 ns
- Main memory
 - DRAM: around 50-60 nanoseconds
 - SDRAM: 2-10 ns after first slow access
- Hard disk
 - · Mechanical, slow






Cache Read Operation

- CPU requests contents of memory location
- Check cache for this data
- If present, get from cache (fast)
- If not present, read required block from main memory to cache
- Then deliver from cache to CPU (or do it in parallel)




Typical Cache Organization

 When cache hit occurs, data and address buffers are disabled, communication is only btw processor and cache.



11



Cache Design - Overview

Cache Addresses

Logical Physical

Cache Size

Mapping Function

Direct

Associative

Set Associative

Replacement Algorithm

Least recently used (LRU)

First in first out (FIFO)

Least frequently used (LFU)

Random

Write Policy

Write through

(b) Main memory

Write back

Write once

Line Size

Number of caches

Single or two level

Unified or split


Cache Addressing (1)

- Virtual memory
 - allows program to address memory from a logical point of view without regard to the amount of main memory physically available (chap 8).
 - memory management unit (MMU) translates each virtual address into a physical address in main memory
- Where does cache sit?
 - Between processor and MMU (logical cache)
 - Between MMU and main memory (physical cache)

25

Cache Addressing (2)

- Logical cache (virtual cache) stores data using virtual addresses
 - Processor accesses cache directly, not through MMU
 - Cache access faster, before MMU address translation
 - Same virtual address in two different applications refers to two different physical address
 - · Must flush cache on each context switch, or
 - · Extra bit to identify
- Physical cache stores data using main memory physical addresses



Size does matter

- Why small is better?
 - More cache is expensive
 - Use as little as possible
- Why larger is better?
 - More cache is faster thanks to higher hit ratio (up to a point)
 - Larger cache is slightly slower than smaller cache due to number of gates
 - Use as much as possible
- So where is the "optimum" size?

Comparison of Cache Sizes

Instr./data cache (Harvard arch)

Processor	Туре	Year of Introduction	L1 cache ^a	L2 cache	L3 cache
IBM 360/85	Mainframe	1968	16 to 32 KB	1-	_
PDP-11/70	Minicomputer	1975	1 KB	/ -	_
VAX 11/780	Minicomputer	1978	16 KB	/ -	_
IBM 3033	Mainframe	1978	64 KB	/ -	_
IBM 3090	Mainframe	1985	128 to 256 KB	-	_
Intel 80486	PC	1989	8 KB /	_	_
Pentium	PC	1993	8 KB/8 KB	256 to 512 KB	_
PowerPC 601	PC	1993	32 KB	_	_
PowerPC 620	PC	1996	32 KB/32 KB	_	_
PowerPC G4	PC/server	1999	32 KB/32 KB	256 KB to 1 MB	2 MB
IBM S/390 G4	Mainframe	1997	32 KB	256 KB	2 MB
IBM S/390 G6	Mainframe	1999	256 KB	8 MB	_
Pentium 4	PC/server	2000	8 KB/8 KB	256 KB	_
IBM SP	High-end server/ supercomputer	2000	64 KB/32 KB	8 MB	_
CRAY MTA ^b	Supercomputer	2000	8 KB	2 MB	_
Itanium	PC/server	2001	16 KB/16 KB	96 KB	4 MB
SGI Origin 2001	High-end server	2001	32 KB/32 KB	4 MB	_
Itanium 2	PC/server	2002	32 KB	256 KB	6 MB
IBM POWER5	High-end server	2003	64 KB	1.9 MB	36 MB
CRAY XD-1	Supercomputer	2004	64 KB/64 KB	1MB	_
					20

29


Latest Cache size

- P4 Extreme Edition (2003)
 - 8 KB L1 data + 12 KB L1 instruction
 - 512 KB L2
 - 2 MB L3
- Pentium Extreme Edition (2005)
 - 16 KB L1 data + 12 KB L1 instruction Per Core
 - 2 MB L2 Per Core
- Intel Core 2 (2006)
 - 64KB L1 per core
 - 4 MB L2
- Intel Core i7 (2008, 64-bit)
 - 256KB L2
 - 8MB L3
- IBM Power 4 series has a 256MB L3 cache shared among several processors
 - >\$1000

31

Cache information on your PC

- CPUID program
 - Download from http://www.cpuid.com/cpuz.php




Cache Mapping

Mapping Function

- Cache lines << memory blocks
 - Need to map memory block to cache
 - · Mapping algorithm
 - · Which memory block is in cache?
- 3 methods
 - 1. Direct
 - 2. Associative
 - 3. Set associative

33

Cache/Main Memory Structure Line Memory Block address Number Tag #blocks M=2n/K 0 0 Block (K words) Block Length Line size = block size (a) Cache = K words C << M Block Indicates where the block came from Word Length (b) Main memory 34



Cache mapping

- 1. Direct mapped
 - Only one place to go in cache
- 2. Fully associative
 - Anywhere to go in cache
- 3. Set associative
 - A memory block is mapped to a set
 - · Within a set, it can be assigned to anywhere
 - If the number of elements in a set is n, it is called n-way


Cache Mapping


1. Direct Mapping


37


1. Direct Mapping (The simplest)

- Each block of main memory maps to only one cache line
 - i.e. if a block is in cache, it must be in one specific place
- i = j modulo m
 - i = cache line number
 - j = main memory block number
 - m = number of lines in the cache
- Example
 - If there are 16 lines in the cache, the memory block 21 is assigned to cache line 5 (= 21 % 16)









Direct Mapping pros & cons

Good ☺

- Fixed location for given block
- Simple & inexpensive


Bad ⊗


- Fixed location for given block
- Competition for the same line
 - If a program accesses 2 blocks that map to the same line repeatedly, they get swapped continually
 - →high cache miss
 - Inefficient usage: cannot use other unused cache lines


4


A small trick - Victim cache

- Lowers cache miss penalty
- Discarded cache data is already fetched, so it can be used again quickly. (no memory access)
 - But where do we store it?
- Victim cache
 - A fully associative cache
 - 4 to 16 cache lines
 - Between direct mapped L1 cache and next level of memory









Set Associative Mapping

- v sets, each with k lines
- m = total number of lines in the cache
- Extreme case 1
 - v=m, k=1 → direct mapping
 - number of sets = number of total cache lines
 - 1 line per each set
- Extreme case 2
 - v=1, k=m → fully associative mapping
 - · only 1 big set
 - · m lines for this big set
- What k is best?
 - 2~8 lines per set is most common

4

Replacement Algorithms

- Associative & Set Associative
- Least Recently Used (LRU)
 - replace block that has been in cache longest with no reference to it
 - e.g. in 2-way set associative: USE bit
 - Best hit ratio
- First In First Out (FIFO)
 - replace block that has been in cache longest
 - · Easy to implement with RR or circular buffer
- Least Frequently Used (LFU)
 - replace block which has had fewest hits
 - · Use a counter for each line
- Random
 - not intuitive? It is shown not bad
- Must be implemented in Hardware for speed

Write policy - Handling Writes

- What if a cache line has been modified?
 - There will be inconsistency between cache and memory
 - If you pick this cache line for replacement, you cannot just overwrite it unless its main memory is updated
- How do we avoid inconsistency?
 - Always write data on both cache and memory: Write-through
 - Copy the modified cache to memory only when the line is replaced: Write-back

51

Write Policy 1 - Write through

- Simplest solution
- All writes go to main memory as well as cache
 - Main memory is also up to date
- Disadvantages
 - Lots of traffic. All write traffic must go to memory.
 - Slow. Cache is basically useless for writing.
- How slow?
 - In SPEC2000, 10% are store instructions. If it requires 100 clock cycles for memory write, the CPI (Cycles Per Instruction) for write

$$= 1 * 90\% + (1 + 100) * 10\% = 11$$

Write Policy 2 - Write back

- Updates initially made in cache only (no memory write)
 - **Update** bit for cache line is set when update occurs
 - If block is to be replaced, write to main memory only if update bit is set
- Disadvantages
 - Discrepancy exists between cache and memory for some duration
 - Requires complex circuitry, and potential bottleneck

53

Issues with Policy 2 (Write back)

- Competition with I/O (DMA)
 - Option1: I/O (DMA) must access the main memory through cache (no one writes directly on memory. Cache change is first)
 - Option 2: I/O (DMA) may address main memory directly. If the matching cache content is modified, the memory is invalid, and I/O module should not write on memory, and vice versa
- Multiple processors may have individual caches
 - Each processor changes only its own cache. Whose cache is correct?
 - Cache coherence problem

Which is better?

- Write through or Write back?
 - write-back seems better, but it depends on the frequency of write operation
 - If write is infrequent, write-through may be faster!
- N.B. 15% of memory references are writes. For highperformance computing (HPC), 33% or even 50%.

55

Comparison example

- Assumptions
 - Each word = 4 bytes
 - 30 ns for 4-byte word transfer
 - Cache line (block) size = 32 byte = 8 words
 - i.e., total transfer time for each block = 8 words * 30 ns = 240 ns
- Which is better between write-through and write-back?
 - · For each write operation, they spend
 - Write-back (must write entire block of 8 words): 240 ns
 - Write-through (can write individual word):
 - If a cache line gets written more than 8 times before swap-out, write-back is better. (always 240 ns)
 - Easier answer: Each line is 8 words, and the unit of transfer is word. So the decision threshold is 8 words.