





LightGuard Monitor



🛞 a **Carmanah** company




Web based AtoN monitoring and control?



LightGuard Monitor: LightGuard Hub




- Windows Server
- .NET Framework 4.5.2
- ASP.NET 4.5.1
- Firebird RDB
- RESTful-API





LightGuard Monitor: Stations

SABIK OFFSHORE




















LightGuard Monitor: Cellular Network

- Sierra Wireless AirPrime® Q and SL Series
- OpenAT OS 6.37 resp. 6.54
- WIP 5.43 resp. 5.58
- Security 1.5.0 resp. 2.2.2










LightGuard Monitor: Cellular Network Vodafone




SIM management
 https://m2mprdgui.vodafone.com/GDSPGui/login.htm

PUSH through Vodafone API





LightGuard Monitor: 3rd Party Cellular Network



PUSH through Esendex' messaging service



LightGuard Monitor: Authentication



- Safe Login Procedure
- P* =
 SHA256(SHA256(password) +
 salt)
- Optional: SSL Encryption









LightGuard Monitor: Push, Poll, Command


- commands trigger a push
- configuration changes trigger a push
- stations wake up on reception of push notifications
- stations contact the server after woken up








LightGuard Monitor: Globalstar





LightGuard Monitor: Inmarsat






LightGuard Monitor: Station



- stations in cellular networks are unique by its IMSI
- stations in Globalstar telemetry network are unique by its ESN
- stations in Inmarsat satellite network are unique by its mobile ID









LightGuard Monitor: Station Data & Layout

- set of station data is static
- layout is a subset of station data
- product types are generated from layouts
- first, create the layout
- afterwards, create a new product type
- finally, create new stations

	ID	DIGITS	PARAMID	NAME	ICON	UNIT	CHART	READONLY	SPACE
C	1	0	STA_BEACMODE	Light Status	Beacon		Bar	1	SET:Active Inactive
	2	0	STA_BEACFAIL	Lantem Health Status	Beacon		Bar	1	ERROR_INDICATOR
	3	0	STA_PHOTOVAL	Photocell Value	Beacon	bc	Line	1	RANGE:0:1:1000
	4	0	STA_BEACOPHOURS	Operation Hours	Beacon	h	Line	1	RANGE:0:1:10000000
	5	0	STA_LOWBATT	Battery	Battery		Bar	1	ERROR_INDICATOR
	6	2	STA_BATTVOLT	Battery Voltage	Battery	V	Line	1	INTERVAL:0/47.5
	7	2	STA_BEACPOWER	Power Consumption	Battery	W	Line	1	INTERVAL:-237.5/237.51
	8	2	STA_SOLARMAX	Solar Current Max.	Solar Details	A	Bar	1	INTERVAL:0/16.8
	9	2	STA_SOLAR24H	Solar Ah Last 24h	Solar Details	Ah	Bar	1	INTERVAL:0/400
	10	1	STA_SOLARAH	Total Solar Ah	Solar Details	Ah	Line	1	INTERVAL:0/80000
	11	0	STA_DAYTONIGHT	Last Night Transition	Day to Night		InvBar	1	DATE
	12	0	STA_NIGHTTODAY	Last Day Transition	Night to Day		InvBar	1	DATE
	13	0	STA_OFFLOC	Location	Position		Bar	1	ERROR_INDICATOR
	14	7	STA_GPSLAT	GPS Latitude	Position	deg	0	1	INTERVAL:-90/90
	15	7	STA_GPSLON	GPS Longitude	Position	deg	0	1	INTERVAL:-180/180
	16	0	STA_DISTFIX	Distance from Fix	Position	m	Line	1	RANGE:0:1:10000000
	17	0	STA_GPSFAIL	GPS Status	Communication		Bar	1	ERROR_INDICATOR
	18	1	STA_TEMP	Avg. Temperature	Temperature	С	Line	1	INTERVAL:-55/125
	19	1	STA_TEMPMAX	Max. Temperature	Temperature	С	Line	1	INTERVAL:-55/125
	20	1	STA_TEMPMIN	Min. Temperature	Temperature	С	Line	1	INTERVAL:-55/125
	21	0	STA_POWERCYCLES	Power Cycles	Counters			0	RANGE:0:1:255
	22	0	STA_PRODCODE	Product Code	Product Details			0	REGEX:^[a-zA-Z0-9:]+\$
	23	2	STA_HDSOFTVER	SMC Software Ver	Product Details			0	REGEX:^[0-9]+(\.[0-9]+)?\$
	24		STA_GSMSOFTVER	GSM Software Version	Product Details			1	REGEX:^[a-zA-Z0-9:]+\$
	25	0	STA_GSMFIRMVER	GSM Firmware Version	Product Details			0	REGEX:^[a-zA-Z0-9:]+\$
	50	0	CFG_BEACMODE	Light Mode	Light Automation		0	0	SET:Photocell Only/Astro GPS Checkup/C
	51	0	CFG_INTENSITY	LED Intensity	Beacon	%	0	0	RANGE:5:1:100
	52	0	CFG_DISTFIX	Max. Distance from Fix	Position	m	0	0	INTERVAL:0/1000
	53	7	CFG_FIXLAT	Fix Latitude	Position	deg	0	0	INTERVAL:-90/90
									,











- each license comes with a fixed and immutable number of credits
- one credit equals one received Globalstar STU message
- licenses can expire, but only if they're not completely used up before expiration








LightGuard Monitor: Licensing



LightGuard Monitor: User Ranks



- Read-Only User
- Read-Write User
- Station
- Gateway
- Super-User
- LightGuard Backend
- Admin









LightGuard Monitor: Apps


Admin Interface



Winterface



Web App




iOS App







LightGuard Monitor



LightGuard Monitor



