Indusoft/Aveva

Download & Checking License

Download AES 2020 Zip File

Execute the setup application file

Need to have internet access to download all required libraries


If you have a softkey: You will need to set up the Network adapter.

Softkey is linked to the NIC card.

Go to AVEVA Register > change license > get Moos your Hardware identifier so you can get an access code.


Hardkey:

Go to Aveva Edge Register




If you have physical hardkey.


1. Select the radio button and click Check



2. Click yes



3. Change License... Note: Runtime



Note: Engineering

When setting up a project.

Run time keys for local HMIs. No edit access. Also allows app to run none-stop Engineering allows edit access but will stop the app every 3 days.