A2000 CPU slot socket adapter

ECLK

100nF

1N4148W

BUBBY!

Rear of
A2000 →

Based on work by Kipper2K
and OpenAmiga2000CoproAdapter by SukkoPera
Licensed under CERN OHL version 1.2

Board by Chris Hooper
http://eebugs.com/amiga/a2000cpuslot
http://github.com/cdhooper/a2000cpuslot

GND
BOSS
INT7
INT6
INT2
OVR

Top row labels (left to right):
D4 D3 D2 D1 D0 AS UDS LDS R/W DTACK BG BGACK BR VCC CLK GND HLT RST VMA E VPA BERR /IPL2 /IPL1 /IPL0 FC2 FC1 FC0 A1 A2 A3 A4

Top row numbers: 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32

Bottom row numbers: 64 63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 35 34 33

Bottom row labels: D5 D6 D7 D8 D9 D10 D11 D12 D13 D14 D15 GND A23 A22 A21 VCC A20 A19 A18 A17 A16 A15 A14 A13 A12 A11 A10 A9 A8 A7 A6 A5

Bottom edge numbers: 85 83 81 79 77 75 73 71 69 67 65 63 61 59 57 55 53 51 49 47 45 43 41 39 37 35 33 31 29 27 25 23 21 19 17 15 13 11 9 7 5 3 1

Bottom edge labels: XRDY VC1 VC3 CFGIN 12V -5V 5V GND