SOFTWARE SETUP

Simstarter NG Profile: Delta VATSIM

CABIN

Pilot Tube Cover: REMOVE

Pilot's Operating Handbook: AVAILABLE Airplane Weight and Balance: CHECKED

Parking Brake: SET

Control Wheel Lock: REMOVE

Ignition Switch: OFF

Avionics Master Switch: OFF

Master Switch: ON

Fuel Quantity Indicators: CHECK Avionics Master Switch: OFF

Static Pressure Alternative Source Valve: OFF

Annunciator Panel Switch: TEST Fuel Selector Valve: BOTH Fuel Shutoff Valve: ON

Flaps: EXTEND Pitot Heat: ON Pitot Heat: OFF Master Switch: OFF

Elevator Trim: SET FOR TAKEOFF

Baggage Door: CHECK

Aitopilot Static Source Opening: CHECK

BEFORE STARTING ENGINE

Preflight Inspection: COMPLETE Passenger Briefing: COMPLETE

Seats and Seat Belts: ADJUST and LOCK

Brakes: TEST and SET Circuit Breakers: CHECK IN Electrical Equipment : OFF Avionics Master Switch: OFF Fuel Selector Valve: BOTH Fuel Shutoff Valve : ON

Avionics Circuit Breakers: CHECK IN

BATTERY ENGINE START

Throttle: OPEN 1/4 INCH Mixture: IDLE CUTOFF Propeller Area: CLEAR Master Switch: ON Flashing Beacon: ON Auxiliary Fuel Pump: ON

Mixture: FULL RICH UNTIL STABLE FUEL FLOW

Auxiliary Fuel Pump: OFF

Ignition: START

Mixture: ADVANCE SMOOTHLY TO RICH

Oil Pressure: CHECK

Navigation Lights: AS REQUIRED

Electrical System : CHECK - Master Switch: OFF

- Taxi and Landing Light Switches: ON

– Engine RPM : REDUCE - Master Switch: ON

- Engine RPM: INCREASE

- Ammeter and Low Voltage Annunciator : CHECK

Avionics Master Switch: ON

Radios: ON Flaps: RETRACT Mixture: LEAN

BEFORE TAKEOFF

Parking Brake: SET Seat Backs: UPRIGHT

Seat and Seat Belts: CHECK SECURE Cabin Doors: CLOSED AND LOCKED Flight Controls: FREE AND CORRECT

Fuel Quantity: CHECK

Mixture: RICH

Fuel Selector Valve: RECHECK BOTH

Throttle: 1800 RPM Magnetos : CHECK

Vacuum Gauge : CHECK

Engine Instruments and Ammeter : CHECK

Annunciator Panel: CHECK Throttle: CHECK IDLE

Throttle: 1000 RPM OR LESS Throttle Friction Lock: ADJUST Strobe Lights: AS DESIRED Radio and Avionics: SET NAV/GPS Switch: SET

Autopilot: OFF

Elevator Trim: SET FOR T/O

Flaps: SET FOR T/O Brakes: RELEASE

NORMAL TAKEOFF

Flaps: 0-10

Throttle: FULL OPEN

Mixture: RICH

At 55 KIAS, ROTATE

Climb Speed: 70-80 KIAS

Flaps: RETRACT

SHORT FIELD TAKEOFF

Flaps: 10

Brakes: APPLY

Throttle: FULL OPEN

Mixture: RICH Brakes: RELEASE Elevator: TAIL LOW

Climb Speed: 57 KIAS UNTIL OBSTACLES CLEARED

Flaps: RETRACT at 60 KIAS

ENROUTE CLIMB

Airspeed: 70-85 KIAS Throttle: FULL OPEN

Mixture: LEAN ABOVE 3000' MSL

CRUISE

Power: 2000-2400 RPM

Mixture: LEAN

DESCENT

Power : AS DESIRED Mixture : ADJUST Altimeter : SET

NAV/GPS switch : SET Fuel Selector Valve : BOTH

Flaps: AS DESIRED

- 0-10 below 110 KIAS

- 10-30 below 85 KIAS

BEFORE LANDING

Seat Backs : UPRIGHT Fuel Selector Valve : BOTH

Mixture: RICH

Landing/Taxi Lights: ON

Autopilot: OFF

NORMAL LANDING

Airspeed: 65-75 KIAS (Flaps Up)

Flaps: AS DESIRED

- 0-10 below 110 KIAS

- 10-30 below 85 KIAS

Airspeed: 60-70 KIAS (Flaps Down) Touchdown: MAIN WHEELS FIRST

Landing Roll: LOWER NOSE WHEEL GENTLY

Braking: MINIMUM REQUIRED

SHORT FIELD LANDING

Airspeed: 65–75 KIAS (Flaps Up)

Flaps: FULL DOWN Airspeed: 62 KIAS

Power: IDLE AFTER CLEARING OBSTACLE

Touchdown: MAIN WHEELS FIRST

Landing Roll: LOWER NOSE WHEEL GENTLY

Braking: APPLY HEAVILY

Flaps: RETRACT

BALKED LANDING

Throttle: FULL OPEN
Flaps: RETRACT TO 20
Climb Speed: 55 KIAS

FLAPS: 10 UNTIL OBSTACLES CLEARED

FLAPS: RETRACT AT 60 KIAS

AFTER LANDING

Flaps: UP

SECURING AIRPLANE

Parking Brake: SET

Electrical Equipment: OFF

Autopilot: OFF

Avionics Master Switch: OFF Mixture: IDLE CUT OFF Ignition Switch: OFF Master Switch: OFF Control Lock: INSTALL

Fuel Selector Valve: LEFT or RIGHT