

INDUSTRY INSIGHT · HOME CINEMA

10 Costly Pitfalls to Avoid in *Home Cinema Design*

*An Architect's **blueprint**.*

Practical, design-stage guidance on the oversights most likely to compromise a home cinema before it is ever built — aligned to CEDIA RP22.

FOR ARCHITECTS

— FOR THE ARCHITECT

Architectural *considerations.*

Ten pitfalls — and the steps to avoid each one — applied at sketch stage, where the cost of getting them wrong is lowest.

01

Prioritise Optimal Room Shape to Enhance Acoustics

DETAILED INSIGHT

The shape of the room is foundational to acoustic performance. Rectangular rooms are preferred because they allow better management of sound waves, reducing standing waves and echoes. Square or corridor-shaped rooms create uneven sound distribution; trapezoidal or circular rooms complicate acoustic treatment.

STEPS TO AVOID

- i* Design rectangular. Adhere to the recommended ratio of 1.15–1.45:1 (length:width) per CEDIA RP22.
- ii* Plan for treatment. Reserve wall and ceiling area for absorption and diffusion at design stage, not retrofit.
- iii* Avoid awkward geometries. Trapezoidal, circular and irregular plans add cost and reduce acoustic predictability.

02

Strategically Position Doors to Maintain Audio Integrity

DETAILED INSIGHT

Doors placed at the back or side walls of the seating area disrupt layout, compromise speaker placement and degrade audio performance. Ambient light from these doors also affects screen contrast and the immersive experience.

STEPS TO AVOID

- i* Site within the front 2/5. Position the entrance door within the front 2/5 of the side wall, swinging away from the screen.
- ii* Specify acoustic doors. Specify soundproof flush doors with an STC rating of at least 65. Avoid barn or pocket doors.
- iii* Introduce a lobby trap. For optimal acoustic isolation, introduce a room lobby trap at the cinema entrance.

03

Eliminate Windows to Preserve Sound and Light Control

DETAILED INSIGHT

Windows compromise both sound isolation and light control, leading to degraded audio quality and screen contrast. They also allow external noise to infiltrate the cinema space — an immediate failure of the brief.

STEPS TO AVOID

- i* Remove where possible. Design the cinema room without external windows wherever the brief allows.
- ii* Use soundproof glass. Where windows are architecturally necessary, specify soundproof glazing with a high STC rating.
- iii* Block permanently. Block windows with solid panels to prevent light intrusion and protect screen contrast.

04

Choose the Right Location to Minimise Noise Interference

DETAILED INSIGHT

The location of the home cinema within a house affects sound transmission and the potential for disturbance. Proximity to noise-sensitive areas such as bedrooms leads to complaints in service and demands costly soundproofing remediation after handover.

STEPS TO AVOID

- i* Default to basement. Basement locations naturally offer better sound isolation.
- ii* Avoid sensitive adjacencies. Do not site the cinema room adjacent to bedrooms, studies, or external noise sources such as busy streets.
- iii* Consider neighbouring use. Account for the function of adjoining rooms to minimise sound transmission paths.

05

Design Without Centre Aisles to Preserve the Sweet Spot

DETAILED INSIGHT

A centre aisle eliminates the optimal listening and viewing position — the sweet spot — which is the reference point for the entire audio and visual system design. Compromise this position and the system cannot deliver its specified performance.

STEPS TO AVOID

- i* Specify side aisles. Use side aisles to keep a clear central seating area at the sweet spot.
- ii* Maintain aisle width. Hold aisles at 600–800mm to preserve accessibility and comfort without sacrificing the prime position.
- iii* Coordinate with seating layout. Resolve aisle and seating layout together at design stage, not as a retrofit.

06 Ensure Adequate Headroom for Acoustics and Comfort

DETAILED INSIGHT

Sufficient headroom contributes directly to better sound dispersion and ensures unobstructed sightlines. Low ceilings hinder acoustic performance and create a cramped viewing experience that undermines the luxury intent of the room.

STEPS TO AVOID

- i Minimum 3m headroom. Design the room with a minimum overall headroom of 3 metres.
- ii 2.7m at the back row. Ensure risers provide at least 2.7 metres of clearance for the back row.
- iii Plan ceiling treatment. Reserve adequate ceiling depth for absorption, diffusion and ceiling speaker positions.

07 Position Seats Away from Walls to Optimise Sound Quality

DETAILED INSIGHT

Seating too close to walls leads to poor sound quality — speakers may be too near listeners, affecting dispersion and clarity, and wall proximity introduces reflections that interfere with audio fidelity at the seat.

STEPS TO AVOID

- i 600mm from side walls. Maintain a minimum clearance of 600mm between seats and the side walls.
- ii 500mm from the back wall. Maintain a minimum clearance of 500mm between the back row and the rear wall.
- iii Coordinate with speaker layout. Resolve seating clearances and speaker positions together — both depend on the same dimensions.

08 Maintain Proper Distance from Screen for Visual Comfort

DETAILED INSIGHT

Placing seats too close to the screen causes visual fatigue and discomfort. Viewers find themselves constantly adjusting their gaze to follow the action — the immersion the room is built for breaks down.

STEPS TO AVOID

- i Cap horizontal viewing angle at 65°. The horizontal viewing angle for 4K/UHD playback should not exceed 65 degrees.
- ii 3m minimum from the screen. Begin seating at least 3 metres from the screen to prevent visual strain.
- iii Verify with the AV designer. Confirm the throw distance, screen size and seating geometry as a single coordinated set.

09 Design Spacious Seat Risers for Luxury and Comfort

DETAILED INSIGHT

Narrow seat risers limit comfort and accessibility, which is particularly costly in luxury home cinemas where spacious recliner seating is the expected standard. Adequate riser depth is necessary to accommodate proper recline travel and personal space.

STEPS TO AVOID

- i 1.8–2m riser depth. Design risers with a depth of 1.8 to 2 metres.
- ii Add 300mm at the last row. Add a further 300mm of depth at the last row to accommodate full recline.
- iii Plan for cable infrastructure. Reserve riser depth for power, control and convenience outlets at the seat.

10 Create a Dedicated Projector Room to Minimise Noise

DETAILED INSIGHT

Placing AV equipment — including projectors — within the cinema room introduces ambient noise and heat that detract from the cinematic experience. The equipment is also visually intrusive in a room whose entire premise is immersion.

STEPS TO AVOID

- i Dedicated projector room. Design a dedicated projector room adjacent to the back wall of the cinema.
- ii Centralise AV equipment. Site receivers, amplifiers, the AV rack and HVAC equipment in this room, secured and ventilated.
- iii Use an acoustic projection port. Beam the projector through an acoustically isolated port to the screen, preserving room acoustics.

SOUNDHOUS · REFERENCE HOME CINEMA · LAGOS

— FROM THE FIELD

Where architecture becomes *cinematic experience*.

Soundhous Experience Store, Lagos. A reference home cinema where every architectural decision in this article is visible — rectangular geometry, side-aisle layout, recliner riser depth, ceiling treatment, and the absence of any compromise.

— A CLOSING WORD

Designed across disciplines. *Built only once.*

A home cinema is the product of decisions made by architects, MEP consultants, interior designers, structural engineers and AV specialists — usually in that order, often in isolation. The discipline that arrives last inherits the constraints set by those that arrived first. The ten pitfalls in this article are the ones we see most often when called in to retrofit, remediate, or rescue. Each is preventable. None is expensive at design stage. All become costly, and several become structurally impossible, after handover.

This guidance aligns to CEDIA RP22 — the international standard for residential cinema design — which we recommend as the reference document for any consulting team approaching a luxury home cinema brief.

VISIT THE REFERENCE CINEMA

Don't just read about it. *Hear it for yourself.*

The principles in this article are not theoretical. They are demonstrated, measured and operating every day inside the Soundhouse Experience Store in Victoria Island — CED Africa's reference home cinema. We invite architects and design teams to visit, sit in the room, and experience what design at this standard sounds like.

SOUNDHOUSE EXPERIENCE STORE

17 Adeyemo Alakija Street
Victoria Island, Lagos

BOOK A VISIT

soundhouse.com
+234 902 754 9690

COMPANION ARTICLE

A companion article — A Mechanical, Electrical & Plumbing Consultant's blueprint for the perfect home cinema — is available for the MEP decisions that complete the work begun in this document. Available on request from CED Africa.

Published By

CED Africa · AV Design Studio
24A Providence Street, Lekki Phase 1, Lagos

REFERENCE

Aligned to CEDIA RP22

Begin a Conversation

design@ced.africa
+234 808 666 2168

ONLINE

www.ced.africa