

INDUSTRY INSIGHT · HOME CINEMA

10 Costly Pitfalls to Avoid in *Home Cinema Design*

*A Mechanical, Electrical &
Plumbing Consultant's **blueprint**.*

*Practical, design-stage guidance on the oversights most likely to
compromise a home cinema before it is ever built — aligned to
CEDIA RP22.*

FOR MECHANICAL, ELECTRICAL & PLUMBING CONSULTANTS

— FOR THE MEP CONSULTANT

Mechanical, Electrical & Plumbing *considerations.*

Ten pitfalls — and the steps to avoid each one — applied at design stage, not retrofitted at handover.

01 Placing the HVAC Indoor Unit Within the Room

DETAILED INSIGHT

The indoor unit is the main component for temperature regulation, but it emits a noticeable clicking sound when cycling on and off — and a low hum or vibration that resonates through the room. In a home cinema environment where silence is golden, this sound is particularly disruptive.

STEPS TO AVOID

- i Plan early. During initial design, designate a separate room for the HVAC unit — a projector or equipment room.
- ii Use insulated ducts. Install insulated ductwork to channel air from the HVAC unit to the cinema, minimising noise transmission.
- iii Consult acoustics experts. Work with acoustics professionals to ensure placement minimises noise impact.

02 Avoid Positioning HVAC Vents to Obstruct Speaker Positions

DETAILED INSIGHT

Strategic speaker placement is vital for the desired sound quality and immersive experience. Ceiling speakers in particular require precise positioning according to industry standards like CEDIA RP22, which specifies angles and distances for optimal performance. HVAC vents must not interfere with these placements.

STEPS TO AVOID

- i Collaborate with audio designers. Coordinate with audio specialists to determine optimal speaker placements early in the design process.
- ii Design flexible duct layouts. Create a ducting plan that adapts to the audio layout without compromising acoustics.
- iii Review industry standards. Familiarise yourself with CEDIA RP22 to understand required speaker positioning.

03

Designing Acoustically Compliant HVAC Ducting

DETAILED INSIGHT

Airflow noise from HVAC systems can degrade the acoustic environment of a home cinema. Ducts should be oversized to reduce air velocity, which in turn reduces noise. Multiple 90-degree bends help dampen sound waves. Linear vent grilles spread airflow over a larger area, reducing the perception of noise and creating an even distribution of air.

STEPS TO AVOID

- i* Oversize ducts. Design ducts larger than standard to reduce air velocity and noise.
- ii* Incorporate bends. Include up to three 90-degree bends in the ductwork to act as silencers.
- iii* Select proper vent grilles. Use linear vent grilles to distribute airflow quietly and evenly across the room.

04

Avoid Plumbing Pipes Passing Through the Cinema Ceiling

DETAILED INSIGHT

The sound of water flowing through pipes can be distracting and undermine the cinematic experience. Plumbing should be routed away from the cinema ceiling. Where unavoidable, pipes should be enclosed in soundproofing materials and isolated from the building structure to prevent vibration transmission.

STEPS TO AVOID

- i* Reroute plumbing. Plan plumbing routes to avoid the cinema ceiling, using alternative paths where possible.
- ii* Use soundproofing materials. If pipes must pass near the cinema, enclose them in soundproofing materials to minimise noise.
- iii* Isolate pipes. Ensure pipes are isolated from the building structure to prevent vibration transmission.

05

Isolate All Adjoining Mechanical Equipment

DETAILED INSIGHT

Mechanical equipment such as washing machines, HVAC compressors and pumps transmit vibrations and noise through walls and floors. These vibrations are especially problematic in a home cinema, where low-frequency sound is crucial for the immersive audio experience.

STEPS TO AVOID

- i* Use resilient mounts. Install resilient mounts and isolation pads for all mechanical equipment to reduce vibration transmission.
- ii* Conduct vibration analysis. Identify potential noise sources and address them proactively.
- iii* Schedule regular maintenance. Keep isolation measures effective over time.

06 HVAC Wall Thermostat Position and Finish

DETAILED INSIGHT

Aesthetics play a significant role in the overall experience of a home cinema. Standard thermostats clash with the sophisticated design of a cinema room. Consider integrating thermostats with the room's lighting control system for a cohesive look.

STEPS TO AVOID

- i Coordinate with interior designers. Select thermostats that match the room's aesthetics.
- ii Integrate with control systems. Tie thermostats into lighting and control systems for a seamless interface.
- iii Explore custom options. Specify custom finishes and designs aligned with the cinema's décor.

07 No AC Units Over AV Equipment

DETAILED INSIGHT

Positioning AC units or plumbing over AV equipment poses a risk of water damage in the event of a leak. The result is costly repairs and equipment replacement — and avoidable downtime in a system the client uses for personal pleasure.

STEPS TO AVOID

- i Plan mechanical layouts carefully. Position AC units and plumbing away from AV equipment during the design phase.
- ii Install drip trays. Use drip trays and leak-detection systems as additional safeguards.
- iii Conduct regular inspections. Verify there are no leaks or potential issues with AC units.

08 Earth Bonding for All AV Equipment and Panels

DETAILED INSIGHT

Electromagnetic interference affects the performance of AV equipment, introducing noise and degrading audio quality. Proper earth bonding is essential to minimise these effects — and to keep the system reliable over its full operational lifetime.

STEPS TO AVOID

- i Install a dedicated earth bond bar. Provide a dedicated earth bond bar at the AV rack and lighting panel.
- ii Conduct regular testing. Verify the effectiveness of the grounding system on a planned schedule.
- iii Coordinate with electrical contractors. Implement an effective grounding strategy from first-fix.

09

UPS Power for All AV Racks and Enclosures

DETAILED INSIGHT

The home cinema must be powered by a central UPS or online inverter system with the capacity to drive power-hungry amplifiers at peak performance. All AV equipment should pass through a power conditioner to clean out overvoltage, brownouts, earth leakage and other forms of performance degradation. Furman power conditioners are particularly reliable in Nigerian conditions. A central UPS or inverter system also provides a stable supply, protecting equipment from surges and allowing orderly shutdowns during extended outages.

STEPS TO AVOID

- i* Select an appropriate UPS system. Choose a UPS or inverter sized to handle peak power demand at full performance.
- ii* Use power conditioners. Integrate power conditioners to deliver clean, stable supply to all AV equipment.
- iii* Schedule maintenance and testing. Confirm the UPS system is operating correctly across its lifecycle.

10

Observe Experiential Home Cinema Lighting Scenes


DETAILED INSIGHT

The home cinema must provide four basic lighting functions — task, ambient, accent, and theatrical (DMX). Each light group must be integrated into the AV control system using a smart lighting control sub-system. Movie playback can be tied to lighting scenes — the lights dim down when the play button is pressed on the AV remote, and lift back up when the film ends.

STEPS TO AVOID

- i* Integrate smart lighting control. Specify a control system capable of managing the four functional lighting layers.
- ii* Coordinate with AV systems. Tie the lighting system into the AV control system for seamless operation.
- iii* Design for flexibility. Plan for multiple lighting scenes adjustable to user preference and on-screen content.

SOUNDHOUS · REFERENCE HOME CINEMA · LAGOS



FROM THE FIELD

Where MEP discipline
becomes *cinematic experience*.

Soundhous Experience Store, Lagos. A reference home cinema where every
MEP decision in this article is visible — and audible.

— A CLOSING WORD

Designed across disciplines. *Built only once.*

A home cinema is the product of decisions made by architects, MEP consultants, interior designers, structural engineers and AV specialists — usually in that order, often in isolation. The discipline that arrives last inherits the constraints set by those that arrived first. The ten pitfalls in this article are the ones we see most often when called in to retrofit, remediate, or rescue. Each is preventable. None is expensive at design stage. All become costly, and several become structurally impossible, after handover.

This guidance aligns to CEDIA RP22 — the international standard for residential cinema design — which we recommend as the reference document for any consulting team approaching a luxury home cinema brief.

VISIT THE REFERENCE CINEMA

Don't just read about it. *Hear it for yourself.*

The principles in this article are not theoretical. They are demonstrated, measured and operating every day inside the Soundhouse Experience Store in Victoria Island — CED Africa's reference home cinema. We invite MEP consultants and design teams to visit, sit in the room, and experience what design at this standard sounds like.

SOUNDHOUSE EXPERIENCE STORE

17 Adeyemo Alakija Street
Victoria Island, Lagos

BOOK A VISIT

soundhouse.com
+234 902 754 9690

COMPANION ARTICLE

A companion article — An Architect's blueprint for the perfect home cinema — is available for the architectural decisions that frame the work in this document. Available on request from CED Africa.

Published By

CED Africa · AV Design Studio
24A Providence Street, Lekki Phase 1, Lagos

REFERENCE

Aligned to CEDIA RP22

Begin a Conversation

design@ced.africa
+234 808 666 2168

ONLINE

www.ced.africa