



# RF-L4040

## User Manual

### 1. Product Description

RF soft label for retail anti-theft protection

Single use only (not reusable)

Suitable for department store items, boxed cosmetics, books, CDs/DVDs, and other valuable packaged products

Do not attach directly to metal, foil, or metallic packaging

### 2. How It Apply

Attach the label to the product, ensuring it is flat and secure

Avoid metal or foil surfaces to maintain detection effectiveness.

### 3. At Checkout

- a) Scan the product barcode or complete checkout.
- b) Place the item on the RF deactivator/demagnetizer.
- c) Wait for the beep — label is deactivated.
- d) Product can leave the store safely.

### 4. Notes

Single-use only — cannot be reused.

Use only with compatible RF EAS systems.

Avoid bending or damaging the label.