This document explains how to set up dial up connection for a CDMA EVDO Data card running Windows Vista.


# **Preparation**


### Requirements


- ✓ Windows Vista pre-installed on your computer
- ✓ Administrator privileges on the Windows Vista machine.
- ✓ Activated Data Card "Modem"
- ✓ Network Coverage

## Setup

When you have met all these requirements, follow these steps to perform the installation and configuration.









This will allow you to connect to the network. In order to use the internet, you must do one more step.

# Add APN to modem initialization string.




### **Connect**



### **Disconnect**

Network Connection in System Tray | Right Click | Disconnect from




Or

To disconnect, **double click** on the desktop shortcut icon for your dialup connection to open connection status and click on **Disconnect**.



Or

Go to Start | Connect To | Select Device | Disconnect.



## **Troubleshooting**

LED provides good diagnostic information.

# LED Indicator

LED not lit	No Power to Card - physical - driver or conflict
LED <i>RED</i>	Card can not acquire CDMA service (outside coverage area)
LED GREEN After a few seconds – flashing 1 per second	Card is registered with a CDMA network - does not require * CM to be running *CM - Connection Manager
LED <i>ORANGE</i>	Card Fault – replace card


If the LED is not lit, then check that the device is connected properly. If physical connection seems good, then check for the device in the device manager.

### Device Manager

Verify that your device is found in Device Manager without Red 'X's or Yellow Triangles with '!". If these conditions show, then there is a driver problem or device conflict

When you insert your Novatel Wireless device into your computer, Windows will double ding and popup messages indicating new hardware found. Please note any error or warning messages that may popup.

To get Hardware Device Manager Information



- Click '+' to expand a device type
  - Highlight device (left click)
  - Right Click Select Properties (left click)

Please check one of the following sections appropriate for your device

# Ovation USB Devices


MC727 MCD3000

U727 U720

USB727 USB720

#### 2 Devices Must show

- Modem Section Novatel Wireless Merlin CDMA EV-DO Modem
- Ports Section Novatel Wireless Merlin CDMA EV-DO Status Port (COM# will vary by system)



- Depending on the device and options available, other Novatel Wireless Merlin ports may also show.
- The 'Safely Remove Device' icon may not show in system tray not required for this device


# ExpressCard Devices

X720 EX720 V720

V640 XV620

#### 2 Devices Must show


- Modem Section Novatel Wireless Merlin CDMA EV-DO Modem
- Ports Section Novatel Wireless Merlin CDMA EV-DO Status Port (COM# will vary by system)




- Depending on the device and options available, other Novatel Wireless Merlin ports may also show.
- The 'Safely Remove Device' icon may not show in system tray not required for this device

#### Note

- if you are using a ExpressCard-PCMCIA adapter, you will also see ⊕ ♣ System devices



- Safely Remove Device Icon will show in System Tray




To remove PCMCIA modems or Expresscard modems using a PCMCIA adapter without shutting down the computer

Right click on the safely remove icon is system tray



Click on "NEC PCI to USB....", Stop | click OK | click Close.



If required, drivers are available for download at <a href="https://www.nvtl.com/releases/NvtlDriver-V2.01.07MSl.zip">www.nvtl.com/releases/NvtlDriver-V2.01.07MSl.zip</a>