This document explains how to set up dial up connection for a UMTS/HSPA Data card on Windows XP.

Preparation

Requirements


- ✓ Windows 2000/ XP pre-installed on your computer
- ✓ Administrator privileges on the Windows XP machine.
- ✓ Data Card "Modem"
- ✓ Activated SIM Card
- ✓ Network Coverage


Setup


When you have met all these requirements, follow these steps to perform the installation and configuration.


To start the setup there are two options,

- a. Select "Start" -> "connect To" -> "Show all Connections".
- b. Or select "Start" -> "Control Panel" -> "Network Connections"












Add APN to modem initialization string.





Connect




Disconnect

Network Connection in System Tray | Right Click | Disconnect




Or

To disconnect, **double click** on the desktop shortcut icon for your dialup connection to open connection status and click on **Disconnect**.



Or

Go to Start | Connect To | Show all connections | Find Dial-up section, your connection - Right Click | Disconnect.



Troubleshooting

LED Color	LED State	Description
RED	SIM Error No Service	Flashing: SIM card may be missing or inserted incorrectly. Solid: GPRS/EDGE/UMTS/HSDPA cellular service is currently not available.
GREEN	GPRS	Flashing: GPRS service is available. Solid: Connected to a network using GPRS.
VIOLET	EDGE	Flashing: EDGE service is available. Solid: Connected to a network using EDGE.
BLUE	UMTS	Flashing: UMTS service is available. Solid:* Connected to a network using UMTS.
YELLOW	HSDPA	Solid:* HSDPA service is available and is being used during the download.

Note: 5 LED colors not supported on U630, U530 or U520

If the LED is not lit, then check that the device is connected properly. If physical connection seems good, then check for the device in the device manager.

Device Manager

Verify that your device is found in Device Manager without Red 'X's or Yellow Triangles with '!". If these conditions show, then there is a driver problem or device conflict

When you insert your Novatel Wireless device into your computer, Windows will double ding and popup messages indicating new hardware found. Please note any error or warning messages that may popup.


To get Hardware Device Manager Information

- Start | Control Panel | System
- Hardware tab
- Select Device Manager



- Click '+' to expand a device type
- Highlight device (left click)
- Right Click Select Properties (left click)

Please check one of the following sections appropriate for your device




ExpressCard Devices XU870

X950D

2 Devices Must show


- Modem Section Novatel Wireless Merlin HSDPA Modem
- Ports Section Novatel Wireless Merlin HSDPA Status Port (COM# will vary by system)



- Depending on the device and options available, other Novatel Wireless Merlin ports may also show.
- The 'Safely Remove Device' icon may not show in system tray not required for this device

Note

- if you are using a ExpressCard-PCMCIA adapter, you will also see



Safely Remove Device Icon will show in System Tray

Ovation USB 2 Devices Must show Modem Section - Novatel Wireless Merlin HSDPA Modem Devices Ports Section - Novatel Wireless Merlin HSDPA Status Port (COM# will vary by system) MC950D MC930D 🖢 Modems 🛴 Novatel Wireless Merlin HSDPA Modem 🤇 ± 🥦 Monitors • Betwork adapters 🗓 📳 PCMCIA adapters Ports (COM & LPT) 📝 Novatel Wireless Merlin HSDPA Status Port (COM. 🛨 \infty Processors Depending on the device and options available, other Novatel Wireless Merlin ports may also show. The 'Safely Remove Device' icon may not show in system tray not required for this device

If required, drivers are available for download at www.nvtl.com/releases/NvtlDriver-v2.01.07MSl.zip