
# Merlin U520™ Quick Start Guide

- 1. Insert the SIM card into the modem\*
- SIM Card contact points must face upwards, and the orientation notch must be positioned as shown in the picture.



#### 2. Install the MobiLink<sup>™</sup> Software


- Insert the MobiLink Software CD into your computer. If the setup program does not launch automatically, open the .exe program on the CD.
- Select the appropriate links and follow the on-screen prompts. You will be asked to re-boot the computer and the MobiLink icon will be placed on the desktop.

## 3. Insert the Merlin U520 into your PC

### 4. Launch MobiLink

■ Double-click the MobiLink icon to launch the application.

## 5. Using MobiLink



\*UMTS and SMS are subscription services and must be enabled on the SIM card. For technical support, contact your service provider. Visit www.novatelwireless.com for the latest software upgrades. The Novatel Wireless logo, Merlin, Merlin U520 and MobiLink are trademarks of Novatel Wireless, Inc.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference (2) This device must accept any interference received, including interference that may cause undesired NOTES:
SEE PAGE 1 FOR FULL NOTES
1. TWO FOLDS ON EITHER SIDE OF
BOX SPINE MARKED.
2. PAPER OUTLINE DOES NOT PRINT

Novatel Wireless Technologies Ltd. Suite 200, 6715 - 8th St NE Calgary, AB Canada T2E 7H7 Phone: 403 295 4800

TITLE: INSERT PRINTED MERLIN U520 GENERIC

NOVATEL WIRELESS

HISTORY: (indicate: REV / DATE / ARTIST / REV. CHANGES) > Rev.1 07/22/04 - Lawrence Zalasky - INITIAL RELEASE BASED ON U520 ATT INSERT P/N: 14615568 pg 2/2