This document explains how to set up dial up connection for a CDMA/EVDO Data card on Windows XP.

Preparation

Requirements


- ✓ Windows 2000/ XP pre-installed on your computer
- ✓ Activated Data Card "Modem"
- ✓ Network Coverage
- ✓ Administrator privileges on the Windows XP machine.


Setup


When you have met all these requirements, follow these steps to perform the installation and configuration.

To start the setup there are two options,

- a. Select "Start" -> "connect To" -> "Show all Connections".
- b. Or select "Start" -> "Control Panel" -> "Network Connections"








Internet Account Information lew Connection Wizard Internet Account Information You will need an account name and password to sign in to your Internet account. - Please leave the User name, Type an ISP account name and password, then write down this information and store it in a safe place. (If you have forgotten an existing account name or password, contact your ISP.) Password, and Confirm password fields blank Password: Please leave these fields blank Depending on your preference, you may choose to check/uncheck the Use this account name and password when anyone connects to the Internet from box for Make this the default Internet Make this the default Internet connection Depends on user ___ preference connection And click 'Next' to continue. ⟨Back Next⟩ Cancel Completing the New Connection Wizard Completing the New Connection Wizard Click on Add a shortcut to this connection to You have successfully completed the steps needed to create the following connection: my desktop Shows the name you have used for this connection Share with all users of this computer Use the same user name & password for everyone And click 'Finish' The connection will be saved in the Network Connections folder. Add a shortcut to this connection to my deskto To create the connection and close this wizard, click Finish < <u>B</u>ack Finish Cancel

Connect




Disconnect

Network Connection in System Tray | Right Click | Disconnect




Or

To disconnect, **double click** on the desktop shortcut icon for your dialup connection to open connection status and click on **Disconnect**.



Or

Go to Start | Connect To | Show all connections | Find Dial-up section, your connection - Right Click | Disconnect.



Troubleshooting

LED Indicator	
LED not lit	No Power to Card - physical - driver or conflict
LED <i>RED</i>	Card can not acquire CDMA service (outside coverage area)
LED GREEN After a few seconds – flashing 1 per second	Card is registered with a CDMA network - does not require * CM to be running *CM - Connection Manager
LED ORANGE	Card Fault – replace card

If the LED is not lit, then check that the device is connected properly. If physical connection seems good, then check for the device in the device manager.

Device Manager

Verify that your device is found in Device Manager without Red 'X's or Yellow Triangles with '!" If these conditions show, then there is a driver problem or device conflict

When you insert your Novatel Wireless device into your computer, Windows will double ding and popup messages indicating new hardware found. Please note any error or warning messages that may popup.


To get Hardware Device Manager Information

- Start | Control Panel | System
- Hardware tab
- Select Device Manager



- Click '+' to expand a device type
- Highlight device (left click)
- Right Click Select Properties (left click)

Please check one of the following sections appropriate for your device




ExpressCard Devices

V640, V740 EX720 XV620, X720

2 Devices Must show


- Modem Section Novatel Wireless Merlin CDMA EV-DO Modem
- Ports Section Novatel Wireless Merlin CDMA EV-DO Status Port (COM# will vary by system)



- Wireless Merlin ports may also show.
- The 'Safely Remove Device' icon may not show in system tray not required for this device

Note

if you are using a ExpressCard-PCMCIA adapter, you will also see



Safely Remove Device Icon will show in System Tray

Ovation USB 2 Devices Must show Modem Section – Novatel Wireless Merlin CDMA EV-DO Modem **Devices** Ports Section – Novatel Wireless Merlin CDMA EV-DO Status Port (COM# will vary by system) MCD 3000. 💂 Device Manager U720, USB720 MC727, U727, Elle Action View Help USB727 II 🖨 😰 🔉 Mice and other pointing devices 🖢 Novatel Wireless Merlin CDMA EV-DO Modem Monitors By Network adapters Ports (COM & LPT) Novatel Wireless Merlin CDMA EV-DO Status Port (COMI) 🗞 Smart card readers Depending on the device and options available, other Novatel

Wireless Merlin ports may also show.

not required for this device

The 'Safely Remove Device' icon may not show in system tray -

If required, drivers are available for download at www.nvtl.com/releases/NvtlDriver V2.01.07MSI.zip