### Building with the myRIO Robotics Kit


## Square Headed Bolts:



Slide square headed bolt Attach desired part into maker beam slot

Fasten with M3 Nut

#### T-Slot Nuts:



Slide T-Slot Nut into makerBeam slot

Line up desired part

Fasten using M3 Fastener

# Attaching LEGOs:




bolts


Insert square head Attach technic beam with M3 Nuts

Build with LEGO!

#### Gears:



**Step 1:** Attach servo gear to servo motor using a washer and servo screw.



Step 2: Use a square headed bolt as an axle and lock down using an M3 Bolt.



**Step 3:** Place rotating gear over bolt and secure with M3 Nut. Make sure the gear can still rotate.



**Step 4:** Use second M3 Nut to lock first M3 Nut in place to avoid loosening when gear rotates

Lock bottom nut
to top nut to
prevent loosening
when gear spins

