
PAGE : ALL LAYER




NOT1 Components highlighted in red will not be assembled (NC).

PAGE : ALL LAYER

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.

PAGE : TOP LAYER




NOT1 Components highlighted in red will not be assembled (NC).

PAGE : TOP LAYER

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.

PAGE : Inner Layer 2




NOT1 Components highlighted in red will not be assembled (NC).

PAGE : Inner Layer 2

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.

PAGE : Inner Layer 3




NOT1 Components highlighted in red will not be assembled (NC).

PAGE : Inner Layer 3

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.

PAGE : BOTTOM LAYER




NOT1 Components highlighted in red will not be assembled (NC).

PAGE : BOTTOM LAYER

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.

PAGE : BOTTOM LAYER MIRROR



NOT1 Components highlighted in red will not be assembled (NC).

PAGE : BOTTOM LAYER MIRROR

		USB to RS485_RS422 Converter			
		ASSEMBLY DOCUMENT		**FO_PRJ_01101 _AA**	
		FO Doc.Rev	.pFoRevision	PBA Rev	AAAA
Haz/Prep	**Cemil Kendir**	FO Tarih/Date	.pFoDate	Scale	SCALE: 1.00
Kont/Check	**Gunes Kendir**	Ortam/Env	Altium Designer 23.9.2		
Onay/Appr	**Cemre Kendir**				

(c) 2022 by SCGC Elektronik A.S. All rights Reserved. No part of this document may be produced or transmitted in any form or by any means electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of SCGC.