

NAVIGATION

 **Move Cursor** - UP or DOWN or LEFT or RIGHT

 **Screen Navigation** - hold SHIFT + [UP or DOWN or LEFT or RIGHT]

EDITING

 **Change Value** fine - hold EDIT + [LEFT or RIGHT]

 **Change Value** coarse - hold EDIT + [UP or DOWN]

 **Cut Value** or set to default - EDIT + OPTION

 **YES** in dialog - EDIT

 **NO** (or exit) in dialog - OPTION

PLAY

 **Play All Tracks** from song cursor - hold SHIFT + PLAY

 **Mute Current Track** - hold OPTION + SHIFT
(latch mute by releasing OPTION first)

 **Solo Current Track** - hold OPTION + PLAY
(latch solo by releasing OPTION first)

 **Clear All Mute** and solos - hold OPTION + hold SHIFT + PLAY

MIXER SCREEN

 **Create Snapshot** - hold SHIFT + OPTION

 **Recall Snapshot** - hold SHIFT + EDIT

GLOBAL

 **Cycle Themes** - hold SHIFT + OPTION then tap UP

 **Toggle Display Mode** Oscilloscope - hold SHIFT + OPTION then tap DOWN

PHRASE SCREEN

 **Create** new instrument - on instrument column, EDIT (double-tap)

 **Clone and Paste** instrument - hold SHIFT + OPTION then EDIT

 **Jump to Track** left or right - hold OPTION + [LEFT or RIGHT]

 **Jump to Phrase** previous or next - hold OPTION + [UP or DOWN]

 **Interpolate** - in selection mode (single column), hold SHIFT + EDIT

 **Move** selection - in selection mode (multi column), hold EDIT + [UP or DOWN]

 **Note Fill** - in selection mode (note column), hold OPTION + LEFT

 **Random Fill** - in selection mode (note column), hold OPTION + RIGHT
velocity can be randomized if selected

 **Randomize Notes** Up or Down - in selection mode (note column), hold OPTION + [UP or DOWN]

SONG SCREEN

 **Cue Row** while playing - hold LEFT + PLAY

 **Create** new chain - double-tap EDIT

 **Clone and Paste** chain alone - hold SHIFT + OPTION then EDIT

 **Clone and Paste** chain & phrases - hold SHIFT + OPTION then double-tap EDIT

 **Solo Tracks** left or right - hold OPTION + [LEFT or RIGHT]

 **Solo Row** Live Mode - hold OPTION + PLAY

 **Jump 16 Rows** up or down - hold OPTION + [UP or DOWN]

 **Move Selection** - in selection mode, hold EDIT + [UP or DOWN]

 **Render Selection** - in selection mode, double-tap EDIT

SELECTION

 **Enter Selection Mode** - hold SHIFT + OPTION
(tap OPTION to cycle through modes)

 **Copy Selection** (exit mode) - OPTION

 **Paste Copy Buffer** - hold SHIFT + EDIT

FILE BROWSER

 **Preview Sample** - PLAY

 **Sort Directory** - SHIFT + OPTION

 **Delete Selected File** - EDIT + OPTION

INSTRUMENT SCREEN

 **Preview Instrument** - PLAY

 **Copy Instrument** - hold SHIFT + OPTION

 **Jump to Instrument** previous or next - OPTION + [LEFT or RIGHT]

 **Edit Parameter** - EDIT + [Touchscreen LEFT and RIGHT]

 **Map Parameter** - OPTION + [Touchscreen LEFT and RIGHT or UP and DOWN]

CHAIN SCREEN

 **Create** new phrase - double-tap EDIT

 **Clone and Paste** phrase - hold SHIFT + OPTION then EDIT

 **Jump to Track** left or right - hold OPTION + [LEFT or RIGHT]

 **Jump to Chain** previous or next - hold OPTION + [UP or DOWN]

 **Play All Tracks** continue song from cursor position - hold SHIFT + PLAY