brsitoa()

Converts a DINT value into a character string

This function block can only be used conditionally for **redundancy**. The applicable limitations are described in the following sections:

Hidden pointer usage

Additional information can be found in the "Redundancy" section.

Parameters

I/O	Parameter	Data type	Description
IN	value	DINT	Numerical value to be converted into a string
IN	pString	UDINT (given as a pointer to STRING)	Address of destination character string
OUT	length	UINT	Length of character string produced

Call syntax (Automation Basic)

length = brsitoa(value,adr(Str))

Note

The brsitoa function converts a DINT value into a character string.

Examples

Automation Basic ANSI C Structured Text