brsatod()

Converts a string to a LREAL (DOUBLE) value

The numerical value to be converted must be represented in decimal format. Other number formats, such as binary, hexadecimal, etc. are not supported.

This function block can only be used for **redundancy** in certain circumstances! Applicable limitations are described in the following sections:

Hidden pointer usage

For additional information about redundancy, see section "Redundancy".

Parameters

I/O	Parameter	Data type	Description
IN	pString	UDINT (given as a pointer to STRING)	Address of the string that should be converted
OUT	z	LREAL	Numerical value of the string

Call syntax (Automation Basic)

z = brsatod(adr(Str))

Note

Function "brsatod" converts a string to a LREAL (DOUBLE) value.

Examples

Automation Basic ANSI C Structured Text