

Full setup: raw vs. de-embedded (perfect)

Raw = VNA port 1 -> circulator -> switch RF1 -> cable -> resonator -> back to port 2, VNA cal off.

De-embedded: perfect standards, plane inside the switch. Both repeats averaged.

