MCN Signals


Sheet 1/7

Sensor Configurations


MCN1 AIN-1 Front Suspension Travel AIN-2 Rear Suspension Travel AIN-3 Steering Angle AIN-4 Ambient Temp. Ambient Pres. AIN-5 AIN-6 Motor Inlet Pressure AIN-7 Unused Analog 1 AIN-8 Unused Analog 2 GPIO-0 Unused GPIO 1 Unused GPIO 2 GPIO-1

	MCN2
AIN-1	Coolant Temp. Motor Inlet
AIN-2	Coolant Temp. Motor Outlet
AIN-3	Coolant Temp. Controller Inlet
AIN-4	Coolant Temp. Controller Outlet
AIN-5	Contactor Box Temp.
AIN-6	Unused Analog 3
AIN-7	Unused Analog 4
AIN-8	Unused Analog 5
GPIO-0	Coolant Flow Controller Loop
GPIO-1	Coolant Flow Motor Loop


	MCN3
AIN-1	Front Tire Temp.
AIN-2	Rear Tire Temp
AIN-3	Flex 1
AIN-4	Flex 2
AIN-5	Flex 3
AIN-6	Unused Analog 6
AIN-7	Unused Analog 7
AIN-8	Unused Analog 8
GPIO-0	Unused GPIO 3
GPIO-1	Unused GPIO 4



Infrared Camera Front/Rear Tire Temp.




Barometer Amb. Pres., Motor Inlet Pres.




Rider Controls		
AIN-1	Throttle Position	
AIN-2	Unused Analog 9	
GPIO-0	Throttle Enable	
GPIO-1	Unusued GPIO 5	

Toggle Switch Throttle Enable




Thermistor

Motor in/out temp., Controller in/out temp Amb. Temp., Contactor Box Temp.




Strain Gauge Flex 1, 2, 3



Flow


Motor Loop Flow, Controller Loop Flow 3V3







Board: Sensor Breakout Board
Drawn by Clayton Greenbaum

Revision date: 2/1/14











Board: Sensor Breakout Board Drawn by Clayton Greenbaum Revision date: 2/1/14

MCN2 TEMP CLNT MTR IN TEMP_CLNT_MTR_IN_MCN2 R3 -WW-0 GND 11 1k 2.2uF C9 _TEMP_CLNT_MTR_OUT TEMP CLNI MTR OUT MCN2 0 1k GND 2.2uF C10 R6 --WW-TEMP CLNT MCTL IN TEMP_CLNT_MCTL_IN_MCN2 R24 0 1k GND μΫ́ 2.2u ò TEMP CLNT MCTL OUT TEMP CLNT MCTL OUT MCN2 R26 0 GND 1k 2.2uF C12 __TEMP_CONTACTOR_BOX R27 TEMP CONTACTOR BOX MCN2 R28 0 10k GND 2.2uF C15 UNUSED A3 AIN6 MCN2 R30 na GND **** na C16 __UNUSED_A4 AIN7 MCN2 R38 na GND na R39 --**W**W-UNUSED A5 AIN8_MCN2 R40 na na GND C20







Board: Sensor Breakout Board Drawn by Clayton Greenbaum Revision date: 2/1/14

MCN3 TEMP_TIRE_FRNT_MCN3 TEMP TIRE FRNT R42 12k 20k GND 270pF C21 R43 --**WW**-_ TEMP TIRE REAR TEMP TIRE REAR MCN3 R44 12k 20k GND FLEX1 FLEX1 MCN3 R46 0 na GND 270pF C23 FLEX2 FLEX2 MCN3 R48 0 W GND na _FLEX3 FLEX3 MCN3 R50 0 GND na 270pF C25 UNUSED A6 AIN6 MCN3 R52 na na GND 029 C26 AIN7 MCN3 UNUSED A7 R58 na na

R60 na


na

30 (a

AIN8_MCN3

UNUSED A8

GND






GND 12V

CANA H

CANA_L


GND







Board: Sensor Breakout Board Drawn by Clayton Greenbaum Revision date: 2/1/14

Rider Control MCN











Board: Sensor Breakout Board Drawn by Clayton Greenbaum Revision date: 2/1/14

Sheet 6/7









Board: Sensor Breakout Board Drawn by Clayton Greenbaum Revision date: 2/1/14

Big Plug Sheet 7/7


MCN1

UNUSED GP2	PAD1
UNUSED GP1	PAD2
UNUSED A2	PAD3
UNUSED A1	PAD4
SUSP FRNT	PAD5
SUSP REAR	PAD6
3V3 MCN1	PAD7
5V MCN1	PAD8
TEMP AMB	PAD9
STEER ANG	PAD10
PRES AMB	PAD11
PRES MTR IN	PAD12
	^

MCN2

FLOW MTRLOOP MCN2	PAD13
FLOW MCTLLOOP MCN2	PAD14
UNUSED A5	PAD15
UNUSED A4	PAD16
TEMP_CLNT_MTR_IN	PAD17
TEMP CLNT MTR OUT	PAD18
3V3 MCN2	PAD19
5V MCN2	PAD20
TEMP CLNT MCTL OUT	PAD21
TEMP_CLNT_MCTL_IN	PAD22
TEMP CONTACTOR BOX	PAD23
UNUSED A3	PAD24
_	

CANA H	PAD45	CAN2 L	PAD44
CANA L	PAD47	CAN2 H	PAD46



MCN3

UNUSED GP4	PAD25
UNUSED_GP3	PAD26
UNUSED A8	PAD27
UNUSED A7	PAD28
TEMP TIRE FRNT	PAD29
TEMP TIRE REAR	PAD30
3V3 MCN3	PAD31
5V MCN3	PAD32
FLEX2	PAD33
FLEX1	PAD34
FLEX3	PAD35
UNUSED A6	PAD36
0.10000	\longrightarrow

RCTL

UNUSED GP6	PAD37
THRTL EN	PAD38
THRTL POS	PAD39
UNUSED_A9	PAD40
3V3 RCTL	PAD41
5V RCTL	PAD42

