- 2023/08/25 ERT3 ver4
  1. fix R1~R8 value error, I onle change its name from 300 to 200, which won't change its accutual value.
  2. split V\_ready of V\_PSU\_data and V\_date individually, also connect OE# of U103 to ground from V\_enable.
  3. add DMM\_ref and V\_PSU\_ready pin .
  4. combine all the data pin to one.(arduino code need to change)

