Add DDQ Rules Through UI

- 1. Open the Office GUI
- 2. Navigate to Rule Management > Rules (double-click) > DDQ Rules
- 3. Click on the 'Enable Table Editing' button Enable Table Editing
- 4. Click on the 'Insert new row' button Insert New Row
- 5. Add appropriate values to row
- 6. Click on the 'Save changes' button Save Changes

Use the below table as a reference. Items should be entered in the same order

Rule Values

| | Mill Product | | Special |
|------------------|---------------------|------------------|------------------------------|
| Product Family | Type | Specific Grade | Attributes |
| ULTRA_NARROW*all | | | Width less than equal to 38" |
| HR | HRB | | • |
| HRPA | HRPA | | |
| SK | HRSK | | |
| PO | HRPO | | |
| SKPO | SKPO | | |
| $CRML_AOD$ | CR | 1001* & 1002* | |
| CRFH | CRFH, RMFH, | | |
| | POTP, HRTP | | |
| CR | CR | | |
| $GALV_LG$ | HRGA, HRGI, | | Gauge less than |
| | GI, GA | | equal to .023" |
| GALV_HR | HRGA, HRGI | | |
| GALV_FH | GI, GA | 1005T1, $1006T1$ | |
| GALV | GI, GA | | |
| Other | | | |