Order Analysis for Caster Scheduler

- Open Caster Scheduler
- Select the Caster from left navigation
- Select the 'Input' tab in the top navigation Select Caster
- Click on Orders > Production Orders > Line Orders > Production Orders
- Left-click the bar graph Left Click Bar Graph
- Click on Excel-Export in top navigation
- Select 'Print current stock' from the list of options Excel-Export
- Choose a location to save the export
- Give the export file a name
- Click the 'Save' button Save Export
- Export is saved as a CSV file in the chosen location