CapTreeView Configuration

Navigate to the DDQ Monitoring CapTreeView > Context-Flows

- 1. Open DDQ Monitoring
- 2. Navigate to the 'Config' tab
- 3. Click on 'CapTreeView'
- 4. Expand 'Cap-Spreadsheet-Contexts'
- 5. Expand 'Context-Flows' DDQ Mon Cap Tree

Update/Insert/Remove Context-Flows Values

- 1. Select an item from the list in the left-hand pane
- 2. Update the 'Line-Name' value in the right-hand pane by:
 - 1. Select the 'Line-Name' field
 - 2. Click on the ellipses (...) inside of the 'Line-Name' field
 - 3. Select the correct line item from the dialog
 - 4. Click the 'OK' button Configure Context-Flows
 - 5. If you need to remove any extra line items, right-click on the line item and select 'Remove'
 - Remove Context-Flows Item
 - 6. If you need to add a new line, right-click on the line item that you need to insert below, select 'Insert Line'
 - Insert Context-Flows Item
 - 7. Click on the 'Save' button Save

Update/Insert/Remove Context-CTP Values

1. Follow the same steps above, but for the Context-CTP values Update Context-CTP Values

Update/Insert/Remove Input Value

- 1. Expand 'Input'
- 2. Follow the same steps above to se the value to 'CCM1' Update Input