# MONERIS QUICK REFERENCE GUIDE

#### **KEYS**



### **OPENING**

## Logon the Machine:

- 1. Press \*\*\*
- 2. Press .,#\*
- 3. Enter **02**.
- 4. Press
- 5. Swipe the POS ADMIN card. The READY screen appears.

### **TRANSACTIONS**

#### Process a Credit Refund:

- 1. Press .,#\*
- 2. Press \*\*\*
- 3. Enter **101**.
- 4. Press
- 5. Swipe the POS ADMIN card.
- 6. Enter the refund amount.
- 7. Enter the authorization number.
- 8. Insert the patron's credit card and turn the machine over to the patron.

  The refund receipt prints.

# Reprint the Last Customer Receipt:

- 1. Press .,#\*
- 2. Press .,#\*
- 3. Enter **29**

## **CLOSING**

## Print the Daily Transactions Report:

- 1. Press .,#\*
- 2. Press .,#\*
- 3. Enter **60**.
- 4. Press
- 5. Press
- 6. Press (F1).
- 7. Press
- 8. Press (**F4**).
  The report prints and the machine returns to the READY screen.

**NOTE**: If you get the TRANSACTION NOT FOUND message that means there were no credit/debit transactions made during the day. Press until you see the READY screen.

## Print the Weekly Transactions Report:

- 1. Press ...#\*
- 2. Press .,#\*
- 3. Enter **99**.
- 4. Press O.

The report starts printing.

**NOTE**: Do not remove from the machine.

5. Press (F1).

The report finishes printing and the machine returns to the READY screen.

# Logoff the Machine:

- 1. Press .,#\*
- 2. Press .,#\*
- 3. Enter **03**